

IO-Link Wireless System Extensions

Specification

**Version 1.1
March 2018**

Order No: 10.112

File name: IO-Link_Wireless_System_10112_V1.1_Mar18

This specification has been prepared by the IO-Link Wireless technology subgroup of the IO-Link community for review.

Any comments, proposals, requests on this document are appreciated through the IO-Link CR database www.io-link-projects.com. Please provide name and email address.

Login: IO-Link.Wireless

Password: Comments

Important notes:

NOTE 1 The IO-Link Consortium Rules shall be observed prior to the development and marketing of IO-Link products. The document can be downloaded from the www.io-link.com portal.

NOTE 2 Any IO-Link device shall provide an associated IODD file. Easy access to the file and potential updates shall be possible. It is the responsibility of the IO-Link device manufacturer to test the IODD file with the help of the IODD-Checker tool available per download from www.io-link.com.

NOTE 3 Any IO-Link devices shall provide an associated manufacturer declaration on the conformity of the device with this specification, its related IODD, and test documents, available per download from www.io-link.com.

Disclaimer:

The attention of adopters is directed to the possibility that compliance with or adoption of IO-Link Consortium specifications may require use of an invention covered by patent rights. The IO-Link Consortium shall not be responsible for identifying patents for which a license may be required by any IO-Link Consortium specification, or for conducting legal inquiries into the legal validity or scope of those patents that are brought to its attention. IO-Link Consortium specifications are prospective and advisory only. Prospective users are responsible for protecting themselves against liability for infringement of patents.

The information contained in this document is subject to change without notice. The material in this document details an IO-Link Consortium specification in accordance with the license and notices set forth on this page. This document does not represent a commitment to implement any portion of this specification in any company's products.

WHILE THE INFORMATION IN THIS PUBLICATION IS BELIEVED TO BE ACCURATE, THE IO-LINK CONSORTIUM MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL INCLUDING, BUT NOT LIMITED TO ANY WARRANTY OF TITLE OR OWNERSHIP, IMPLIED WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR USE.

In no event shall the IO-Link Consortium be liable for errors contained herein or for indirect, incidental, special, consequential, reliance or cover damages, including loss of profits, revenue, data or use, incurred by any user or any third party. Compliance with this specification does not absolve manufacturers of IO-Link equipment, from the requirements of safety and regulatory agencies (TÜV, BIA, UL, CSA, etc.).

 **IO-Link** ® is registered trade mark. The use is restricted for members of the IO-Link Consortium. More detailed terms for the use can be found in the IO-Link Consortium Rules on www.io-link.com.

Conventions:

In this specification, the following key words (in **bold** text) will be used:

may: indicates flexibility of choice with no implied preference.

should: indicates flexibility of choice with a strongly preferred implementation.

shall: indicates a mandatory requirement. Designers **shall** implement such mandatory requirements to ensure interoperability and to claim conformity with this specification.

Publisher:

IO-Link Community

Haid-und-Neu-Str. 7

76131 Karlsruhe

Germany

Phone: +49 721 / 96 58 590

Fax: +49 721 / 96 58 589

E-mail: info@io-link.com

Web site: www.io-link.com

© No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

CONTENTS

1		
2		
3	Introduction.....	12
4	General.....	12
5	1 Scope.....	15
6	1.1 Structure of the document.....	17
7	2 Normative references.....	18
8	3 Terms, definitions, symbols, abbreviated terms and conventions.....	18
9	3.1 Common terms and definitions.....	18
10	3.2 Abbreviated terms.....	22
11	3.3 Conventions.....	22
12	4 Overview of IO-Link wireless.....	26
13	4.1 Purpose and topology.....	26
14	4.2 Positioning in the automation hierarchy.....	27
15	4.3 Cell concept.....	29
16	4.4 Wireless Mechanisms.....	30
17	4.5 Concept of Air Interface.....	33
18	5 Air interface / Physical Layer (PL).....	38
19	5.1 Base technology, Physical Layer (PL).....	38
20	5.2 Downlink and Uplink.....	43
21	5.3 W-Sub-cycle.....	47
22	5.4 Medium Access Control (MAC).....	49
23	5.5 Physical Layer PL services.....	51
24	5.6 Physical Layer PL protocol.....	69
25	6 Data Link Layer (DL-A).....	94
26	6.1 General (W-Master).....	94
27	6.2 General (W-Device).....	95
28	6.3 DL-A services.....	96
29	6.4 Acknowledgments (DownLinkAck and UpLinkAck).....	102
30	6.5 Message handler.....	102
31	7 Data Link Layer (DL-B).....	114
32	7.1 DL-B services.....	114
33	7.2 DL-mode handler.....	124
34	7.3 Process Data handler.....	130
35	7.4 Indexed Service Data Unit (ISDU) handler.....	140
36	7.5 Command handler.....	145
37	7.6 Event handler.....	148
38	7.7 Transmission of Segmented Data and retry handling.....	152
39	8. Application Layer (AL).....	155
40	8.1 General.....	155
41	8.2 Application Layer services.....	156
42	8.3 Application layer protocol.....	163
43	9. System management (SM).....	174
44	9.1 General.....	174
45	9.2 System management of the W-Master.....	174
46	1 183	
47	9.3 System management of the W-Device.....	199
48	10 W-Device.....	213
49	10.1 Overview.....	213
50	10.2 Process Data Exchange (PDE).....	214
51	10.3 IMA handling.....	214
52	10.4 Parameter Manager (PM).....	214
53	10.5 Data Storage (DS).....	215
54	10.6 Event Dispatcher (ED).....	216
55	10.7 W-Device features.....	216
56	10.8 W-Device design rules and constraints.....	218
57	Annex C.....	220
58	10.9 I/O W-Device description (W-IODD).....	220
59	10.10 W-Device diagnosis.....	222
60	10.11 W-Device connectivity.....	225

61	11	W-Master.....	226
62	11.1	Overview.....	226
63	11.2	Configuration Manager (CM).....	228
64	11.3	Data Storage (DS).....	234
65	11.4	On-request Data Exchange (ODE).....	243
66	11.5	Diagnosis Unit (DU).....	244
67	11.6	Process Data Exchange (PDE).....	245
68	11.7	Port and Device configuration tool (PDCT).....	247
69	11.8	Gateway application.....	248
70	11.9	Human machine Interface HMI.....	250
71	Annex A.....	251	
72	12	W-Messages Codings.....	251
73	12.1	Overview.....	251
74	12.2	Definition of a W-Message.....	251
75	12.3	Downlink W-Messages: Control Octets.....	251
76	12.4	Uplink W-Messages.....	253
77	12.5	Example for combination of several W-Messages within a DLink / PreDLink.....	253
78	12.6	Example for DLink data transmission within cyclic process data and segmentation.....	254
79	12.7	Examples for uplink data transmissions.....	255
80	12.8	User data (PD or OD).....	256
81	12.9	PDVALID PDINVALID.....	257
82	12.10	General structure and encoding of ISDUs.....	257
83	12.11	General structure and encoding of Events.....	257
84	Annex B.....	259	
85	13	W-Frame Codings, CRC calculation and errors.....	259
86	13.1	Description of ConnectionParameter.....	259
87	13.2	W-Frame Downlink encodings for Normal Operation.....	259
88	13.3	W-Frame Downlink encodings for Configuration Operation.....	260
89	13.4	Uplink encodings for Normal Operations.....	264
90	13.5	Uplink encodings for Configuration Operations.....	266
91	13.6	Acknowledge Generation.....	268
92	13.7	CRC16 and CRC32 calculation.....	268
93	13.8	Errors.....	268
94	Annex C.....	270	
95	14	W-Device Parameter and commands.....	270
96	14.1	Direct Parameter Page 1.....	271
97	14.2	Direct Parameter Page 2.....	275
98	14.3	Wireless Parameter (W-Parameter).....	275
99	Annex D.....	282	
100	15	EventCodes.....	282
101	15.1	EventCodes for Devices.....	282
102	Annex E.....	285	
103	16	Data Types.....	285
104	Annex F.....	285	
105	17	Device design rules for low Energy W-Devices.....	285
106	17.1	Low Energy W-Devices.....	285
107	17.2	Battery lifetime calculation.....	286
108	Annex G.....	288	
109	18	Frequency Hopping Calculation.....	288
110	18.1	Blacklisting.....	288
111	18.2	Creation of frequency hopping table HT01 with blacklisting.....	288
112	18.3	Modified Sequence for ServiceMode.....	292
113	18.4	Adaptive Hopping Table (AHT).....	293
114	Annex H.....	297	
115	19	How to get a certified product.....	297
116	19.1	Radio Certification.....	297
117	19.2	IO-Link Certification.....	297
118	Annex I.....	298	
119	20	Regulatory Compliance.....	298
120	20.1	General.....	298

121	20.2	Compliance with FCC 15.247	298
122	20.3	Compliance with ETSI EN 300 328 V2.1.1 (2016-11)	298
123	20.4	Compliance with ETSI EN 300 440 V.2.1.1 (2017-03)	298
124		Annex J	299
125	21	Wireless IODD File handling	299
126	21.1	File naming convention	299
127	21.2	Rules merging IODD and W-IODD file for W-Bridges	299
128	22	Bibliography	301
129			
130	Figure 1	Relationships of this document to standards	12
131	Figure 2	Logical structure of W-Master and W-Device	15
132	Figure 3	Detailed overview of the W-Master	16
133	Figure 4	Detailed overview of the W-Device	17
134	Figure 5	Generalized example of a confirmed service	22
135	Figure 6	Example of initiator / receiver of services (W-Device)	23
136	Figure 7	Example of service between W-Master and W-Device in generalized and detailed view	24
137	Figure 8	Example of confirmed / non-confirmed services (W-Device)	24
138	Figure 9	IO-Link and IO-Link wireless topology	26
139	Figure 10	IO-Link wireless system	27
140	Figure 11	Object transfer at the application layer level (AL)	28
141	Figure 12	Radius of a cell with a 1 track W-Master	29
142	Figure 13	W-Master cell consisting of 2 W-Master	30
143	Figure 14	Cell concept	30
144	Figure 15	Roaming between W-Master cells	32
145	Figure 16	Downlink	34
146	Figure 17	Uplink	34
147	Figure 18	Transmission capacity with SSlots and DSlots	35
148	Figure 19	Uplink assignments	35
149	Figure 20	TDMA and FDMA in the W-Cycle	36
150	Figure 21	W-Frame and W-Sub-cycle	37
151	Figure 22	Physical layer (W-Master)	38
152	Figure 23	Physical layer (W-Device)	38
153	Figure 24	Base technology and modulation	39
154	Figure 25	Transceiver timings	40
155	Figure 26	Memory Storage and transmission order for values for WORD based data types	43
156	Figure 27	Bit ordering within an octet	43
157	Figure 28	Octet array transmission over the air	43
158	Figure 29	Octet ordering of Preamble values	44
159	Figure 30	Octet ordering of ConfigSyncword	44
160	Figure 31	Octet ordering of DataSyncword	44
161	Figure 32	Octet ordering of CRC16 result values	44
162	Figure 33	Octet ordering of CRC32 result values	44
163	Figure 34	Data Whitening LFSR	45
164	Figure 35	Regular Downlink	45
165	Figure 36	Configuration Downlink	46
166	Figure 37	Uplink - SSlot	46
167	Figure 38	Uplink - DSlot	47
168	Figure 39	Format of a W-Sub-cycle with DSlots	48
169	Figure 40	SSlots and DSlots	48
170	Figure 41	W-Frame structure	49
171	Figure 42	W-Frame type for pairing and configuration	49
172	Figure 43	Physical Layer services of the W-Master	52
173	Figure 44	Physical Layer services of the W-Device	62
174	Figure 45	Usage of the Configuration Channels	69
175	Figure 46	Retry handling during ServiceMode	70
176	Figure 47	Configuration sequence for Scan	71
177	Figure 48	Configuration sequence for pairing by UniqueID	72
178	Figure 49	Configuration sequence for pairing by Button	73
179	Figure 50	Message Sequence Chart for Roaming	74
180	Figure 51	PL W-Master state machine	75

181	Figure 52 Submachine of CyclicMode_2 or RoamingMode_3 of W-Master physical layer	76
182	Figure 53 Submachine of Handle_Sub_Cycle_4 of W-Master physical layer	77
183	Figure 54 Submachine for Mode_Scan_12	78
184	Figure 55 Submachine for Mode_Pairing_15	79
185	Figure 56 PL W-Device state machine	89
186	Figure 57 Structure and services of the data link layer (W-Master)	94
187	Figure 58 Track and W-Device-Mapper (TDMapper)	95
188	Figure 59 Structure and services of the data link layer (W-Device)	95
189	Figure 60 State machine of the W-Master Message handler	103
190	Figure 61 Sub-State machine Compile_PD-Out_7 of the message handler	104
191	Figure 62 Sub-State machine Compile Acyclic 11 of the message handler	105
192	Figure 63 State machine of the W-Device Message handler	110
193	Figure 64 W-Device Message handler sub state machine "CreateMessage_8" (DL-A)	111
194	Figure 65 State Machine of the W-Master DL-mode handler	125
195	Figure 66 State machine of the W-Device DL-mode handler	128
196	Figure 67 State machine for W-Master PDOOut handler	130
197	Figure 68 Sequence diagram for PDOOut distribution	134
198	Figure 69 State machine for W-Master PDIn handler	135
199	Figure 70 State machine of the W-Device Process Data Out handler	137
200	Figure 71 State machine of the W-Device Process Data In handler	138
201	Figure 72 State machine of the W-Master ISDU handler	140
202	Figure 73 State machine of the W-Device ISDU handler	142
203	Figure 74 State machine of the W-Master command handler	145
204	Figure 75 State machine of the W-Device command handler	147
205	Figure 76 State machine of the W-Master Event handler	149
206	Figure 77 Sequence diagram: Single event scheduling	150
207	Figure 78 State machine of the W-Device Event handler	151
208	Figure 79 Structure and services of the application layer (W-Master)	155
209	Figure 80 Structure and services of the application layer (W-Device)	155
210	Figure 81 ISDU state machine of the W-Master AL	164
211	Figure 82 ISDU state machine of the W-Device AL	165
212	Figure 83 Sequence diagram: ISDU Read Data	166
213	Figure 84 Sequence diagram: ISDU read Data in case of timeout	167
214	Figure 85 Sequence diagram: ISDU read Data in case of error	167
215	Figure 86 Sequence diagram for low energy W-Devices: ISDU Data	168
216	Figure 87 Event state machine of the W-Master AL	169
217	Figure 88 Event state machine of the W-Device AL	170
218	Figure 89 Sequence diagram: Single Event scheduling	171
219	Figure 90 PD state machine of the W-Device-AL	171
220	Figure 91 Sequence diagram for output Process Data	172
221	Figure 92 Sequence diagram for input Process Data	173
222	Figure 93 Structure and services of the W-Master system management	176
223	Figure 94 Sequence chart of the use case "port x setup"	177
224	Figure 95 State Machine of the W-Master Track handler	188
225	Figure 96 State Machine of the W-Port-handler	190
226	Figure 97 Submachine CheckCompatibility_3 of the W-Port-handler	193
227	Figure 98 Activities for state „CheckVxy_21“	194
228	Figure 99 Activities for state „CheckComp_22“	195
229	Figure 100 Activities (write parameter) in state "RestartDevice_23"	195
230	Figure 101 Submachine CheckSerNum_6 of the W-Port-handler	196
231	Figure 102 Activities (check SerialNumber) for state CheckSerNum_6	197
232	Figure 103 State Machine of the W-Master AHT-handler	197
233	Figure 104 Structure and services of the W-Device system management	199
234	Figure 105 Sequence chart of a Device pairing	200
235	Figure 106 State machine for W-Device System Management	206
236	Figure 107 State Machine of the W-Device AHT-handler	209
237	Figure 108 Sequence chart of a regular W-Device startup	210
238	Figure 109 Sequence chart of a Device startup in compatibility mode	211
239	Figure 110 Sequence chart of a Device startup when compatibility fails	212
240	Figure 111 Structure and services of a W-Device	213

241	Figure 112 Schematic representation of the use of (a) a W-Device and (b) a W-Bridge to connect a wired IO-link Device.	221
242		
243	Figure 113 Device LED blink timing	224
244	Figure 114 Device LED double flash timing.	225
245	Figure 115 Structure and services of a W-Master.....	226
246	Figure 116 Relationship of the common W-Master applications.....	227
247	Figure 117 Sequence diagram of configuration manager actions.....	229
248	Figure 118 State machine of the Track Configuration Manager	232
249	Figure 119 State machine of the W-Port Configuration Manager	233
250	Figure 120 Main state machine of the Data Storage mechanism	235
251	Figure 121 Submachine "UpDownload_2" of the Data Storage mechanism	236
252	Figure 122 Data Storage submachine "Upload_7"	237
253	Figure 123 Data Storage upload sequence diagram	238
254	Figure 124 Data Storage submachine "Download_10"	238
255	Figure 125 Data Storage download sequence diagram	239
256	Figure 126 State machine of the On-request Data Exchange	243
257	Figure 127 System overview of IO-Link diagnosis information propagation via Events	245
258	Figure 128 Process Data mapping from ports to the gateway data stream.....	246
259	Figure 129 Propagation of PD qualifier status between W-Master and W-Device	246
260	Figure 130 Example 1 of a PDCT display layout.....	247
261	Figure 131 Example 2 of a PDCT display layout.....	248
262	Figure 132 Generic relationship of W-Master and automation technology.....	249
263	Figure 133 Faulty device replacement.....	250
264	Figure 134 W-Message and Control Octets	251
265	Figure 135 Definition of DLink Control Octet	251
266	Figure 136 DLink Control Octets contains MasterCommand	252
267	Figure 137 Definition of ULink Control Octet	253
268	Figure 138 Placement of different W-Messages in a downlink	254
269	Figure 139 Structure of the EventQualifier	257
270	Figure 140 W-Frame encodings	259
271	Figure 141 Scan Request.....	261
272	Figure 142 Pairing Request.....	262
273	Figure 143 Pairing Negotiation type 1 => DLink-Message-Type = MSG_DLink_Pair_Neg_1.....	263
274	Figure 144 Pairing Negotiation type 2 => DLink-Message-Type = MSG_DLink_Pair_Neg_2.....	264
275	Figure 145 Regular SSlot Uplink Packet.....	264
276	Figure 146 Regular DSlot Uplink Packet	265
277	Figure 147 DSlot IMA-Uplink Packet	265
278	Figure 148 SSlot IMA-Uplink-Packet	266
279	Figure 149 Scan Response Packet	267
280	Figure 150 Pairing Response Packet	267
281	Figure 151 Pairing Negotiation Uplink Packet	268
282	Figure 152 Memory mapping of the direct parameter page 1 of a W-Master with a W-Device.	270
283	Figure 153 Memory mapping of the direct parameter page 1 of a W-Master with a W-Bridge connected to an IO-Link device.....	271
284		
285	Figure 154 MasterCycleTime and MinCycleTime	273
286	Figure 155 Possible values of MasterCycleTime and MinCycleTime	274
287	Figure 156 Index space for ISDU data objects	276
288	Figure 157 UniqueID octet mapping	280
289	Figure 158 Blacklisting of 2 WLAN channels in 2.4GHz ISM Band.....	289
290	Figure 159 Possible Frequencies for 5 Tracks.....	290
291	Figure 160 Frequency Table for 5 Tracks.....	290
292	Figure 161 Blacklisting of one WLAN channel in 2.4GHz ISM Band	291
293	Figure 162 Possible Frequencies for 1 Track.	291
294	Figure 163 Frequency Table for 1 Track.....	292
295	Figure 164 Usage of the configuration frequencies	292
296	Figure 165 Changing Hopping Table synchronization timeline	294
297	Figure 166 AHT WakeUp sequence	295
298	Figure 167 AHT Jump sequence	296
299	Figure 168 Merging IODD and W-IODD file for W-Bridges.....	299
300		

301	Table 1 Transceiver timings within W-Sub-cycle	41
302	Table 2 HT01 parameter	50
303	Table 3 Link Quality Indication	51
304	Table 4 PL Service assignments of W-Master	52
305	Table 5 PL_SetTrackConfig	52
306	Table 6 PL_SetMode	53
307	Table 7 Definition of parameters for Service PL_SetMode.....	54
308	Table 8 PL_Scan	54
309	Table 9 PL_ScanEnd	54
310	Table 10 PL_SetSlotConfig	55
311	Table 11 PL_Pairing	55
312	Table 12 PL_State	56
313	Table 13 PL_Transfer	57
314	Table 14 PL_QualityService	58
315	Table 15 PL_GetHopTable	58
316	Table 16 PL_SetHopTable	59
317	Table 17 PL_SetWakeUpTime	60
318	Table 18 PL_WakeUpTime.....	60
319	Table 19 PL_AHTStatus.....	61
320	Table 20 PL_CmdTrig	61
321	Table 21 PL Service assignments of W-Device	62
322	Table 22 PL_SetMode (W-Device)	63
323	Table 23 PL_SetMode coding of Parameters	64
324	Table 24 PL_Pairing (W-Device)	64
325	Table 25 PL_State (W-Device).....	65
326	Table 26 PL_Transfer (W-Device).....	65
327	Table 27 PL_QualityService (W-Device)	66
328	Table 28 PL_SetHopTable	67
329	Table 29 PL_SetWakeUpTime	67
330	Table 30 PL_CmdTrig	68
331	Table 31 State transition table of the Master physical layer.....	79
332	Table 32 State transition tables of the W-Device physical layer (normal device).....	90
333	Table 33 DL-A services within W-Master and W-Device	96
334	Table 34 MCmd	96
335	Table 35 ISDUmsg.....	97
336	Table 36 DownLinkAck.....	98
337	Table 37 UpLinkAck	99
338	Table 38 EventMsg	99
339	Table 39 PDOutMsg.....	100
340	Table 40 PDInMsg	101
341	Table 41 State transition tables of the W-Master Message handler	106
342	Table 42 Compilation of Downlink Control Octet	109
343	Table 43 State transition tables of the W-Device Message handler	112
344	Table 44 Compilation of Uplink Control Octet.....	114
345	Table 45 Service assignments within W-Master and W-Device.....	115
346	Table 46 DL_PDTrig	115
347	Table 47 DL_PDInputTransport.....	115
348	Table 48 DL_Control.....	116
349	Table 49 DL_PDOutputUpdate	116
350	Table 50 DL_PDOutputTransport	117
351	Table 51 DL_PDInputUpdate	117
352	Table 52 DL_Event	118
353	Table 53 DL_ISDUTransport	118
354	Table 54 DL_ISDUAbort.....	119
355	Table 55 DL_TDConfig (W-Master)	119
356	Table 56 DL_Read	120
357	Table 57 DL_Write	121
358	Table 58 DL_SetMode	122
359	Table 59 DL_Mode.....	122
360	Table 60 DL_MaxRetry	123

361	Table 61 DL_SetParam	123
362	Table 62 State transition tables of the W-Master DL-mode handler	126
363	Table 63 State transition tables of the W-Device DL-mode handler	128
364	Table 64 Transition tables for the State machine PDOOut handler.....	131
365	Table 65 State transition tables of the W-Master PDIn handler.....	135
366	Table 66 State transition tables of the PDOOut handler	137
367	Table 67 State transition tables of the W-Device PDIn handler.....	138
368	Table 68 State transition tables of the state machine ISDU handler (W-Master)	140
369	Table 69 State transition tables of the ISDU handler	143
370	Table 70 Definition of the nibble "I-Service"	144
371	Table 71 State transition tables of the W-Master command handler	145
372	Table 72 State transition tables of the CMD handler	147
373	Table 73 State transition tables of the W-Master Event handler DL	149
374	Table 74 State transition tables of the Event handler	151
375	Table 75 Flow Control for segmented data	153
376	Table 76 AL services within W-Master and W-Device.....	156
377	Table 77 AL_Read	156
378	Table 78 AL_Write	157
379	Table 79 AL_Abort	158
380	Table 80 AL_NewInput.....	158
381	Table 81 AL_GetInput	159
382	Table 82 AL_SetInput	159
383	Table 83 AL_PDTrig.....	160
384	Table 84 AL_GetOutput	160
385	Table 85 AL_NewOutput	161
386	Table 86 AL_SetOutput.....	161
387	Table 87 AL_Event	162
388	Table 88 AL_Control	163
389	Table 89 State transition tables of the ISDU state machine (W-Master AL)	164
390	Table 90 State transition tables of the ISDU W-Device AL	165
391	Table 91 State transition tables of the Event state machine (W-Master AL).....	169
392	Table 92 State transition tables of the event W-Device AL	170
393	Table 93 State transition tables of the PD device AL	172
394	Table 94 SM services within the W-Master	178
395	Table 95 SM_SetMasterConfig.....	178
396	Table 96 SM_SetTrackMode	179
397	Table 97 SM_GetTrackMode.....	180
398	Table 98 SM_TrackScanResult	181
399	Table 99 SM_TrackScanEnd	181
400	Table 100 SM_SetPortConfig	181
401	Table 101 Definition of the InspectionLevel (IL)	183
402	Table 102 Definitions of the Target Modes	183
403	Table 103 SM_GetPortConfig	183
404	Table 104 SM_PortPairing	185
405	Table 105 SM_PortMode.....	186
406	Table 106 SM_GetPortQuality.....	186
407	Table 107 SM_Operate	187
408	Table 108 State transition table of the Track handler	189
409	Table 109 State transition table of the W-Port-handler	191
410	Table 110 State transition table Submachine Check Compatibility 3 W-Port-handler	193
411	Table 111 State transition table Submachine CheckSerNum_6 of the W-Port-handler	196
412	Table 112 State transition table of the W-Master AHT-handler	198
413	Table 113 System management services within the W-Device	201
414	Table 114 SM_SetDeviceCom.....	201
415	Table 115 SM_GetDeviceCom	202
416	Table 116 SM_SetDeviceIdent	203
417	Table 117 SM_GetDeviceIdent.....	204
418	Table 118 Service SM_SetDeviceMode.....	204
419	Table 119 Service SM_DeviceMode	205
420	Table 120 State transition tables of the W-Device System Management	207

421	Table 121 State transition table of the W-Device AHT-handler	209
422	Table 122 Overview of the protocol constants for Devices	220
423	Table 123 Classification of W-Device diagnosis incidents	223
424	Table 124 Visual states of W-Device.....	224
425	Table 125 Pairing Button functions.....	225
426	Table 126 Internal variables and Events to control the common W-Master applications.....	228
427	Table 127 State transition tables of the Track Configuration Manager	232
428	Table 128 State transition tables of the W-Port Configuration Manager	234
429	Table 129 States and transitions of the Data Storage state machines	240
430	Table 130 State transition table of the ODE state machine.....	243
431	Table 131 Definition of DataLength (DLen)	252
432	Table 132 Definition of ChannelCode (ChC) for DLink.....	252
433	Table 133 Definition of ChannelCode (ChC) for ULink.....	253
434	Table 134 Data types for user data	257
435	Table 135 PDVALID PDINVALID.....	257
436	Table 136 Values of INSTANCE	257
437	Table 137 Values of SOURCE	258
438	Table 138 Values of TYPE	258
439	Table 139 Values of MODE	258
440	Table 140 Description of ConnectionParameter	259
441	Table 141 MasterID	259
442	Table 142 Track_N	260
443	Table 143 Normal Downlink ACK	260
444	Table 144 Downlink-MSG-Type content (Config Mode only).....	260
445	Table 145 Uplink Type	260
446	Table 146 Config Downlink ACK	260
447	Table 147 Downlink-MSG-Type coding	260
448	Table 148 Device_N.....	260
449	Table 149 Roaming Flag	260
450	Table 150 Track No	261
451	Table 151 Slot No	261
452	Table 152 Pairing Request: Unique ID	262
453	Table 153 Values for Frequency Table length	263
454	Table 154 Permitted Values for HOP_N	263
455	Table 155 HOP_N Bit coding	263
456	Table 156 Uplink IMA.....	265
457	Table 157 Uplink ACK.....	265
458	Table 158 Diagnosis encoding octet 3 (RSSI)	266
459	Table 159 Diagnosis encoding octet 4 (Link Quality)	266
460	Table 160 Uplink-MSG-Type (Config Mode only).....	266
461	Table 161 Slot-Type in config Uplink.....	266
462	Table 162 Uplink-MSG-Type Coding	266
463	Table 163 RevisionID.....	267
464	Table 164 Direct Parameter Page 1	272
465	Table 165 Types of MasterCommands.	273
466	Table 166 Coding of SystemCommand (ISDU)	275
467	Table 167 Direct parameter Page 2.....	275
468	Table 168 Index assignment of data objects (W-Device parameter)	277
469	Table 169 Wireless system index assignments	278
470	Table 170 Radio manufacturer identification information	278
471	Table 171 ISDU indexes for system management	278
472	Table 172 Minimum and maximum IMA time	279
473	Table 173 IMA time encoding.....	279
474	Table 174 Time value encoding table for the IMATime	279
475	Table 175 Value for the maximal number of retries	279
476	Table 176 TxPower parameter	280
477	Table 177 LinkQuality parameter	280
478	Table 178 W-Bridge information index assignments	281
479	Table 179 update hopping table index assignments	281
480	Table 180 EventCodes.....	282


481	Table 181 EventCodes used for IOLW	284
482	Table 182 Recommended power on time	286
483	Table 183 Frequency table for WLAN channels	288
484	Table 184 WLAN Channels 1 and 6 Blacklisting example	290
485	Table 185 WLAN Channel 1 Blacklisting example	291
486	Table 186 Timeouts for ServiceMode	293
487	Table 187 AHT UpdateType	293
488		

489 **Introduction**

490 **General**

491 The base technology of IO-Link™¹) is subject matter of the international standard IEC 61131-9 (see REF
 492 2). It specifies a single-drop digital communication interface technology for small sensors and actuators –
 493 named SDCI, which extends the traditional switching input and output interfaces as defined in IEC 61131-
 494 2 towards a point-to-point communication link using coded switching. This technology enables the cyclic
 495 exchange of digital input and output process data between a W-Master and its associated W-Devices
 496 (sensors, actuators, I/O terminals, etc.). The W-Master can be part of a fieldbus communication system or
 497 any stand-alone processing unit. The technology enables also the acyclic transfer of parameters to W-
 498 Devices and the propagation of diagnosis information from the W-Devices to the upper-level automation
 499 system (controller, host) via the W-Master/gateway.

500 Therefore, the market demand for the extension of this technology towards wireless transmission was
 501 raised. This document provides the necessary changes and extensions to the basic IO-Link interface and
 502 system standard for wireless communication including the radio characteristic, air interface, frequencies,
 503 message/frame types, and pairing mechanism as well as the necessary configuration management and the
 504 changes of state machines compared to IO-Link Interface and System Specification. Figure 1 shows its
 505 relationships to international fieldbus, wireless communications, EMC, and power source standards.
 506



507 **Figure 1 Relationships of this document to standards**

508 IEC 61131-9 is part of a series of standards on programmable controllers and the associated peripherals
 509 and should be read in conjunction with the other parts of the series.

510 Terms of general use are defined in IEC 61131-1 or in the IEC 60050 series. More specific terms are defined
 511 in each part.

512 Conformity with this document cannot be claimed unless the requirements of Annex I are met.

¹ IO-Link™ and IO-Link wireless™ are trade names of the "IO-Link Community". This information is given for the convenience of users of this specification and does not constitute an endorsement by the IO-Link Community of the trade name holder or any of its products. Compliance to this standard does not require use of the registered logos for IO-Link™. Use of the registered logos for IO-Link™ requires permission of the "IO-Link Community".

513 The main characteristics of the IO-Link Wireless technology are:

- 514 • The application interface for cyclic (Process Data) and acyclic data (On-request Data) is compatible
515 to IO-Link; from the user perspective, it is a transparent view on W-Devices.
- 516 • A W-Master can handle up to 5 transmission tracks in parallel, each track can handle a maximum
517 of 8 W-Devices, thus supporting up to 40 W-Devices per W-Master.
- 518 • Up to 3 W-Master can be placed in a cell, yielding a maximum of 120 W-Devices per W-Master cell.
- 519 • A scan service is available for discovery of yet unpaired W-Devices.
- 520 • A pairing service is provided to assign W-Devices to a W-Master, corresponding to a logical cable
521 connection.
- 522 • There are no limitations for typical relative movement speeds of W-Devices within a single W-Master
523 cell.
- 524 • Controlled roaming between multiple W-Master cells is supported by a dedicated handover
525 mechanism.
- 526 • A minimum transmission cycle time of 5 ms can support high-speed wireless applications with a
527 payload of up to 32 octets.
- 528 • IO-Link Wireless also supports mechanisms for low energy W-Devices.
- 529 • IO-Link wireless utilizes in this version radios for the 2.4 GHz ISM band, divided to frequency
530 channels with a distance of 1 MHz.
- 531 • Frequency Hopping changes the frequency channels for each transmission as a measure against
532 interference, yielding a PER of 10⁻⁹ which is similar to a wired connection.
- 533 • W-Coexistence with other wireless systems (e.g. WLAN) is achieved with a blacklisting mechanism.
- 534 • To comply with regulatory standards, transmission power is limited to ≤ 10 dBm (10 mW) EIRP, still
535 yielding a range of up to 20 m in case of a W-Master cell with one track. In case of more than one
536 track, 10 m can be achieved. These figures are dependent on the machine environment.
- 537 • Each transmission track in a W-Master can use its own narrow-band transceiver and dedicated
538 antenna or all of them can use a single shared transceiver and/or antenna.

539 **0.2 Patent declaration**

540 The IO-Link Community draws attention to the fact that it is claimed that compliance with this document
541 may involve the use of patents concerning the point-to-point wireless communication interface for small
542 sensors and actuators as follows, where the [xx] notation indicates the holder of the patent right

DE 19947344 A2	[ABB]	[1]	SENSOR MIT DRAHTLOSER DATENÜBERTRAGUNG MIT GERINGER LEISTUNGS-AUFNAHME
DE 10153462 A1	[ABB]	[2]	Verfahren zum Betrieb eines Systems mit mehreren Knoten und einer Basisstation gemäß TDMA
DE 10334873 A1	[ABB]	[3]	METHOD FOR OPERATING A SYSTEM COMPRISING A PLURALITY OF NODES AND A BASE STATION ACCORDING TO TDMA, AND ASSOCIATED SYSTEM
DE 102006032354 A1	[Festo]	[4]	Funk-Steuerungssystem

543 IO-Link Community takes no position concerning the evidence, validity and scope of these patent rights.
544 The holders of these patents rights have assured the IO-Link Community that they are willing to negotiate
545 licenses either free of charge or under reasonable and non-discriminatory terms and conditions with
546 applicants throughout the world. In this respect, the statements of the holders of these patent rights are
547 registered with the IO-Link Community.
548 Information may be obtained from:


[1 - 3x]	ABB Automation GmbH Heidelberg
4	Festo & Co KG, Esslingen

549 Attention is drawn to the possibility that some of the elements of this document may be the subject of patent
550 rights other than those identified above. For example, they may be subject of patents listed in [1 -3] or [4].
551 The IO-Link Community shall not be held responsible for identifying any or all such patent rights.
552 The IO-Link Community maintains on-line data bases of patents relevant to their standards. Users are
553 encouraged to consult the databases for the most up to date information concerning patents.

554

555 **1 Scope**

556 This document specifies IO-Link Wireless communication for factory automation. Different aspects of
 557 communication are realized by different communication layers based on the following layer model.



558 **Figure 2 Logical structure of W-Master and W-Device**

561 The “PL” (Air interface) for IO-Link wireless includes the Physical Layer as well as the wireless mechanisms
 562 (e.g. pairing, blacklisting, ...) with all aspects related to the radio:

- 563 • Antenna aspects
- 564 • Radio transceivers
- 565 • Radio frequencies
- 566 • Bidirectional data transmission via downlink and uplink (W-Sub-cycle)
- 567 • Media access and frequency hopping patterns
- 568 • W-Sub-cycle structures

569 Following elements specify the Data Link Layer (DL):

- 570 • Data scheduling (DL-A)
- 571 • Data handling (DL-B)

572 Following elements specify the Application Layer (AL):

- 573 • Data exchange

574 System Management (SM) realizes:

- 575 • Operating states
- 576 • Pairing functionality for W-Master and its W-Devices during commissioning and replacement
- 577 • Parameterization (download of W-Parameters)

579 In addition, this document provides the necessary changes and extensions to the IO-Link Interface and
 580 System Specification for the operation of wireless communication.





Figure 3 Detailed overview of the W-Master

581
582
583

584



585

586

587

Figure 4 Detailed overview of the W-Device

588 1.1 Structure of the document

589 The document is organized in an almost identical structure than the IO-Link Standard. If possible, the IO-
 590 Link Standard is referenced instead of repeating passages.
 591 Every time a system element is introduced that is later referenced to, it is desired to name the element
 592 uniquely to make it easier for the reader to identify the dependencies that exist throughout the document.
 593 Each clause contains a short entry description about the purpose of the clause.
 594 Clause 2 lists normative references.
 595 Clause 3 defines Terms and abbreviations for the context of this document.
 596 Clause 4 presents a top-level overview of the basic concepts of IO-Link wireless
 597 Clause 5 specifies the air interface (“PL”) of IO-Link wireless,
 598 Clause 6 specifies Data Link Layer (DL-A) services and the DLA Message handler.
 599 Clause 7 specifies Data Link Layer (DL-B) services, and the DL-B layer handlers.
 600 Clause 8 specifies the services and the protocol of the Application Layer (AL).
 601 Clause 9 describes the System Management responsibilities (SM).
 602 Clause 10 specifies features and implementation details for W-Devices. These include Process Data
 603 Exchange (PDE), Parameter Management (PM), Data Storage (DS), and Event Dispatcher (ED).

604 Technology specific applications are not part of this standard. They may be specified in profiles for particular
605 W-Device families.
606 Clause 11 specifies W-Master applications and features. These include Process Data Exchange (PDE), On-
607 request Data Exchange (ODE), Configuration Management (CM), Data Storage (DS) and Diagnosis Unit
608 (DU).
609 Several normative and informative annexes are included:
610 Annex A defines W-Message Codings.
611 Annex B defines W-Frame Codings, CRC calculation and Errors.
612 Annex C describes the W-Parameters and commands.
613 Annex D lists the system Event Codes (diagnosis information of W-Devices).
614 Annex E is linked to IO-Link Interface and System Specification REF 1 (description of the basic and
615 composite data types).
616 Annex F contains design rules and constraints concerning low energy W-Devices.
617 Annex G describes the calculation of the frequency hopping tables.
618 Annex H informs about certification.
619 Annex I informs about regulatory compliance.
620 Annex J defines rules merging IODD and W-IODD file for W-Bridges.

621 **2 Normative references**

622 Identical to IO-Link Interface and System Specification clause 2 REF 1
623

624 **3 Terms, definitions, symbols, abbreviated terms and conventions**

625 For the purpose of this document, the terms and definitions given in IEC 61131-1 and IEC 61131-2, as well
626 as the following ones apply.

627 **3.1 Common terms and definitions**

628 **3.1.1 Acknowledge (ACK)**

629 Response information indicating the acceptance of a message

630 **3.1.2 Adaptive Hopping Table (AHT)**

631 This mechanism enables a change of the hopping table of a track while the communication is already
632 running (improvement of connection), see clause 18.4

633 **3.1.3 Air interface**

634 Radio-based communication links between the W-Master and the W-Devices

635 **3.1.4 Application Layer (AL)**

636 Part of the protocol responsible for the transmission of Process Data objects and On-request Data objects

637 **3.1.5 Blacklist**

638 List of frequency channels not to be used for IO-Link wireless communication within a W-Master

639 **3.1.6 Broadcast (BC)**

640 A mechanism to send a Master command to all W-Devices in a track. A Broadcast is restricted to specific
641 Master commands according to Table 166.

642 **3.1.7 Cell**

643 Logical grouping of 1 or up to 3 W-Masters with a dedicated coverage area, often associated to a "machine".

644 **3.1.8 Checksum**

645 Data integrity measures for each pre-downlink, downlink or uplink in the physical layer

646 **3.1.9 ConfigSyncword**

647 Syncword which shall be used for the configuration channels

648 **3.1.10 Configuration frequency channels**

649 Two Frequency Channels are reserved for configuration purposes, see clause 5.4.4.

- 650 **3.1.11 Configuration W-Frame**
- 651 Downlink message to one particular W-Device with configuration data, followed by the corresponding uplink
652 message of that W-Device
- 653 **3.1.12 ConnectionParameter**
- 654 A set of parameters containing the data which are necessary to establish wireless communication. The
655 parameters are transmitted via the pairing mechanism (see Table 140). These parameters are only
656 changeable via a new pairing or re-pairing.
- 657 **3.1.13 Control interval**
- 658 Time required to change the radio to receive mode, to transmit mode or to change frequencies
- 659 **3.1.14 Control octet (CO)**
- 660 Header, indicating the structure and purpose of a W-Message (2 octets in downlink 1 octet in uplink), see
661 clause 12.3. and clause 12.4
- 662 **3.1.15 Communication channel**
- 663 Logical connection between W-Master and W-Device.
664 Note to entry: Four communication channels are defined: master command channel, process data channel, ISDU
665 channel (for parameters), and diagnosis channel (for events).
- 666 **3.1.16 Communication error**
- 667 Unexpected disturbance of the transmission
- 668 **3.1.17 Cyclic mode**
- 669 Operation mode to achieve the needed short latency time.
670 Note to entry: Not occupied retries by process data are used for acyclic exchange of on-request Data. The configuration
671 channels are not used.
- 672 **3.1.18 DataSyncword**
- 673 Syncword which shall be used for the data channels.
- 674 **3.1.19 Disconnected**
- 675 Disconnected describes the loss of communication between a W-Device and its W-Master.
- 676 **3.1.20 Double Slot (DSlot)**
- 677 Uplink type of a W-Device which combines two SSlots (15 octet payload) as uplink, see 4.5.3.
- 678 **3.1.21 Downlink (DLink)**
- 679 Multicast transmission from a W-Master to its associated W-Devices.
680 During configuration, a point to point transmission is used between W-Master and a particular W-Device
- 681 **3.1.22 Event**
- 682 Instance of a change of conditions in a W-Device
683 Uppercase "Event" is used for IOLW Event mechanism, while lowercase "event" is used in a generic
684 manner.
- 685 **3.1.23 Frequency channel**
- 686 One out of 80 channels in the 2.4 GHz ISM band with frequency spaces of 1 MHz. For details see 5.4.1 and
687 5.4.4
- 688 **3.1.24 Frequency division multiple access FDMA**
- 689 Access method where users are allocated to individual frequency channels (frequency bands)
- 690 **3.1.25 FullDownLink**
- 691 Data structure of the regular downlink. Definitions see 5.2.8
- 692 **3.1.26 Gaussian frequency shift keying (GFSK)**
- 693 Binary frequency shift modulation with gaussian filter limiting its spectral width
- 694 **3.1.27 Guard interval**
- 695 Time interval between successive uplinks to avoid collisions on air

- 696 **3.1.28 Header**
- 697 Message part relevant for wireless communication only, consisting of Preamble, Syncword, MasterID, Track
698 Number, and Acknowledge.
- 699 **3.1.29 MasterID**
- 700 Identification number of a particular W-Master
- 701 **3.1.30 IMA message "I am alive"**
- 702 Message from the W-Device, which informs the W-Master, that it is still functional.
- 703 **3.1.31 IMA time**
- 704 User configured watchdog time in which the W-Device shall send a IMA message, if no other messages
705 had been sent.
- 706 **3.1.32 InspectionLevel (IL)**
- 707 Degree of verification for the W-Device identity during start-up
- 708 **3.1.33 ISDU**
- 709 Indexed service data unit used for acyclic transmission of parameters which may be segmented in multiple
710 W-Frames
- 711 **3.1.34 ISM band**
- 712 Radio frequencies reserved for industrial, scientific, and medical use
- 713 **3.1.35 Negative Acknowledge (NACK)**
- 714 Indicating a missing response message, e.g. wrong CRC or no received DLink or ULink
- 715 **3.1.36 Negotiation**
- 716 Step within the pairing procedure for configuration of the ConnectionParameter
- 717 **3.1.37 Packet Error Probability (PEP)**
- 718 The Packet Error Probability is the mean error probability within the last 3000 transmissions. Errors are not
719 acknowledged downlink- or uplink transmissions.
- 720 **3.1.38 Pairing**
- 721 Pairing is the equivalent procedure to plugging in a cable connection in a wired system between a master
722 and a device.
- 723 **3.1.39 Payload**
- 724 Message parts carrying cyclic Process Data and acyclic On-request Data such as commands, Events and
725 ISDUs (see W-Message Figure 133)
- 726 **3.1.40 Port and Device Configuration Tool (PDCT)**
- 727 Engineering support for a W-Master and W-Devices is usually provided by a "Port and Device Configuration
728 Tool".
- 729 **3.1.41 PortCycle**
- 730 The IO update is performed in a cyclic manner, which is determined by the W-Port related cycle time, within
731 which the IO data of the W-Device are read or written
- 732 **3.1.42 Preamble**
- 733 Fixed bit pattern used for bit synchronization and calibration of automatic gain control of a radio receiver
- 734 **3.1.43 PreDownLink**
- 735 Part of a downlink including preamble up to CRC16. The 2 octet payload is used for low energy W-Devices
736 only. Definitions see clause 5.2.8
- 737 **3.1.44 Residual Failure Probability (RFP)**
- 738 The Residual Failure Probability is the probability that the maximum latency is violated. By the calculation
739 of the RFP the MaxRetry will be taken in account.

- 740 **3.1.45 Roaming**
- 741 Feature that allows mobility to a predefined W-Device between multiple predefined W-Masters by "Handover
742 disconnect" and "Handover connect" procedures.
- 743 **3.1.46 Security**
- 744 All organizational measures and technical mechanisms to achieve authentication, confidentiality, integrity
745 and availability.
- 746 Note: In the context of IOLW communication, encryption is not in the scope of the security goals.
- 747 **3.1.47 SerialNumber**
- 748 Unique vendor specific code for each individual W-Device.
- 749 **3.1.48 Service Mode**
- 750 Operational mode in which a W-Master track also utilizes the configuration channels. This mode is required
751 for discovery, pairing and roaming procedures. A W-Master shall only operate with one of its tracks in
752 Service Mode at the same time.
- 753 **3.1.49 Single Slot (SSlot)**
- 754 Uplink type of a W-Device which uses one SSlot (2 octet payload) as uplink, see 4.5.3.
- 755 **3.1.50 Synchronization**
- 756 Is a process of matching timing and the frequency tables between a W-Master and corresponding W-
757 Devices.
- 758 **3.1.51 Track and W-Device-Mapper (TDMapper)**
- 759 The TDMapper is located in DL and assigns a W-Port to a specific Track number (Track_N) and Slot number
760 (Slot_N).
- 761 **3.1.52 UniqueID**
- 762 Unique 9 octets identifier for each W-Device, consisting of the 16 bit manufacturer distinguishing VendorID,
763 24 bit DeviceID and a 32 bit W-Device distinguishing identifier, which is related to the SerialNumber. See
764 clause 14.3.9
- 765 **3.1.53 Unpairing**
- 766 Unpairing is the user action via PDCT, to delete the permanently stored ConnectionParameter on the W-
767 Device side and subsequently disconnects the W-Device. On the W-Master side the Unpairing command
768 clears the current W-Port configuration which disables the communication with the unpaired W-Device
- 769 **3.1.54 Uplink (ULink)**
- 770 Single cast W-message from a W-Device to its W-Master consisting of Header, Payload, and Cyclic
771 Redundancy Check (CRC).
- 772 **3.1.55 W-Bridge**
- 773 W-Device that connects a wired IO-Link device via IO-Link Wireless to a W-Master.
- 774 **3.1.56 W-Coexistence**
- 775 Wireless communication solutions within an industrial area can fulfill their communication requirements
776 application, using the shared ISM frequency band.
- 777 **3.1.57 W-Cycle**
- 778 Combined utilization of TDMA and FDMA with several W-Sub-cycles to achieve a reliable wireless
779 transmission.
- 780 **3.1.58 W-Device**
- 781 Single peer to a W-Master such as a IO-Link wireless sensor or actuator
- 782 **3.1.59 W-Frame**
- 783 Sequence of messages comprising a W-Master message (DLink) and all subsequent W-Device messages
784 (ULinks). The sequence is transmitted in a W-Sub-cycle consisting of control intervals, downlink, and uplink
785 slots (see Figure 21).

786 **3.1.60 W-Master**

787 Peer connected through W-Ports via radio to one up to n W-Devices and which provides an interface to the
788 gateway to the upper level communication systems or PLCs

789 **3.1.61 W-Message**

790 Content of payload comprising control octet and (segmented) data exchanged between W-Master and W-
791 Device (see Figure 21)

792 **3.1.62 W-Parameter**

793 This is the generic term that describes all the parameters located in the "wireless specific index" range, see
794 clause 14.3.

795 **3.1.63 W-Port**

796 The logical wireless Port number to address a paired W-Device.

797 **3.1.64 W-Sub-cycle**

798 Time duration to transmit one W-Frame (see Figure 21).

799 **3.1.65 Wired IO-Link Device**

800 Device according to IO-Link Interface and System Specification

801 **3.1.66 WLAN channels**

802 Occupied frequency blocks used by WLAN
803

804 **3.2 Abbreviated terms**

805 IOL = wired IO-Link

806 IOLW = IO-Link wireless

807 **3.3 Conventions**

808 **3.3.1 General**

809 The service model, service primitives, and the diagrams shown in this standard are entirely abstract
810 descriptions. The implementation of the services may reflect individual issues and can be different.

811 **3.3.2 Service primitives**

812 Service primitives are used to represent service provider/consumer interactions (ISO/IEC 10731). Each
813 service consists of up to four service primitives:

- 814 • request primitive (.req),
- 815 • indication primitive (.ind),
- 816 • response primitive (.rsp), and
- 817 • confirmation primitive (.cnf).

818 An indication can occur with or without the corresponding response, a request can occur with or without the
819 corresponding confirmation.

821 Figure 5 shows a generalized example of a confirmed service. In this case "Initiator" and "Responder"
822 correspond to either Master or Device and not to the layer within one of each.




Figure 5 Generalized example of a confirmed service

823
824

825 **3.3.3 Service parameters**

826 Service primitives convey parameters which indicate the information available in the provider/ consumer
 827 interaction. In any particular interface, not each and every parameter needs to be explicitly stated.
 828 The service specification in this standard uses a tabular format to describe the component parameters of
 829 the service primitives. The parameters which apply to each group of service primitives are set out in tables.
 830 Each table consists of up to five columns:

- 831 1) parameter name;
- 832 2) request primitive (.req);
- 833 3) indication primitive (.ind);
- 834 4) response primitive (.rsp); and
- 835 5) confirmation primitive (.cnf).

836 One parameter (or component of it) is listed in each row of each table. Under the appropriate service
 837 primitive columns, a code is used to specify the type of usage of the parameter on the primitive specified
 838 in the column.

- 839 M Parameter is mandatory for the primitive.
- 840 U Parameter is a user option and can or cannot be provided depending on dynamic usage of the
 841 service user. When not provided a default value for the parameter is assumed.
- 842 C Parameter is conditional upon other parameters or upon the environment of the service user.
- 843 – Parameter is never present.
- 844 S Parameter is a selected item.

845 Some entries are further qualified by items in brackets. These may be:

- 846 a) a parameter-specific constraint "(=)" indicates that the parameter is semantically equivalent to the
 847 parameter in the service primitive to its immediate left in the table;
- 848 b) an indication that some note applies to the entry "(n)" indicates that the following note "n" contains
 849 additional information related to the parameter and its use.

850 **3.3.4 Service procedures**

851 The procedures are defined in terms of:

- 852 • the interactions between application entities through the exchange of protocol data units; and
- 853 • the interactions between a communication layer service provider and a communication layer service
 854 consumer in the same system through the invocation of service primitives.

855 These procedures are applicable to instances of communication between systems which support time-
 856 constrained communications services within the communication layers.

857 **3.3.5 Service attributes**


858 The nature of the different (W-Master and W-Device) services is characterized by attributes. All services
 859 are defined from the view of the affected layer towards the layer above.

- 860 I Initiator of a service (.ind) (towards the layer above)
- 861 R Receiver (responder) of a service (.req) (from the layer above)

863 **Figure 6 Example of initiator / receiver of services (W-Device)**

864 Figure 6 shows the example of initiator / receiver of services (W-Device)

865



866 **Figure 6 Example of initiator / receiver of services (W-Device)**


867

868 **3.3.6 Figures**

869 For figures that show the structure and services of protocol layers, the following conventions are used:

- 870 • an arrow with just a service name represents
 - 871 • a request and the corresponding confirmation (the request being in the direction of the arrow);
 - 872 • an indication and the corresponding response (the indication being in the direction of the arrow)
- 873
- 874
- 875 • a request without confirmation as well as an indication without response are labelled as such (i.e. service.req, service.ind).
- 876
- 877


878 Figure 7 shows the example of service between W-Master and W-Device in generalized and detailed view



879 **Figure 7 Example of service between W-Master and W-Device in generalized and detailed view**

880 Figure 8 shows the example of confirmed / non-confirmed services (W-Device)

879
880
881
882
883



884 **Figure 8 Example of confirmed / non-confirmed services (W-Device)**

884
885

886 **3.3.7 Transmission octet order**

887 See clause 5.2.1

888 **3.3.8 Behavioral descriptions**

889 For the behavioral descriptions, the notations of UML 2 (ISO/IEC 19505) are used (e.g. state, sequence,
890 activity, timing diagrams, guard conditions). The layout of the associated state-transition tables is following
891 IEC/TR 62390.

892 Due to design tool restrictions the following exceptions apply. For state diagrams, a service parameter (in
893 capital letters) is attached to the service name via an underscore character, such as for example in
894 DL_SetMode_INACTIVE. For sequence diagrams, the service primitive is attached via an underscore
895 character instead of a dot, and the service parameter is added in parenthesis, such as for example in
896 DL_Event_ind (OPERATE). Timing constraints are labelled "tm (time in ms)".
897 Asynchronously received service calls are not modelled in detail within state diagrams.
898 To find the balance between clearness and degree of detailing not all negative responses or confirmations
899 are modelled explicitly in the state machines.

4 Overview of IO-Link wireless

4.1 Purpose and topology

IO-Link wireless is a communication technology intended to replace the cable(s) for remote sensor/actuator control in production automation. The key features of IO-Link wireless technology are real-time capabilities, very low latency and robustness. Applications within factory automation comprise moving parts such as rotating bottle filling, robot arms and linear moving machinery. These applications are difficult to realize with wired sensor/actuator equipment or suffer from frequently broken wires. These kinds of applications are targets of IO-Link wireless.

IO-Link wireless equipment operates in the unlicensed 2.4 GHz ISM band and using frequency hopping to reduce the impact of interference. IO-Link wireless realizes a communication between the air interface of a wireless Master (W-Master) and the air interface of one or more wireless Devices (W-Devices).




Figure 9 IO-Link and IO-Link wireless topology

From a PLC or Controller users point of view, Master and W-Master provide the same functionality in respect to Process Data (PD) and On-request Data (OD). The main differences between the two topologies is during commissioning, the discovery of available W-Devices ("scan"), the connection configuration ("pairing") and the parameterization of the air interface ("W-Parameter").

4.2 Positioning in the automation hierarchy

Figure 10 shows the architecture of an automation topology with an IO-Link wireless system comparable to the wired version.




Figure 10 IO-Link wireless system


In all cases a PLC, a PC-based controller, or an embedded system can exchange Process Data (PD) and/or On-request Data (OD) with wire or radio connected devices via Master or W-Master, respectively. Additional to the IO-Link Interface and System Specification (REF 1) clause 11.7.7 the “Port and Device Configuration Tool” (PDCT) for IO-Link can be extended by features like:

- Device discovery and pairing support for unpaired devices.
- Optimizing connection quality of W-Masters and W-Devices.
- W-Coexistence management for a conflict-free layout of the radio transmissions such as overlapping frequencies of non-IO-Link wireless systems.
- Configuration of the W-Parameters as described in the provided IODDs.

IO-Link wireless uses the Data Storage mechanism of IO-Link Interface and System Specification REF 1 to support faulty device replacement. To re-establish a wireless connection after a W-Device replacement, pairing buttons or software tools can be used. With pairing buttons activated on both W-Device and W-Master a W-Device can be exchanged without the need of any software tools. After replacement, the parameters are downloaded automatically from the Data Storage, if enabled.

939 **4.2.1 Relationship to IO-Link**

940 In relationship to IO-Link, the transfer of the IO-Link objects via the Downlink and Uplink mechanism is
941 outlined in Figure 11.



942 **Figure 11 Object transfer at the application layer level (AL)**
943
944

945 **4.2.2 Role of a W-Master**

946 A W-Master manages up to 40 W-Port instances. The possible max. number of W-Ports depends on the
947 available tracks and slots and how they are utilized.

948 A W-Master can comprise up to five (small band) transceivers with their own antenna and dedicated
949 frequency channels, called tracks. Each track can serve up to 8 W-Devices and send and receive
950 alternately. All tracks of a W-Master send at the same time on different frequencies according to the
951 computed frequency hopping tables, providing an optimal medium utilization.

952 The user may manually operate the W-Master for discovery and pairing of devices.

953 During commissioning or roaming Service Mode is used by the W-Master to establish communication with
954 W-Devices (pairing), includes checking of the "identity" of the W-Device, i.e. its VendorID, DeviceID, and
955 communication properties. If there is a mismatch between W-Device parameters and the stored parameter
956 set within the W-Master, the parameters in the W-Device are overwritten (see 11.3) or the stored parameters
957 within the W-Master are updated depending on the configuration.

958 After power on with paired W-Devices, the W-Master establishes communication, including all checks
959 described above.

960 The W-Master is responsible for the assembly and disassembly of all data from or to the W-Devices (see
961 Clause 11).

962 **4.2.3 Role of a W-Device**

963 A W-Device consists of a single transceiver, the IOLW device stack and the technology specific application,
964 i.e. the transducer with its technology parameters. The common W-Device applications are the same as in
965 IO-Link and comprise of configuration parameters, diagnosis information and process data.
966

967 **4.2.4 Role of a W-Bridge**

968 A W-Bridge is a W-Device to connect a single wired IO-Link Device. The application part of the W-Bridge
969 basically contains a wired IO-Link Master.

970 For compatibility reasons towards the wired IO-Link Device in the System Configuration Tooling, a straight
971 forward parameter mapping of the wired IO-Link device via the W-Bridge is desired. To achieve this, the
972 IODD of the wired IO-Link Device and the required extension for the W-Bridge are merged together to
973 constitute the W-IODD of the novel entity formed by the W-Bridge and the wired IO-Link Device.
974

975 **4.2.5 System Configuration Tool**


976 Engineering support for a W-Master is usually provided by a Port and Device Configuration Tool (PDCT).
977 The PDCT configures both W-Port and W-Device properties. It combines both an interpreter of the IO Device
978 Description (IODD) and a configurator (see 11.7.2). The parameters provide all the necessary properties to
979 establish communication and the desired function of a sensor or actuator.

980 **4.2.6 Mapping to fieldbuses**

981 See clause 4.7 in REF 1 and clause 11.8.1.

982 **4.3 Cell concept**

983 Due to the limited transmission power (see Air Interface 4.5), the possible range of a W-Master is limited
984 to max. 20 m in case of only one track as shown in Figure 12. This value is derating to ≤ 10 m if more than
985 one track is active.
986



987 **Figure 12 Radius of a cell with a 1 track W-Master**

988
989 A single W-Master can consist of one up to five tracks. Up to 3 W-Masters are allowed within one cell to a
990 certain extent. If there are more than one W-Master installed in a cell, the MasterID's shall be subsequently.
991 To prevent frequency access conflicts between the tracks, IO-Link wireless provides mechanisms to create

992 disjoint frequency tables by W-Masters. Every W-Master has its MasterID, a frequency hopping table and
 993 a blacklist.
 994 One W-Master and a group of associated W-Devices form a W-Master cell is shown in Figure 13. The W-
 995 Master A is connected to W-Devices A1 to Ai. The W-Master B is connected to W-Devices B1 to Bj, whereas
 996 both systems are in an overlapping RF coverage area.
 997




Figure 13 W-Master cell consisting of 2 W-Master

998
 999
 1000 Figure 14 shows the IO-Link wireless concept with partly overlapping W-Master cells. In one area, there
 1001 should not coexist more than three W-Master in order to avoid interference. W-Master cells with a distance
 1002 of more than 40 m can use the same MasterID again. W-Master cells with a distance less than 40 m require
 1003 distinct MasterIDs. The MasterID is used to calculate individual frequency hopping tables.
 1004




Figure 14 Cell concept

4.4 Wireless Mechanisms

The following mechanisms are used to setup and operate the wireless connections.

4.4.1 Scan (Device Discovery)

1010 After power-on, every unpaired W-Device is waiting for connection establishment from a W-Master on the
 1011 configuration frequency channels. Upon user request for W-Device discovery, the W-Master sends scan
 1012 request messages on the configuration frequency channels. Any unpaired W-Device receiving such a scan
 1013 request message is responding with a scan response message, where the W-Device returns its unique
 1014 identifier (UniqueID) for authentication purposes before pairing. With the help of this mechanism all
 1015 unpaired W-Devices in the proximity of the W-Master can be discovered. Subsequently, the application can
 1016 decide to pair the W-Devices.

1017 Several W-Devices may simultaneously respond within a single uplink. In order to minimize collisions, they
1018 are using randomly determined time slot positions within that uplink frequency. In this manner, the W-Master
1019 collects all non-paired W-Devices over time within several W-Sub-cycles.

1020 **4.4.2 Pairing**

1021 Pairing is the equivalent procedure to plug in the cable connection in a wired system .
1022

1023 **4.4.2.1 Pairing by UniqueID**

1024 This mechanism is provided for pairing of a W-Device with a pre-configured W-Master and reflects the
1025 normal commissioning mechanism. The UniqueID of the W-Device is used for automatic identification of
1026 the W-Device within the pairing process. An Engineering Tool or HMI such as an PDCT is required for the
1027 pre-configuration of the W-Master. See clause 10.7.3.

1028 **4.4.2.2 Pairing by Button**

1029 This mechanism is for manual pairing without detailed knowledge about the W-Device. No Engineering Tool
1030 is required for this kind of pairing. The pairing must be acknowledged on both entities by manual intervention
1031 (i.e. pressing a button or equivalent mechanism). In case of a faulty W-Device, which must be replaced with
1032 a new, but identical W-Device, IO-Link wireless provides this simplified procedure for the pairing of both
1033 partners without using an Engineering Tool or PDCT.

1034 **4.4.2.3 Re-Pairing by Button**

1035 A W-Device previously paired to former W-Master can be re-paired to a new W-Master. If such a W-Device
1036 still has the ConnectionParameters of its "old" W-Master, it stays in state Configured. With a button press,
1037 the W-Device can be switched by the operator temporarily to state Re_Pairing and listens on the
1038 configuration channels for a pairing request message from the new W-Master. The pairing must be started
1039 previously on the W-Master by manual intervention (i.e. by UniqueID or pressing a button).

1040 **4.4.3 Unpairing**

1041 A W-Device can be removed from a communication relationship with a W-Master. When the operator wants
1042 to unpair one of the W-Devices, the W-Master is triggered by the operator (i.e. via HMI) and starts an
1043 unpairing procedure on the dedicated W-Device. This sends an unpairing request to the W-Device, which
1044 sends an acknowledgement back to the W-Master. The ConnectionParameters on the W-Device and the
1045 related W-Port configuration within the W-Master are deleted.

1046 **4.4.4 Roaming**

1047 Roaming is a feature that allows mobility to a predefined W-Device between multiple predefined W-Master
1048 cells. A W-Master track configured to Roaming Mode is sending scan request messages on the
1049 configuration channels to detect roaming W-Devices in their range. Disconnected roaming W-Devices
1050 listening for a W-Master shall respond with a scan response message to indicate their presence to this W-
1051 Master. The application on the W-Masters may then decide to connect the roaming W-Device by initiating
1052 a pairing and configuration sequence.

1053 Handover disconnect is initiated by the W-Master when the application (e.g. the PLC) wants to release the
1054 W-Device, for example when the application has finished processing with the roaming W-Device in its
1055 current state (e.g. in a tool changer or conveyor belt application). Another reason for a disconnect procedure
1056 could be that the parameter LinkQuality at the W-Port has degraded to an absolute minimum, indicating
1057 that the W-Device leaves the range of the W-Master. Reconnection in the case of link quality degradation
1058 to the same W-Master should only be done if the link quality has improved substantially.

1059 For any handover procedure with another W-Master, the scan message followed by a pairing and a W-
1060 Device startup sequence is utilized. It must be noted that the handover procedure requests a certain amount
1061 of time where no process data can be exchanged.

1062 An unexpected IMA-Failure detected by a W-Master from a roaming W-Device must lead to an autonomous
1063 handover disconnect of this W-Device for the associated W-Port within the W-Master.

1064




Figure 15 Roaming between W-Master cells

1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075

“Roaming” is configurable on the W-Master. On each W-Master, not more than one track shall be configured for Roaming Mode, as indicated in Figure 15 for W-Master 1 and W-Master 3. The tracks in Roaming Mode utilize a dedicated frequency hopping table which includes the configuration channels. For the “handover disconnect” procedure, the entire fault indications (e.g. IMA timeout) to the system/user are suppressed, since it is related to an intended action. Accordingly, all pending diagnosis messages of the related W-Port and W-Device are deleted once the "handover disconnect" procedure is completed. A roaming W-Device does not permanently store its pairing information and discards it when disconnected. The computation of the frequency hopping tables for roaming is described in clause 18.2.

4.4.5 Transmission Error Handling

1076
1077
1078
1079
1080
1081
1082
1083

Transmitted packets in both uplink and downlink direction are subject to error detection via CRC and must be acknowledged by the receiving side. W-Devices acknowledge correct reception of their Downlink packets within the respective subsequent Uplink packets. Within the next downlink, the W-Master acknowledges correct reception of the Uplink packet to each W-Device. In case of missing acknowledgments, the W-Master uses this information to initiate a retransmission within the same W-Cycle. When all retransmissions fail within a W-Cycle, a communication error is indicated towards system management.

4.4.6 “I am alive” supervision (IMA)

1084
1085
1086
1087
1088

The activity of a W-Device is monitored via an “I am alive” (IMA) timer in the W-Master. When a W-Device has no data to transmit for a time period longer than its configured IMATime, an IMA message must be sent by the W-Device before the IMA-timer expires. When the supervision IMA-timer of the W-Master expires, i.e. because the W-Device is down, a communication error must be indicated via system management.

1089 **4.4.7 Link Quality supervision**

1090 Link Quality Indication is a service for evaluation of the functionality and reliability of the IO-Link Wireless
 1091 system in its application environment of the wireless connection. The parameter LinkQuality of a
 1092 communication link between W-Master and a W-Device is continuously monitored and can be accessed on
 1093 W-Master by the gateway application via service GetPortQuality. The computation of the LinkQuality
 1094 Indicator is described in clause 5.4.6.

1095 **4.5 Concept of Air Interface**

1096 IO-Link wireless uses the license-free 2.4 GHz ISM band (industrial, scientific, and medical) from 2.4 to
 1097 2.4835 GHz compliant to REF 5 Bluetooth SIG - Regulatory Committee, "Bluetooth low energy Regulatory
 1098 Aspects", V10r00, 26 April 2011, which also forms the basis for the well-known Bluetooth®-technology. It
 1099 is therefore possible to cost-effectively use existing integrated radio circuits available on the market to build
 1100 IO-Link wireless systems. But it must be noted that there is no system compatibility between Bluetooth®
 1101 and IO-Link wireless. For more details see clause 5.4

1102 **4.5.1 Frequency Division Multiple Access (FDMA)**

1103 Using different carrier frequencies in IO-Link wireless follows in principle the Frequency Division Multiple
 1104 Access (FDMA) technology. IO-Link wireless periodically changes the transmission frequencies ("frequency
 1105 hopping") to improve robustness against burst interferences. W-Coexistence with other wireless systems
 1106 and other IO-Link wireless cells is possible through omitting those frequencies within the table of unusable
 1107 transmission frequencies ("Blacklisting").

1108 **4.5.1.1 Frequency Hopping Tables**

1109 To compute the frequency hopping tables for a W-Master and its W-Devices, IO-Link wireless defines
 1110 dedicated channel hopping sequence algorithms that depend on the individual MasterID to achieve W-
 1111 Coexistence within neighboring IO-Link wireless systems. For W-Coexistence with other wireless systems,
 1112 a blacklist can be utilized to avoid certain frequency channels in the computed hopping table. The hopping
 1113 sequence is transferred to the W-Device during pairing. For more details, see clause 18.2.

1114 **4.5.1.2 Blacklist**

1115 To suspend frequency ranges, they can be defined in the blacklist. The blacklist is configurable via
 1116 SetMasterConfig. For more details, see clause 18.1.

1117 **4.5.1.3 Configuration channels**

1118 Configuration of W-Master and W-Devices is required prior to cyclic data exchange. For this purpose, the
 1119 frequency channels "1" (2 401 MHz) and "80" (2 480 MHz) are exclusively used in an alternating manner
 1120 for ConnectionParameter exchange and initial scan and pairing of W-Master with its W-Devices. For a
 1121 detailed description of usage of the configuration channels see 18.3

1122 **4.5.1.4 Data channels**

1123 The frequency channels 3 (2403 MHz) to 78 (2478 MHz) can be used for cyclic data exchange. This number
 1124 of frequency channels allows the configuration of W-Master sets disjoint from their cell neighbors for W-
 1125 Coexistence. The set of frequency channels a W-Master uses is configured in the frequency hopping table
 1126 (see 18.2).

1127 **4.5.2 Time Division Multiple Access (TDMA)**

1128 IO-Link wireless uses Time Division Multiple Access (TDMA) principles. A communication exchange
 1129 between a W-Master and its W-Devices is splitted into a "downlink" phase that is immediately followed by
 1130 an "uplink" phase for a dedicated track and frequency channel. The transmitters on the W-Master and W-
 1131 Devices are operating in half-duplex mode, switching between TX and RX mode according to their time
 1132 slots.

1133 TDMA requires precise timings on both, sender and receiver. At the beginning of a TDMA cycle, the
 1134 frequency channel is selected from the hopping table. The W-Devices respond at their subsequent
 1135 respective time slots using the same frequency channel.

1136 **4.5.2.1 Downlink**

1137 The downlink communication from W-Master to its W-Devices can contain W-Messages for several W-
 1138 Devices as shown in Figure 16. It is therefore a multicast communication. Immediately after sending the
 1139 Downlink, the W-Master switches its radios from TX to RX mode, awaiting the subsequent uplink
 1140 transmissions from the W-Devices of that track.

1141




Figure 16 Downlink

1142

1143

4.5.2.2 Uplink

Figure 17 demonstrates the timely staggered delivery of single cast W-Messages of W-Devices to their W-Master.

1145

1146

1147




Figure 17 Uplink

1148

1149

4.5.2.3 Synchronization

The W-Master provides the system’s master clock which is a downlink sent each W-Sub-cycle. To precisely switch the radio mode and send the Uplinks in the respective timeslots, the clocks of the W-Devices need to be continuously synchronized with the master clock. Synchronization of a W-Device clock takes always place when the W-Device receives a downlink from the W-Master. When the clocks after a longer communication pause between W-Master and W-Device have deviated (this particularly happens using low energy W-Devices), the W-Device may listen for a longer period of time until it detects its W-Masters downlink again.

A paired W-Device that has lost clock synchronization still knows the frequency channels of its W-Master via the frequency table. It just listens at one particular frequency channel until it receives an appropriate downlink of its W-Master and is then able to synchronize to the hopping sequence and uplink time slots.

4.5.3 SSlots, DSlots, Transmission capacity

The transmission capacity of downlink and uplink is shown in Figure 18. The Downlink can carry 52 octets. An uplink message can carry 12 octets or 25 octets, depending on the slot type “SSlot” or “DSlot”. DSlots combine the payload of two SSlots to operate sensors or actuators with larger process data, but this reduces the number of possible W-Devices per track.




Figure 18 Transmission capacity with SSlots and DSlots

Some octets are required for protocol control data and integrity checksums, finally reducing the usable message payload. The message payload encodings are listed in Annex A clause 12.

4.5.4 Assignment of W-Devices to tracks and slots

A W-Master contains up to 5 tracks, which are numbered from 0 to 4. Each track has up to 8 slots, numbered from 0 to 7. This allows a maximum number of 40 W-Devices per W-Master.

Figure 19 shows the assignment of W-Device numbers to slots and tracks.

The allocation of W-Devices to track and Slot number is performed during commissioning and pairing.




Figure 19 Uplink assignments

Numbering gaps in the W-Device count can occur because of DSlot usage (DSlots shall always be placed on even slots, see Figure 40) or non-used slots in a track.

1180


1181 **4.5.5 Assignment of W-Ports to W-Devices**

1182 A W-Master provides a limited number of virtual W-Ports, depending on the number of available tracks and
1183 the slot configuration, since W-Devices with occupation of a DSlot reduce the number of available W-Ports.
1184 The W-Master must therefore administratively map its W-Device slots to these virtual W-Ports, which is
1185 performed on application level during commissioning. The Application shall maintain a monotonically
1186 increasing numbered list of W-Ports counting from 0 in the sequence of the commissioning operation and
1187 assign the W-Device slots autonomously. The mapping between W-Port and W-Device slot numbering is
1188 given via the W-Port handler of the System Management SM. The Track and W-Device Mapper (TD-Mapper)
1189 uses this information to map a W-Port to the corresponding track and slot (see 6.1.1).
1190

1191 **4.5.6 W-Cycle**

1192 A W-Cycle utilizes TDMA and FDMA in combination with a retransmission mechanism to achieve a very
1193 dependable wireless transmission. The standard duration of a complete W-Cycle is almost 5 ms as shown
1194 in Figure 20, consisting of three W-Sub-cycles. The W-Cycle is configurable via SM_SetPortConfig with a
1195 granularity of the time duration of a W-Sub-cycle.
1196 The W-Master uses the remaining W-Sub-cycles for retries in case of transmission errors caused by channel
1197 interferences. The different frequency channels for these sub-cycles and for each track are the
1198 countermeasure against these channel interferences. When no retransmissions are required within a W-
1199 Cycle, the otherwise unused bandwidth can be used to transfer acyclic data, such as On-request data (OD)
1200 or Events.

1201 A W-Master can comprise up to five (small band) transceivers with their own antenna and dedicated
1202 frequency channels, called a track. Each track can serve up to 8 W-Devices and send and receive
1203 alternately. All tracks of a W-Master send at the same time on different frequencies according to the
1204 computed frequency hopping tables, providing an optimal medium utilization
1205



1206 **Figure 20 TDMA and FDMA in the W-Cycle**

1207

4.5.7 W-Frame

A W-frame is the data structure in which a communication exchange between a W-Master and its W-Devices is organized (see Figure 21). It is structured in Control intervals, Downlink and Uplinks. In Control interval, the radio switches between transmission and reception and in the first Control interval also frequency hopping takes place.

The Downlink addresses all devices via broad cast. The Uplinks is transmitted subsequently W-Device by W-Device in the respective timeslot. The W-Frame is transmitted in a W-Sub-cycle of 1.664ms.




Figure 21 W-Frame and W-Sub-cycle

5 Air interface / Physical Layer (PL)

This clause describes the relevant definitions for transceivers and media access on both, W-Master and W-Devices, which must comply to the requirements described below. For an easier relationship to the IO-Link Interface and System specification REF 1 the air interface, which contains the wireless mechanisms and the physical layer, is called physical layer (PL) furthermore.




Figure 22 Physical layer (W-Master)




Figure 23 Physical layer (W-Device)

5.1 Base technology, Physical Layer (PL)

IO-Link wireless uses frequencies from 2401 to 2480 GHz of the license-free 2.4 GHz ISM band (industrial, scientific, and medical).

Physical Layer of IO-Link wireless is based on the proven technology used in Bluetooth® version 4.2 (Bluetooth Low Energy). It is therefore possible to use radios available on the market with the restriction that the requirements, described in the following clauses, being taken in account.

5.1.1 Transmission rate

The on-air bit duration T_{bit} is 1 μ s as shown in Figure 24. Hence, the gross transmission rate is 1 Mbit/s.

5.1.2 Carrier frequency accuracy

The carrier frequencies f_c of a W-Master or a W-Device shall not deviate more than +/- 20 ppm.

5.1.3 W-Device Carrier frequency calibration

W-Device adjusts their carrier frequency to those of its W-Master. To adjust carrier frequency and compensate aging and thermal drifts, the W-Devices shall measure the frequency deviation during reception of each Downlink. This deviation is used by the W-Device for recalibration of its carrier frequency before each transmission.

If a W-Device is waiting on pairing request from a W-Master longer than two minutes on the configuration channel, it shall start to sweep its carrier frequency in frequency steps of +/- 25 kHz. Each frequency step is to be used four times before the next step. The maximum deviation of the sweep is +/- 250 kHz.

5.1.4 W-Master Carrier frequency calibration

The carrier frequencies of a W-Master should be calibrated to the defined carrier frequency accuracy during manufacturing.

5.1.5 Modulation

IO-Link wireless uses binary Gaussian frequency shift keying (GFSK) modulation scheme with a Gaussian filter bandwidth bit period product $BT=0.5$. The modulation index shall be 0.5.




Figure 24 Base technology and modulation

Figure 24 shows an unmodulated carrier frequency and the binary frequency modulated signal. A binary one shall be represented by a positive frequency deviation, and a binary zero shall be represented by a negative frequency deviation.

The frequency transitions are non-linear (red circle in Figure 24) and cause interfering harmonics. A Gaussian filter reduces this impact. The entire modulation mechanism is named Gaussian Frequency Shift Keying (GFSK).

5.1.6 Transmission power

The transmission power shall meet FCC 15.247 and EN 300 328 for the use of the 2.4 GHz ISM frequency band. For this reason, the maximum transmission power of a W-Master or W-Device should not exceed a total of 10 mW. If at a W-Master more than one track is used, all tracks are sharing the 10 mW. Thereby the antenna gain shall be taken in account.

The output power shall be controlled by setting the attribute TransmitPower.

5.1.7 Antenna

If radio regulations (see 5.1.6) are met, a W-Master or W-Device can use internal or external antennas. If an antenna with direction characteristic is used, also the maximum transmission power of ≤ 10 dBm EIRP shall be observed for any direction.

5.1.8 Receiver sensitivity

The minimal radio sensitivity on the W-Master and W-Device side shall be at least -94 dBm. With a transmission power of 2 mW, a guaranteed range of 10 meters and a message latency less than 5 ms with a remaining failure probability of less than 10^{-9} can be achieved like this.

1279
1280
1281
1282
1283

5.1.9 Transceiver timings

To meet the necessary timings for the W-sub-cycle (See in clause 5.3) as shown in **Figure 25** Figure 25, switching between different transceiver states shall fulfill the requirements listed in Table 1.




Figure 25 Transceiver timings

1284
1285

Table 1 Transceiver timings within W-Sub-cycle

W-Master					
Name (see Figure 25)	Minimum	Typical	Maximum	Unit	Remark
Oscillator accuracy	-20	0	20	ppm	The maximal oscillator deviation allowed
T_{BIT}	n/a	1	n/a	μs	Bit time at 1 Mbit/s transmission rate
M_SWITCH_RX_TX	-1	208	+1	μs	Time between the end of last Uplink and begin of next Downlink. Within this time, the W-Master transceiver shall change frequency channel and switch from receive (Rx) to transmit (Tx). The transmission of the Downlink shall start immediately after this time interval.
M_TX_DLink	n/a	416	n/a	T_{BIT}	The W-Master transceiver shall transmit a complete Downlink with 416 bits to all devices.
M_TX_PRE-DLink	n/a	88	n/a	T_{BIT}	The W-Master transceiver shall transmit a Pre-Downlink part of the complete Downlink with 88 bits to all W-Devices.
M_SWITCH_TX_RX	-1	208	+1	μs	The time between the end of Downlink and begin of Uplinks. Within this time the transceiver shall switch from transmit (Tx) to receive (Rx). The reception of the Uplinks shall start immediately after this time interval. NOTE: No change of frequency
M_RX_ULink	n/a	832	n/a	T_{BIT}	Receive of all separate W-Device Uplinks within a W-Sub-cycle on frequency of Downlink: only SSlot: $8 * (96 T_{BIT} + M_GUARD)$ only DSlot: $4 * (200 T_{BIT} + M_GUARD)$ or mix of SSlot and D-Slot NOTE: See Mx_RX_RX
Mx_RX_RX	n/a	8	n/a	T_{BIT}	Receive- to Receive-Time between two Uplinks except the last Uplink. e.g.: The W-Master transceiver receives an Uplink x. After this Uplink, the transceiver has this time to recover to Rx to receive next Uplink x+1. The recovery time shall be less than given time of $8T_{BIT}$

W-Device					
Name (see Figure 25)	Minimum	Typical	Maximum	Unit	Remark
Radio frequency deviation	-250	0	250	kHz	The maximum carrier frequency error, which can be tolerated by radio
Frequency correction step	n/a	25	n/a	kHz	Frequency step used by correction of the carrier frequency error
T _{BIT}	n/a	1	n/a	μs	Bit time at 1 Mbit/s transmission rate
D_SWITCH_TX_RX	-1	208	+1	μs	Time between the end of Uplink of slot 7 and begin of next Downlink. Within this time, the W-Device transceiver shall change frequency channel and switch from transmit (Tx) to receive (Rx). The reception of the Downlink for each slot shall start immediately after this time interval.
D_RX_DLink	n/a	416	n/a	T _{BIT}	The W-Master transceiver shall transmit a complete Downlink with 416 bits to all devices.
D_RX_PPE-DLink	n/a	88	n/a	T _{BIT}	The W-Master transceiver shall transmit a Pre-Downlink with 88 bits to low energy devices.
D_SWITCH_RX_TX	-1	208	+1	μs	Time between the end of Downlink and begin of Uplink of slot 0. Within this time the W-Device transceiver shall switch from receive (Rx) to transmit (Tx). The time difference between the end of the time interval D_SWITCH_RX_TX and the start of the transmission for each Uplink can be calculated as following: Slot_N x [D_TX_ULink + D_GUARD] NOTE: No change of frequency
Dx_TX_ULink	n/a	96	n/a	T _{BIT}	Time a single slot W-Device sends its Uplink.
Dx_TX_ULink_D	n/a	200	n/a	T _{BIT}	Time a double slot W-Device sends its Uplink.
D_GUARD	n/a	8	n/a	μs	Guard time between two Uplinks. This prevents from "overlapping on air" of the W-Device Uplink before or after.
D_GUARD/2	n/a	4	n/a	μs	Uncertainty time by reception of the Downlink on W-Device side

1288


1289

5.2 Downlink and Uplink

5.2.1 Transmission octet order for WORD based data types

The values within the payload, independent of the architecture, transmitted in *Big Endian* format as shown in Figure 26. The following rule shall apply:

- The Most Significant octet (MSO) transmitted first.



Key

MSO = Most Significant octet

LSO = Least Significant octet

Figure 26 Memory Storage and transmission order for values for WORD based data types

5.2.2 Downlink and Uplink transmission

The bit ordering within each octet on the air follows the *Little-Endian* format. The Least Significant Bit (LSB) is the first bit, which shall be sent over the air for each octet. For instance, an 8-bit value 0x26(hex) (binary 0010 0110) is transmitted as shown in Figure 27.

b ₀	b ₁	b ₂	b ₃	b ₄	b ₅	b ₆	b ₇
0	1	1	0	0	1	0	0

t₀




Figure 27 Bit ordering within an octet

The radio transmits payload octets as an octet array over the air as shown in Figure 28.

octets on air

Figure 28 The order of the octets is not altered during data transmission/reception.



octets on air

Figure 28 Octet array transmission over the air

5.2.3 Preamble

Each Downlink or Uplink always starts with the so-called "Preamble", a unique bit pattern. The two octets of the Preamble can contain either the value "0xAA" or "0x55". If the first bit of the syncword on air is "0" the preamble shall be set to "0xAA" otherwise the Preamble shall be set to "0x55". For example used syncword "0x59943E" the preamble shall be set to "0xAA". It shall be stored in the transmit buffer as shown in Figure 29.

First bit of syncword on air	Preamble octet 0	Preamble octet 1
0	AA	AA
1	55	55

Figure 29 Octet ordering of Preamble values

5.2.4 Syncword

The syncword immediately follows the Preamble. The syncword is required for octet synchronization and identification of the packet as an IO-Link wireless packet. The three octets long syncword shall be stored in to the transmit buffer directly after the preamble.

ConfigSyncword

This syncword is used for the configuration channels. The octets of the ConfigSyncword shall have the values and octet order shown in Figure 30.

ConfigSyncword octet 0	ConfigSyncword octet 1	ConfigSyncword octet 2
0	1	2
3E	94	59

Figure 30 Octet ordering of ConfigSyncword

DataSyncword

This syncword is used for the data channels. In this version of the system extension, the octets of the DataSyncword shall have the values and octet order shown in Figure 31 . This DataSyncword shall be transmitted on Pairing Request from the W-Master to the W-Device (see Figure 141). By this mechanism other DataSyncwords are possible for future versions. Currently only the DataSyncword from Figure 31 shall be used.

DataSyncword octet 0	DataSyncword octet 1	DataSyncword octet 2
3E	94	59

Figure 31 Octet ordering of DataSyncword

5.2.5 Downlink and Uplink CRC

CRC are necessary to avoid reception of a wrong message as a right one. Each Pre-Downlink, Downlink and Uplink has a CRC at the end to check its consistence after wireless transmission. The Pre-Downlink CRC has a length of 16 Bit. The Full-Downlink and all Uplinks have a CRC length of 32 Bit. To get the same probability of a correct message for Uplinks and the Full-Downlink they need a longer CRC due to of their data length.

5.2.6 CRC Transmission

The result of the CRC16 and CRC32 shall be stored in a *Big Endian* format in the transmit buffer. See Figure 32 and Figure 33.

octet 0	octet 1
CRC (15:8)	CRC (7:0)

Figure 32 Octet ordering of CRC16 result values

octet 0	octet 1	octet 2	octet 3
CRC (31:24)	CRC (23:16)	CRC (15:8)	CRC (7:0)

Figure 33 Octet ordering of CRC32 result values

5.2.7 Data Whitening


Before transmission and after receiving, the W-Frame is scrambled/descrambled with a data whitening polynomial in order to randomize the data from highly redundant pattern and to minimize DC bias in the W -

1368 Frame. IO-Link wireless shall use the same whitener as the Bluetooth 4.2 with the polynomial shown in
 1369 Equation 1.

$$P = X^7 + X^4 + 1$$

1370
 1371
 1372 **Equation 1 Whitening Polynomial**


1373
 1374 The Figure 34 shows the realization of the whitening pseudo random number generator using a shift register
 1375 with a feedback:



1376
 1377
 1378
 1379
 1380 **Figure 34 Data Whitening LFSR**

1381 **5.2.8 Regular Downlink**

1382 The data structure of the Regular Downlink is shown in Figure 35. The distribution of payload of Pre-
 1383 Downlink and Full-Downlink is dynamically assembled by Message handler (see clause 12). The data
 1384 structure of the Downlink is described in clause 13.2 in detail.
 1385



1386
 1387
Figure 35 Regular Downlink

5.2.9 Configuration Downlink

The data structure of the Configuration Downlink is shown in Figure 36. The content of the payload is compiled by the Physical Layer (see clause 12). Data structure of the configuration Downlink is described in 13.3. in detail.




Figure 36 Configuration Downlink

5.2.10 Uplink Single Slot (SSlot)

The data structure of the SSlot Uplink is shown in Figure 37. The DL-A handler compiles the Uplink payload. There are maximal 8 Slots possible per track of a W-Frame.





Figure 37 Uplink - SSlot

5.2.11 Uplink Double Slot (DSlot)

The data structure of the DSlot Uplink is shown in Figure 38. The DL-A handler compiles the Uplink payload. There are maximal 4 D-Slot possible per track of a W-Frame.

1404



1405

Figure 38 Uplink - DSLOT

1406

1407

5.3 W-Sub-cycle

1408

The general concept of the W-Cycle and the W-Sub-cycles is specified in Figure 20. The following subclauses explain definitions for packets within a W-Frame.

1409

1410

1411

5.3.1 W-Sub-cycle structure

1412

A W-Sub-cycle describes a time frame with a duration of 1.664 ms, because the minimum cycle time shall be shorter than 5 ms. For this purpose the W-Sub-cycle has a length of 1.664 ms => 3 x cycle < 5 ms. In a W-Sub-cycle a complete communication exchange between a W-Master and its W-Devices is organized (see Figure 39 Format of a W-Sub-cycle with DSLOTS). The detailed encoding of W-Messages within W-Sub-cycles are described in clause 12.

1413

1414

1415

1416

1417

1418


The first part of a W-Sub-cycle is a control interval of 208 μs. In this interval, the carrier frequency and transceiver mode are adjusted. After that the so-called "Downlink" starts. The Downlink has a duration of 416 μs and can contain individual W-Message(s) for each W-Device, e.g. W-Device in Slot_N 2 in Figure 39.

1419

1420

1421

1422



1423

Figure 39 Format of a W-Sub-cycle with DSLOTS

1424

After the control interval during which the transceivers of the W-Master switches from "transmit" (TX) to "receive" (RX) and of the W-Device vice versa, the Uplink with a total duration of 832 μ s starts. In the "Uplink" each W-Device has its own time slot to response, e.g. Slot_N 2 for W-Device 2 in Figure 39.

1426

Between sequentially Uplink slots, a guard interval with a duration of 8 μ s is placed. At the beginning of the guard interval the previous W-Device stops sending, while the following W-Device starts sending at the end of the guard interval. The guard interval is required for the W-Master to recover.

1428

A W-Device can use two kinds of Slots in an Uplink with different duration, Single Slots (SSlot) with 96 μ s (see Figure 37) or Double Slots (DSlot) with a length 200 μ s (see Figure 38). Only by using SSlots, the maximum number of 8 W-Devices per track can be achieved. DSLOTS shall always start at an even slot number. If in a track an odd number of SSlots is used one SSlot cannot be used e.g. SSlot 5 in Figure 39.


1430

1431

1432

1433

1434



1435

Figure 40 SSlots and DSLOTS

1436

5.3.2 Regular W-Frame

1437


Figure 41 shows the structure of a regular W-Frame, which is used for cyclic transmission of IO-Link Process Data (PD) and acyclic transmission of On-request Data (OD). This W-Frame can contain multiple W-Messages in its Downlink section addressed to dedicated W-Devices.

1439

The first part of the Downlink, the so-called Pre-Downlink, is integral part of the full Downlink for regular W-Frames. It contains the acknowledgments and two octets payload. Pre-Downlink has its own 16 bit CRC signature. low energy W-Devices may reduce their receiver activity time by only receiving the Pre-Downlink instead of the full Downlink.

1442

1444 All other W-Devices of the track shall receive the entire Downlink section and the 32 bit CRC signature at
 1445 the end.
 1446



1447 **Figure 41 W-Frame structure**

1448 **5.3.3 Configuration W-Frame**

1449 During pairing and configuration via the configuration channel, the W-Master communicates with only one
 1450 W-Device. This allows using the entire Downlink space for the transfer of ConnectionParameters. There is
 1451 no Pre-Downlink encoded in this frame type. Consequently, only the addressed W-Device returns a
 1452 message within the Uplink section (see Figure 42).
 1453



1454 **Figure 42 W-Frame type for pairing and configuration**

1455 **5.4 Medium Access Control (MAC)**

1457 This clause describes the relevant definitions for media access on both, W-Master and W-Devices, which
 1458 must comply with the requirements described below.

1459 W-Devices and W-Master shall operate in synchronous manner in frequency and time domain. Therefore,
 1460 the synchronization of the W-Devices on a W-Master is necessary. Initial synchronization of the W-Device
 1461 on its W-Master takes place during the pairing process. A paired W-Device resynchronizes its timing on
 1462 each successful reception of the Downlink. The W-Devices calculates the next Downlink transmission time
 1463 and adds a window of uncertainty of 4 μs (D_GUARD/2) to control its receiver activity.

1464 W-Devices after a longer inactivity period might loose clock synchronization with their W-Master. In this
 1465 case it is required to increase the uncertainty window of the W-Device, thus increasing the receiver on-
 1466 time.

1467 The use of orthogonal frequency channel hopping sequences by the W-Masters and their associated W-
 1468 Devices allows operational coexistence of overlapping IO-Link wireless systems. The W-Master creates the
 1469 hopping sequences. For increasing capability of W-Coexistence, the frequency channel hopping sequences
 1470 can be adapted to environment using Blacklisting. During the pairing and configuration processes, the W-
 1471 Master downloads these hopping sequences into the unpaired W-Devices.

1472 **5.4.1 Frequency channels**

1473 The carrier frequencies f_n are defined by the frequency channel number n using Equation 2

$$f_n = f_0 + n \times 1 \text{ MHz}$$

1474 **Equation 2 Carrier frequencies**

1475 where

1476 $f_0 = 2400 \text{ MHz}$

1477 $n = 3 \text{ to } 78.$

1478 The minimum spectral distance between the tracks of a W-Master is 3 MHz. The bandwidth of a modulated
 1479 carrier frequency is less than 1.1 MHz.

5.4.2 Default Hopping Table HT01

IO-Link wireless defines the frequency channel hopping table HT01. HT01 omits the frequency channels f_{1-2} and f_{79-80} . The frequency channels f_1 and f_{80} are reserved for configuration (see 5.4.4). Hopping table HT01 is organized in rows and columns. In a column, all frequency channels used by a W-Master and its W-Devices within a W-Sub-cycle are listed. In a row, the sequence of frequency channels used by a track of a W-Master and its W-Devices is listed. HT01 additionally allows blacklisting of each 1 MHz frequency channel (see 5.4.5).

The frequency hopping sequence of all tracks of overlapping W-Masters shall be orthogonal to avoid transmission collisions within a W-Master. Therefore, in a cell with three W-Masters, the probability of collisions by chance is sufficiently low.

Each track of a IO-Link W-Master shall keep the hopping tables of all other tracks of this W-Master, which enables a (e.g. roaming) track to pair a W-Device to another target track of this W-Master. Therefore the target track can stay in cyclic mode without loss of performance during pairing.

The sequence of frequency channels in HT01 is determined by the HT01 parameters listed in Table 2.

Table 2 HT01 parameter

HT01 parameter	Definition	Remark
Col_N	Column number within the frequency hopping table HT01	The frequency channels of the sequence listed column by column. See 18.2
MasterID	MasterID: The ID the W-Master is assigned to	
Blacklist	List of unused frequency channels	An 80-bit word each bit representing a frequency channel. See Section 5.4.5
Track Number	Ensures that all tracks of the W-Master have non-overlapping frequency tables	
Frequency Spacing	Ensures the interference between the tracks within a W-Master are minimal	For this purpose, the minimal space between the channels within a track frequency group must be greater or equal to 3 MHz but not greater than 5 MHz.

The Hopping Sequence is calculated in the IO-Link Wireless Master according to the following algorithm:

- Determine possible frequencies for the tracks
- Build non-overlapping groups of frequencies
- Build the hopping sequence depending on the MasterID

See clause 18.2 for calculation rules and examples.

5.4.3 Alternative Hopping algorithms

Hopping algorithms other than for calculation of HT01 may be specified in further versions of this specification.

5.4.4 Configuration Frequencies

The frequencies f_1 and f_{80} (i.e. 2401 MHz and 2480 MHz) are exclusively reserved for configuration channels. They shall be used in an alternating manner to reduce frequency related interferences. The configuration frequencies cannot be blacklisted. Clause 18.3 describes their utilization in detail.

5.4.5 Blacklisting

In order to mitigate interference from or to other devices in the 2.4 GHz ISM band affected frequency channels can be omitted by appending them to the blacklist (see Table 183). It should be taken in account, that the reduction of available frequency channels may compromise latency in a non-deterministic manner. See clause 18.2 for calculation rules and examples.

1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535

1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547

5.4.6 Link Quality Indication

Link Quality Indication is a service for evaluation of the functionality and reliability of the IO-Link Wireless System in certain application environments. This service should be used during commissioning or significant changes during the running period of the IO-Link Wireless System. Optional it can be used during operating mode of the IO-Link Wireless system for monitoring the wireless environment regarding reliability. To analyze connection quality independent from RSSI the Link Quality Indication shall be evaluated on each W-Port. Therefore, the first order Remaining Failure Probability (RFP(1)) is used to calculate Packet Error Probability (PEP) of the last 3000 Packets with Equation 3

Equation 3 Remaining Failure Probability
 $RFP = PEP_{(1)}^{(1+MaxRetry)}$

The RFP can be described in percent using values from Table 3.

Table 3 Link Quality Indication

RFP	Link Quality
10 ⁻⁹	100 %
5x10 ⁻⁹	80 %
10 ⁻⁸	60 %
5x10 ⁻⁸	40 %
8x10 ⁻⁸	20 %

5.5 Physical Layer PL services

5.5.1 Overview

An overview of the Physical Layer and its service primitives is given in Table 4 and Figure 44. They are the interface to the higher protocol layers.

5.5.2 PL Services for W-Master


Subsequently, the services are specified which are provided by the PL to System Management and to the Data Link Layer (see Figure 22 for a complete overview of all the services). Table 4 lists the assignments of W-Master to their roles as initiator or receiver for the individual PL services.

1548

Table 4 PL Service assignments of W-Master

Service name	Master
PL_SetTrackConfig	R
PL_SetMode	R
PL_Scan	I
PL_ScanEnd	I
PL_SetSlotConfig	R
PL_Pairing	I / R
PL_State	I
PL_Transfer	I / R
PL_QualityService	R
PL_GetHopTable	R
PL_SetHopTable	R
PL_SetWakeUpTime	R
PL_WakeUpTime	I
PL_AHTStatus	I
PL_CmdTrig	R
Key (see 3.3.5) I Initiator of service R Receiver (Responder) of service	

1549
1550



1551
1552

Figure 43 Physical Layer services of the W-Master

1553

5.5.2.1 PL_SetTrackConfig (W-Master)

1554
1555
1556
1557

The PL_SetTrackConfig service is used to setup the initial parameter for each track on a W-Master. The parameters of the service primitives are listed in Table 5.

Table 5 PL_SetTrackConfig

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

1558

Argument

The service-specific parameters are transmitted in the argument.

ParameterList

This parameter contains the configured parameters of a Track.

Parameter Type: Record

Record Elements:

MasterID: This parameter contains the MasterID of the W-Master (see Table 140)

Permitted values: 1-29

BlackList: This parameter contains the frequency channels which shall not be used by the W-Master.

Permitted values: 0x0000 0000 0000 0000 0000 to 0x7FFF FFFF FFFF FFFF FFFE
(bitwise coded 1MHz channels 2-79 (LSB first))

Track_N: This parameter set up the internal number of a track for calculation of track-dependent hopping sequence.

Each Track shall be numbered consecutively within a W-Master. Permitted values: 0-4

SyncTrack: This parameter defines, whether the Track is running as W-Frame

SyncMaster or SyncSlave. The synchronization signal is transferred via a hardware pin to tracks configured as SyncTrack (SLAVE).

Permitted values:

MASTER (The track generates the hardware synchronization-signal on each start of W-Sub-cycle)

SLAVE (To start its W-Sub-cycle the track is waiting for the hardware synchronization signal, which is generated by the track configured as SyncTrack(MASTER))

DataSyncword

DataSyncword which shall be used for data channels (see clause 5.2.4)

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:

STATE_CONFLICT (service unavailable within current state)

PARAMETER_CONFLICT (consistency of parameter set violated)

5.5.2.2 PL_SetMode (W-Master)

The PL_SetMode service is used to setup the mode of a track and configuration for transmission power of the physical layer. This service can also be called during runtime to change the parameters (State ≠ Idle_0). The parameters of the service primitives are listed in Table 6.

Table 6 PL_SetMode

Parameter Name	.req	.cnf
Argument	M	
TrackMode	M	
TxPower	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

TrackMode:

This parameter indicates the requested operational mode of the radio (see Table 7)

Permitted values: STOP, CYCLIC, SCAN, ROAMING

TxPower:

This parameter indicates the transmission power level of the track.

Permitted values: 1 to 255 (See 10.9 for definition)

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:

STATE_CONFLICT (service unavailable within current state)

PARAMETER_CONFLICT (consistency of parameter set violated)

Table 7 specifies the coding of the different parameters.

Table 7 Definition of parameters for Service PL_SetMode

TargetMode	Definition
STOP	Communication disabled, radio turned off
SCAN	W-Master is working in Scan mode. (Limited performance)
ROAMING	W-Master is working in Roaming mode. (Limited performance)
CYCLIC	W-Master is working in Cyclic mode. (Full performance)

5.5.2.3 PL_Scan (W-Master)

The PL_Scan service is used to report a new unpaired W-Device within the track's proximity via indication. This is only initiated by PL if the track is in ROAMING or SCAN mode. The parameters of the service primitives are listed in Table 8.

Table 8 PL_Scan

Parameter Name	.ind
Argument	M
ParameterList	S

Argument:

The service-specific parameters are transmitted in the argument.

ParameterList

This parameter contains the information of the found W-Device.

Parameter Type: Record

Record Elements:

SlotType: Type of the W-Device in Uplink

Permitted values: SSLOT, DSLOT (see Table 21)

UniqueID: This parameter indicates the UniqueID of the Device. (see Figure 156)

RevisionID: This parameter indicates the protocol version of the found W-Device. (see Figure B.4 in REF 1)

5.5.2.4 PL_ScanEnd (W-Master)

The PL_ScanEnd service is used to indicate the end of the scan mode. The parameters of the service primitive are listed in Table 9.

Table 9 PL_ScanEnd

Parameter Name	.ind
<none>	

5.5.2.5 PL_SetSlotConfig (W-Master)

The PL-SetSlotConfig service is used to setup the slot configuration for a W-Device. If the connection to W-Device is established, only IMATime shall be changed. If the connection to W-Device is not established, all parameters can be changed.

The parameters of the service primitives are listed in Table 10.

1648
1649

Table 10 PL_SetSlotConfig

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

1650

Argument

1651

The service-specific parameters are transmitted in the argument.

1652

ParameterList

1653

Parameter Type: Record

1654

UniqueID: This parameter contains the UniqueID of the W-Device (see Figure 156)

1655

SlotType: Type of the W-Device in Uplink given through W-Device application.

1656

Permitted values: SSLOT, DSLOT (see Table 161)

1657

Slot_N: This parameter contains the Slot number for the corresponding W-Device

1658

Permitted values: 0-7. Each DSLOT (only on even Slots allowed) occupies 2 SSLOT's.

1659

IMATime

1660

This parameter contains the I am alive time (see clause 14.3.5) for the corresponding Slot/W-Device (see 10.3 to detect COMLOST).

1661

1662

Result (+):

1663

This selection parameter indicates that the service has been executed successfully.

1664

Result (-):

1665

This selection parameter indicates that the service failed.

1666

ErrorInfo

1667

This parameter contains the error information. Permitted values:

1668

STATE_CONFLICT (service unavailable within current state)

1669

PARAMETER_CONFLICT (consistency of parameter set violated)

1670

1671

5.5.2.6 PL_Pairing (W-Master)

1672

This service is used to pair or unpair a W-Device from the W-Master via system management. The parameters of the service primitives are listed in Table 11.

1673

1674

1675

Table 11 PL_Pairing

Parameter Name	.req	.cnf	.ind
Argument	M		M
ParameterList	M		
Info			M
Result (+)		S	
Result (-)		S	
ErrorInfo		M	

1676

Argument:

1677

The service-specific parameters are transmitted in the argument.

1678

ParameterList

1679

Parameter Type: Record

1680

UniqueID: This parameter contains the UniqueID of the W-Device (see 14.3.9)

1681

Track_N: This parameter selects the track number where the W-Device should be assigned to.

1682

Used to pair a W-Device to another track for example when one track is in roaming mode.

1683

SlotType: Type of the W-Device in Uplink given through W-Device application.

1684

Permitted values: SSLOT, DSLOT (see Table 21)

1685

Slot_N: This parameter contains the Slot number for the corresponding W-Device

1686 Permitted values: 0-7 SSLOT's. Each DSLOT (only on even Slots allowed) occupies 2
 1687 SSLOT's.
 1688 **Method:** This parameter requests the pairing mode which shall be used.
 1689 Permitted values:
 1690 PAIRING_BUTTON (PL shall use the W-Frame Figure 141 to pair a W-Device via button
 1691 method)
 1692 PAIRING_UNIQUE (PL shall use the W-Frame Figure 141 to pair a W-Device via U-ID)
 1693 PAIRING_ABORTED (pairing is stopped by the W-Master application)
 1694 UNPAIRING (PL issues the MasterCommand "Unpairing" and clears the configuration of
 1695 the slot given in Slot_N. No further ULinks can be received)
 1696 **TargetMode:** This parameter requests the mode of the W-Device to be paired
 1697 Permitted values: CYCLIC, ROAMING
 1698 **Timeout:** This parameter contains the timeout for a pairing attempt in seconds. See Table 186
 1699 (definition of PAIRING_BUTTON_TIMEOUT, PAIRING_UNIQUE_TIMEOUT)
 1700 **Info**
 1701 Permitted values:
 1702 PAIRING_SUCCESS (Device has been paired)
 1703 PAIRING_TIMEOUT (Device was not paired within the time given in Timeout)
 1704 PAIRING_WRONG_SLOTTYPE (The Device cannot support the requested SlotType)
 1705 **Result (+):**
 1706 This selection parameter indicates that the service has been executed successfully.
 1707 **Result (-):**
 1708 This selection parameter indicates that the service failed.
 1709 **ErrorInfo**
 1710 This parameter contains the error information.
 1711 Permitted values:
 1712 STATE_CONFLICT (service unavailable within current state)
 1713 PARAMETER_CONFLICT (consistency of parameter set violated)
 1714

1715 **5.5.2.7 PL_State (W-Master)**

1716 The PL_State service is used to signal the state of a running or lost connection for the W-Device on the
 1717 corresponding SSLOT or DSLOT. The parameters of the service primitives are listed in Table 12.
 1718
 1719

Table 12 PL_State

Parameter Name	.ind
Argument	M
PLInfo	M

1720 **Argument**
 1721 The service-specific parameters are transmitted in the argument.
 1722 **PLInfo:**
 1723 This parameter contains the bit coded status of the connection for each Slot.
 1724 Bit 0 represents Slot_N 0. Bit 7 represents Slot_N 7
 1725 Bitvalues: 0: COMLOST (Device has no or lost connection to its Master)
 1726 1: SYNCED (Device is synchronized with its Master)
 1727

5.5.2.8 PL_Transfer (W-Master)

The PL-Transfer service is used to exchange the data between Data Link Layer and Physical Layer. The generation of the ACK-Bits for each W-Device is handled in PL (see 13.6). The parameters of the service primitives are listed in Table 13

Table 13 PL_Transfer

Parameter Name	.req	.ind
Argument	C	M
PreDIData	M	
Data	M	C
DataLength	M	C
ULinkType		C
Slot_N		C
Acknowledge		C
WFrameComplete		C
Result (+)		
Result (-)		
ErrorInfo		

Argument

The service-specific parameters are transmitted in the argument.

PreDIData

This parameter contains the data of the Pre-Downlink
DataLength 2 octet

Data

This parameter contains the data which are transferred from / to the PL (radio interface). Data contains one or more W-Message(s) (Control Octet + corresponding data).

DataLength

This parameter contains the length of transmitted data, dependent on the direction (DLink or ULink) and the uplink type.

Ranges: PL_Transfer.req: up to 37 octets in FULLDOWNLINK (data from master to W-Device)

PL_Transfer.ind: 2 octets (data from W-Device to master, SSlot-Format)

PL_Transfer.ind: 15 octets (data from W-Device to master, DSlot-Format)

ULinkType:

This parameter contains the type of ULink. Permitted values:

DATA (regular ULink received, see 13.4. Regular Uplink Frame Annex B).

NOUPLINK (No ULink received)

IMA (IMA ULink received, see Figure 146 and Figure 147 and IMA-Uplink Frame Annex B).

Slot_N:

This parameter contains the Slot_N to assign the received ULink to the corresponding W-Port (see 6.1.1 TD-Mapper)

Acknowledge

This parameter indicates, whether the last DLink has been confirmed by W-Device or not. PD handler, Event handler and OD handler needs the Acknowledge from PL to decide, if a retransmit of data for the corresponding W-Device is needed or not.

WFrameComplete:

This parameter indicates that the W-Frame has been completed (all ULinks have been processed). The Message handler needs this information to start the assembly of the next Downlink.

Result (+):

This selection parameter indicates that the service request has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

StatusErrorInfo

This parameter contains the error information.
 Permitted values:
 STATE_CONFLICT (service unavailable within current state)

5.5.2.9 PL_QualityService (W-Master)

The PL_QualityService is used to request the actual link-quality of the wireless connection between the W-Master-track and the corresponding W-Device. The Service responds with the link quality in percent for each W-Device (see clause 5.4.6). The parameters of the service are listed in Table 14.

Table 14 PL_QualityService

Parameter Name	.req	.cnf
Argument	M	
Slot_N	M	
Result (+)		S
Quality		M
Result (-)		S
ErrorInfo		M

Argument:

The service-specific parameters are transmitted in the argument.

Slot_N: This parameter indicates the selected Slot_N with its corresponding W-Device.
 Permitted values: 0 to 7.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Quality

Parameter type: Octet

Permitted Values: 0 to 100%.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

STATE_CONFLICT (service unavailable within current state)

5.5.2.10 PL_GetHopTable (W-Master)

The PL_GetHopTable service is used to get the hopping table from the PL to the AHT handler in SM for channel monitoring, see clause 9.2.3.2.4. The parameters of the service primitives are listed in Table 15.

Table 15 PL_GetHopTable

Parameter Name	.req	.cnf
Argument	M	
Track_N	M	
Result (+)		S
Data		M
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

Track_N: This parameter selects the track number of which to read the hopping table values. Used to read all the hopping table values from any track, see clause 5.4.2.

Permitted values: 0-4

Result (+):

1806 This selection parameter indicates that the service has been executed successfully.
 1807 **Data**
 1808 Parameter type: 78 Octets
 1809 This parameter contains the used hopping table sequence in PL (see clause 13.3.3).
 1810 **Result (-):**
 1811 This selection parameter indicates that the service failed.
 1812 **ErrorInfo**
 1813 This parameter contains the error information. Permitted values:
 1814 STATE_CONFLICT (service unavailable within current state)
 1815 PARAMETER_CONFLICT (consistency of parameter set violated)
 1816

1817 **5.5.2.11 PL_SetHopTable (W-Master)**

1818 The PL_SetHopTable service is used to set the new hopping table in W-Master PL track.
 1819 The parameters of the service primitives are listed in Table 16.
 1820
 1821

Table 16 PL_SetHopTable

Parameter Name	.req	.cnf
Argument	M	
Track_N	M	
UpdateType	M	
Index	M	
Data		
Result (+)		S
Result (-)		S
ErrorInfo		M

1822 **Argument**

1823 The service-specific parameters are transmitted in the argument.
 1824 Parameter Type: Record
 1825 **Track_N:** This parameter contains the track number of which to set the hopping table values. Used
 1826 to set the hopping table values for any track, see clause 5.4.2.
 1827 Permitted values: 0-4
 1828 **UpdateType:** This parameter contains the type of update, for the usage of UpdateType, Index and
 1829 data see 18.4. Permitted values:
 1830 FULL_TABLE
 1831 DELETE_CELL
 1832 ADD_CELL
 1833 REPLACE_CELL
 1834 **Index:** This parameter contains the index of the changed cell in the hopping table. Permitted
 1835 values: 0, 1-78
 1836 **Data:** This parameter contains the value/s to replace/add.

1837 **Result (+):**

1838 This selection parameter indicates that the service has been executed successfully.

1839 **Result (-):**

1840 This selection parameter indicates that the service failed.
 1841 **ErrorInfo**
 1842 This parameter contains the error information. Permitted values:
 1843 STATE_CONFLICT (service unavailable within current state)
 1844 PARAMETER_CONFLICT (consistency of parameter set violated)
 1845

PL_SetWakeUpTime (W-Master)

The PL_SetWakeUpTime service is used to set a countdown in the PL with the value WakeUpTime. The parameters of the service primitives are listed in Table 17.

Table 17 PL_SetWakeUpTime

Parameter Name	.req	.cnf
Argument	M	
WakeUpTime	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument:

The service-specific parameters are transmitted in the argument.

WakeUpTime: contains the WakeUpTime in W-Sub-cycles to set in PL.
Permitted values: 0 to 16777215 (3 Octets).

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:
STATE_CONFLICT (service unavailable within current state)
PARAMETER_CONFLICT (consistency of parameter set violated)

5.5.2.12 PL_WakeUpTime (W-Master)

The PL_WakeUpTime service indicates the current WakeUpTime from the PL. The AHT handler sends the WakeUpTime to the corresponding W-Device via ISDU. The parameters of the service primitives are listed in Table 18.

Table 18 PL_WakeUpTime

Parameter Name	.ind	.rsp
Argument	M	
WakeUpTime	M	
Slot_N	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument:

The service-specific parameters are transmitted in the argument.

WakeUpTime: contains the WakeUpTime in W-Sub-cycles to set to the W-Device.
Permitted values: 0 to 16777215 (3 Bytes).

Slot_N: This parameter indicates the selected Slot_N with its corresponding W-Device.
Permitted values: 0 to 7.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:
STATE_CONFLICT (service unavailable within current state)
PARAMETER_CONFLICT (consistency of parameter set violated)

5.5.2.13 PL_AHTStatus (W-Master)

The PL_AHTStatus service is used to indicate to the AHT handler the status of hopping table update, see 9.2.3.2.4. The parameters of the service primitives are listed in Table 19.

Table 19 PL_AHTStatus

Parameter Name	.ind	.rsp
Argument	M	
Status	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument:

The service-specific parameters are transmitted in the argument.

- Status:** contains the update status. Permitted values:
 JUMP_SUCCESS (Update completed successfully)
 WAKE_UP_ABORT (low energy W-Device did not wake up)
 JUMP_FAIL (W-Device did not acknowledge JUMP command)
 STOP (PL track has stopped)

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

- This parameter contains the error information. Permitted values:
 STATE_CONFLICT (service unavailable within current state)
 PARAMETER_CONFLICT (consistency of parameter set violated)

5.5.2.14 PL_CmdTrig (W-Master)

The PL_CmdTrig service is used to communicate real time actions to the PL from the command handler, see 18.4. The parameters of the service primitives are listed in Table 20.

Table 20 PL_CmdTrig

Parameter Name	.req	.cnf
Argument	M	
Command	M	
Result (+)		S
WakeUpTime		S
JumpAction		S
Result (-)		S
ErrorInfo		M

Argument:

The service-specific parameters are transmitted in the argument.

- Command:** contains the action to perform in PL. Permitted values:
 WAKE_UP_TIME (triggers the PL to deliver the current WakeUpCountdown value)
 W_DEVICE_AWAKE (indicates low energy W-Device sent IMA at WakeUpTime)
 W_DEVICE_NOT_AWAKE (indicates low energy W-Device did not send IMA)
 JUMP (switch to new hopping table HT02, starting with Hop-1 frequency)
 JUMP_FAIL (W-Device did not acknowledge JUMP command)

Result (+):

This selection parameter indicates that the service has been executed successfully.

WakeUpTime: WakeUpTime value of the corresponding low energy W-Device in W-Sub-cycles, received for WAKE_UP_TIME command.
 Permitted values: 0 to 16777215 (3 Octets).
JumpAction: informs the command handler if low power W-Devices are awake and which action to invoke, received for W_DEVICE_AWAKE/NOT_AWAKE command.
 Permitted values:
 JUMP (all low energy W-Devices are awake)
 WAKE_UP_ABORT (a low energy W-Device did not wake up)

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:
 STATE_CONFLICT (service unavailable within current state)
 PARAMETER_CONFLICT (consistency of parameter set violated)

5.5.3 PL Services for W-Device

Subsequently, the services are specified which are provided by the PL to System Management and to the Data Link Layer (see Figure 23Figure 59 for a complete overview of all the services). Table 21 lists the assignments of W-Device to their roles as initiator or receiver for the individual PL services.

Table 21 PL Service assignments of W-Device

Service name	W-Device
PL_SetMode	R
PL_Pairing	I / R
PL_State	I
PL_Transfer	I / R
PL_QualityService	R
PL_SetHopTable	R
PL_SetWakeUpTime	R
PL_CmdTrig	R
Key (see 3.3.5) I Initiator of service R Receiver (Responder) of service	




Figure 44 Physical Layer services of the W-Device

5.5.3.1 PL_SetMode (W-Device)

The PL-SetMode service is used to setup the radio characteristics and configurations for startup of the Physical Layer.

This service can also be called during runtime (State \neq Idle_0) to change the following parameters only: DownlinkType, TxPower and MaxRetry. The parameter "TargetMode: STOP" can also be called during runtime to deactivate radio. All other parameters shall be ignored during runtime. The parameters of the service primitives are listed in Table 22.

Table 22 PL_SetMode (W-Device)

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

This parameter contains the configured identification parameter for the W-Device's PHY and MAC Layer.

ParameterList

Parameter Type: Record

Record Elements:

TargetMode: This parameter indicates the requested operational mode of the radio (see Table 23)

Permitted values: STOP, START

UniqueID: This parameter contains the UniqueID of the W-Device (see Figure 156)

SlotType: Type of the W-Device in Uplink given through W-Device application. Permitted values: SSLOT, DSLOT (see Table 161)

DownlinkType: Type of the W-Device in Downlink given through W-Device application.

Permitted values: PRE_DOWNLINK, FULL_DOWNLINK (see Table 23)

TxPower: Permitted values: 1 to 31 (See Table 176)

MaxRetry: Permitted values: Table 175.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information. Permitted values:

STATE_CONFLICT (service unavailable within current state)

PARAMETER_CONFLICT (consistency of parameter set violated)

1981 Table 23 specifies the coding of the different Parameters
 1982
 1983

Table 23 PL_SetMode coding of Parameters

Parameters	Definition
STOP	Communication disabled, radio turned off
START	Start radio in Cyclic Mode. W-Device is or can be paired to a W-Master permanently or temporarily (Method shall be selected by W-Master)
PRE_DOWNLINK	W-Device is listening for a pre-downlink (reduced receive-on time for low energy devices) only when connected
FULL_DOWNLINK	W-Device is listening for a full-downlink when connected
SSLOT	W-Device send its uplink in SSLOT format (see Figure 144 Regular SSLOT Uplink Packet)
DSLOT	W-Device send its uplink in DSLOT format (see Figure 145 Regular DSLOT Uplink Packet)

1984
 1985 **5.5.3.2 PL_Pairing (W-Device)**

1986 This service is used to pair / unpair a W-Device from its W-Master via system management or by
 1987 MasterCommand. The parameters of the service primitives are listed in Table 24.
 1988
 1989

Table 24 PL_Pairing (W-Device)

Parameter Name	.req	.ind	.cnf
Argument	M	M	
Method	M		
Info		M	
Result (+)			S
Result (-)			S
ErrorInfo			M

1990 **Argument**

1991 The service-specific parameters are transmitted in the argument.
 1992

1993 **Method**

1994 This parameter indicates the selected pairing mode.

1995 Permitted values: PAIRING_BUTTON, UNPAIRING.

1996 **Info**

1997 Permitted values:

1998 TIMEOUT (W-Device got no pairing request by W-Master within the time given in Timeout) see Table 186.

1999 PERMANENT (W-Device has been paired permanently)

2000 TEMPORARY (W-Device has been paired temporary (roaming))

2001 **Result (+):**

2002 This selection parameter indicates that the service has been executed successfully.

2003 **Result (-):**

2004 This selection parameter indicates that the service failed.

2005 **ErrorInfo**

2006 This parameter contains the error information.

2007 Permitted values:

2008 STATE_CONFLICT (service unavailable within current state)
 2009

5.5.3.3 PL_State (W-Device)

The PL_State service is used to indicate the pairing states of the physical layer after its startup or signals the state of a running or lost connection. The parameters of the service primitives are listed in Table 25.

Table 25 PL_State (W-Device)

Parameter Name	.ind
Argument	M
PLInfo	M

Argument

The service-specific parameters are transmitted in the argument.

PLInfo:

This parameter contains the status Information of the Physical Layer

Permitted values:

UNPAIRED	W-Device is unpaired
PAIRED	W-Device is paired
SYNCED	W-Device is synchronized with its W-Master
COMLOST	W-Device has no or lost connection to its W-Master

5.5.3.4 PL_Transfer (W-Device)

The PL-Transfer service is used to exchange the data between Data Link Layer and Physical Layer. The generation of the ACK-Bits for the W-Device is handled in PL (see clause 13.6). The parameters of the service primitives are listed in Table 26.

Table 26 PL_Transfer (W-Device)

Parameter Name	.req	.ind
Argument	C	M
Data	M	M
DataLength	M	M
Acknowledge		M
Result (+)		
Result (-)		
ErrorInfo		

Argument

The service-specific parameters of the service request are transmitted in the argument.

Data

This parameter contains the data which is transferred from / to the PL (air interface).

DataLength

This parameter contains the length of transmitted data, dependent on the direction and uplink type.

Ranges: PL_Transfer.ind: 0 to 37 octets (data from W-Master to W-Device)
 PL_Transfer.req: 0 to 2 octets (data from W-Device to W-Master, SSlot-Format)
 PL_Transfer.req: 0 to 15 octets (data from W-Device to W-Master, DSlot-Format)
 PL_Transfer.req with DataLength = 0 causes the PL to send an IMA-Uplink.

Acknowledge

2048 This parameter indicates, whether the last ULink has been confirmed by W-Master or not. PD
 2049 handler, Event handler and OD handler needs the Acknowledge from PL to decide if a retransmit
 2050 of data is needed or not.

2051 **Result (+):**

2052 This selection parameter indicates that the service request has been executed successfully.

2053 **Result (-):**

2054 This parameter contains supplementary information on the transfer status.

2055 **ErrorInfo**

2056 This parameter contains the error information.

2057 Permitted values:

2058 STATE_CONFLICT (service unavailable within current state)
 2059

2060 **5.5.3.5 PL_QualityService (W-Device)**

2061 The PL_QualityService is used to request the actual quality of the wireless connection from PL. The Service
 2062 response with the link quality in percent of the W-Device (calculation see 5.4.6).

2063 The parameters of the service are listed in Table 27
 2064
 2065

Table 27 PL_QualityService (W-Device)

Parameter Name	.req	.cnf
Argument <none>	C	
Result (+) Data		S M
Result (-) ErrorInfo		S M

2066 **Argument**

2067 This service has no parameter for PL.

2068 **Result (+):**

2069 This selection parameter indicates that the service has been executed successfully.

2070 **Data**

2071 Parameter type: Octet

2072 Permitted Value: 0 to 100%.
 2073

2074 **Result (-):**

2075 This selection parameter indicates that the service failed.

2076 **ErrorInfo**

2077 This parameter contains the error information.

2078 Permitted values:

2079 STATE_CONFLICT (service unavailable within current state)
 2080

2081 **5.5.3.6 PL_SetHopTable (W-Device)**

2082 The PL_SetHopTable service is used to set the new hopping table in W-Device PL.

2083 The parameters of the service primitives are listed in Table 28.
 2084

2085

Table 28 PL_SetHopTable

Parameter Name	.req	.cnf
Argument	M	
UpdateType	M	
Index	M	
Data	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

2086

Argument

2087

The service-specific parameters are transmitted in the argument.

2088

Parameter Type: Record

2089

UpdateType: This parameter contains the type of update, for the usage of UpdateType, Index and data See 18.4. Permitted values:

2091

FULL_TABLE

2092

DELETE_CELL

2093

ADD_CELL

2094

REPLACE_CELL

2095

Index: This parameter contains the index of the changed cell in the hopping table.

2096

Permitted values: 0, 1-78

2097

Data: This parameter contains the value/s to replace/add.

2098

Result (+):

2099

This selection parameter indicates that the service has been executed successfully.

2100

Result (-):

2101

This selection parameter indicates that the service failed.

2102

ErrorInfo

2103

This parameter contains the error information. Permitted values:

2104

STATE_CONFLICT (service unavailable within current state)

2105

PARAMETER_CONFLICT (consistency of parameter set violated)

2106

2107

5.5.3.7 PL_SetWakeUpTime (W-Device)

2108

The PL_SetWakeUpTime service is used to deliver the WakeUpTime of low energy W-Device from the AHT handler to the PL. The parameters of the service primitives are listed in Table 29.

2109

2110

2111

Table 29 PL_SetWakeUpTime

Parameter Name	.req	.cnf
Argument	M	
WakeUpTime	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

2112

Argument:

2113

The service-specific parameters are transmitted in the argument.

2114

WakeUpTime: contains the WakeUpTime in W-Sub-cycles to set in PL.

2115

Permitted values: 0 to 16777215 (3 Octets).

2116

Result (+):

2117

This selection parameter indicates that the service has been executed successfully.

2118

Result (-):

2119

This selection parameter indicates that the service failed.

2120

ErrorInfo

2121

This parameter contains the error information. Permitted values:

2122

STATE_CONFLICT (service unavailable within current state)

2123 PARAMETER_CONFLICT (consistency of parameter set violated)

2124

2125 5.5.3.8 PL_CmdTrig (W-Device)

2126 The PL_CmdTrig service is used to communicate real time actions in PL triggered by Command handler.
2127 PL_CmdTrig delivers the WakeUpTime value. The parameters of the service primitives are listed in Table
2128 30.

2129

2130

Table 30 PL_CmdTrig

Parameter Name	.req	.cnf
Argument	M	
Command	M	
Result (+)		S
WakeUpTime		S
Result (-)		S
ErrorInfo		M

2131

Argument:

2132

The service-specific parameters are transmitted in the argument.

2133

Command: contains the action to perform in PL. Permitted values:

2134

WAKE_UP_TIME (triggers the PL to deliver the WakeUpTime to Cmd handler)

2135

JUMP (switch to new hopping table HT02, starting with Hop-1 frequency)

2136

Result (+):

2137

This selection parameter indicates that the service has been executed successfully.

2138

WakeUpTime: WakeUpTime value received from the W-Master in W-Sub-cycles.

2139

Permitted values: 0 to 16777215 (3 Octets).

2140

Result (-):

2141

This selection parameter indicates that the service failed.

2142

ErrorInfo

2143

This parameter contains the error information. Permitted values:

2144

STATE_CONFLICT (service unavailable within current state)

2145


PARAMETER_CONFLICT (consistency of parameter set violated)

2146

2147

2148 **5.6 Physical Layer PL protocol**
 2149 **5.6.1 Usage of the Configuration Channel**

2150 The Configuration channel is available only when one track is configured to ServiceMode. Only in this mode,
 2151 scan, pairing and roaming activities are possible. The following figures are based on the method where
 2152 every 5th W-Sub-cycle is substituted with a configuration message on the configuration hopping frequencies. All
 2153 other W-Frames are transmitted on the regular frequency channels from the frequency hopping table.
 2154



2155
2156

Figure 45 Usage of the Configuration Channels

5.6.1.1 Retry handling during ServiceMode (Scan, Pairing, Roaming)

Figure 46 describes the retry handling for all ServiceModes between W-Master and W-Device. If a DLink or a ULink was lost, the Data shall be retransmitted. The maximal number of all retransmissions within a service request is given by the timeout of the corresponding service (see Table 186).




Figure 46 Retry handling during ServiceMode

5.6.1.2 Configuration sequence for Scan

Figure 47 describes the sequence for a discovery procedure. The W-Master sends a Scan Request Downlink (see Figure 134) on each configuration W-Sub-cycle with a continuously incremented request number (RequestN).

If an unpaired W-Device receives the Scan Request, it shall respond with a Scan Response Uplink (see Figure 148) after X W-Sub-cycles. The number of W-Sub-cycles to wait shall be calculated as described in Equation 4

$$X = \text{RequestN} + \text{FrameN}$$

Equation 4 Calculation of the number of W-Sub-cycles

where FrameN is the number of W-Sub-cycles between the first received Scan request and the following Scan Response. The Frame number is calculated with Equation 5

$$\text{Frame}_N = \left(\sum_{i=1}^9 \text{UniqueID}(i) \right) \text{mod}(30)$$

Equation 5 Frame number calculation using a UniqueID of the W-Device

2184
2185
2186
2187


A W-Device shall, irrespective to its Slot Type, respond always as a DSlot in an even Slot. The slot number the W-Device shall use, has to be calculated according to Equation 6.

2188

$$Slot_N = 2 \cdot \left(\sum_{i=1}^9 UniqueID(i) \right) \text{mod}(4)$$

2189
2190
2191
2192
2193

Equation 6 Slot number calculation using the UniqueID.



2194
2195
2196
2197
2198
2199

Figure 47 Configuration sequence for Scan

Note:
A W-Device shall not reply twice on Scan Requests of the same W-Master within the same SCAN_TIMEOUT interval.

5.6.1.3 Configuration sequence for pairing by UniqueID

Figure 48 describes the sequence for pairing by UniqueID. W-Master sends ConnectionParameter via

- Pairing Request Downlink (Roaming Flag = 0), see Figure 141
- Negotiation 1 Request Downlink, see Figure 142.
- Negotiation 2 Request Downlink, see Figure 143.

Unpaired W-Device receives the pairing request and if the requested UniqueID is identical to the W-Device UniqueID, shall reply with Response ULinks according to this sequence:

- Pairing Response Uplink, see Figure 149
- Negotiation Response Uplink 1 and 2, see Pairing Negotiation Uplink Packet Figure 150




Figure 48 Configuration sequence for pairing by UniqueID

5.6.1.4 Configuration sequence for pairing by Button

Figure 49 describes the sequence for pairing by Button. If pairing by Button is active the W-Master sends ConnectionParameter via:

- Pairing Request Downlink, see Figure 141.
- Negotiation 1 Request Downlink, see Figure 142.
- Negotiation 2 Request Downlink, see Figure 143.

If the unpaired W-Device has been activated by the pairing button and it receives a pairing request, then the W-Device responds with Uplinks according to this sequence:

- Pairing Response Uplink, see Figure 149,
- Negotiation Response Uplink 1 and 2, see Pairing Negotiation Uplink Packet Figure 150




Figure 49 Configuration sequence for pairing by Button

5.6.1.5 Message Sequence Chart for Roaming

Figure 50 describes the “Handover Connect” sequence for a temporary connection in Roaming Mode. A W-Master track in Roaming Mode shall regularly scan for unpaired W-Devices (see 5.6.1.2 Configuration sequence for Scan). If an unpaired W-Device shall be temporarily paired in Roaming Mode, the W-Master executes a Pairing by UniqueID (see 5.6.1.3., Configuration sequence for pairing by UniqueID) with Roaming Flag = 1 (Pairing Request Downlink, see Figure 141).





Figure 50 Message Sequence Chart for Roaming

2242 **5.6.2 PL W-Master state machine**


2243 **Figure 51** shows the main state machine of the W-Master Physical Layer. This state machine describes
2244 initialization and starting of the Physical Layer. The sub state machines *CyclicMode_2* and *RoamingMode_3*
2245 (Figure 52) handles operation of the Physical Layer in Cyclic and Roaming modes. The only operational
2246 difference between the sub state machines is the usage of the scanning mode (Sub State machine
2247 *Mode_Scan_12*) in permanent (Roaming) and “on request” (Cyclic) manner.



2248
2249

Figure 51 PL W-Master state machine

2250




2251
2252

Figure 52 Submachine of CyclicMode_2 or RoamingMode_3 of W-Master physical layer

2253
2254
2255
2256
2257
2258

5.6.2.1 Submachine of Handle_Sub_Cycle_4 of Master physical layer

The Handle_Sub_Cycle_4 sub state machine handles timing control within each sub cycle, transmission of the downlink, reception of the uplinks and handling of the IMA (I'm Alive) timeouts for all configured devices. This state machine triggers the Scan if the activation is requested by the PL_SetMode.req service or in case the W-Master Track is set in to roaming mode. It triggers also pairing if the Pairing.req service invoked.




2259
2260

Figure 53 Submachine of Handle_Sub_Cycle_4 of W-Master physical layer

2261 **5.6.2.2 Submachine for Mode_Scan_12**

2262 The Mode_Scan_12 (Figure 54) sub state machine handles transmission of the scan request telegrams to
 2263 all not configured devices and collects the scan responses.
 2264
 2265



2266 **Figure 54 Submachine for Mode_Scan_12**
 2267

2268 **5.6.2.3 Submachine for Mode_Pairing_15**

2269 The Mode_Pairing_15 (Figure 55) sub state machine handles the pairing procedure of the unpaired W-
 2270 Devices. The pairing itself is divided into three steps, the pairing request, and two pairing negotiation steps.
 2271




Figure 55 Submachine for Mode_Pairing_15

Table 31 State transition table of the W-Master physical layer

STATE NAME	STATE DESCRIPTION
Idle_0	Waiting for activation by SM_SetTrackConfig via PL_SetTrackConfig service.
SetupRadio_1	Initialisation and setup of the radio transceiver (Track) for radio operation as specified in 5.1 to 5.4 and 18.2 Annex G (HoppingTable) Set up the slot configuration for the slot given in Slot_N via service PL_SetSlotConfig: UniqueID: the UniqueID of the W-Device which will be connected to this SSlot or DSlot. Slot_N: points to the timing slot within the TDMA slot assignment (See Figure 39 Format of a W-Sub-cycle with DSlots and Figure 40 Slots and DSlots). SlotType: indicates the length of ULink (See Figure 144 "Regular SSlot Uplink Packet" and Figure 145 "Regular D-Slot Uplink packet"). IMATime: contains the I am alive time (see clause 14.3.5) to detect COMLOST.

STATE NAME	STATE DESCRIPTION
CyclicMode_2	Cyclic W-Frame exchange between W-Master and W-Devices in CyclicMode: The state performs the creation of the W-Frames, starting with the transmission of DLink and the handling of ULinks. After each W-Frame (all ULinks processed) this state changes the radio frequency to the next frequency specified by the frequency hopping table.
RoamingMode_3	Cyclic W-Frame exchange between W-Master and W-Devices in RoamingMode: Perform the creation of each W-Frame, starting with the transmission of DLink and the reception of ULinks. After each W-Frame (all ULinks processed) this state changes the radio frequency to the next frequency given by the frequency hopping table. At every 5th W-Sub-cycle, the frequency given by the hopping table is overwritten by one of the configuration frequencies in an alternating sequence. Note: Due to the Scan Request Downlinks every 5th W-Sub-cycle, the cyclic data channel availability at a cycle time of 5 ms might be affected. Therefore, it is recommended to use W-Devices with a W-Cycle of minimum 10 ms within a roaming track.
SM: Handle_SubCycle_4	This Submachine cyclically transmits the W-Frames (DLink payload and processing of all ULinks). It is used by State „CyclicMode_2“ and „RoamingMode_3“, dependent on PL_SetMode(Cyclic or Roaming), see T3 and T4. Furthermore, this state generates a trigger to handle every 5th Frame for the Modes SCAN, PAIRING and ROAMING, selected by service PL_SetMode in state „Start_next_Frame_5“.
SM: Start_next_Frame_5	This state loads the data from MH (reported via service PL_Transfer) to the payload data of the DLink (see Figure 139 Regular DLink). If MH has no data to send (PL_Transfer hasn't be called), set the payload data to 0 (DLink without data). Get the next frequency which shall be used for the following DLink from the frequency table.
SM: SubCycle_Count_6	This state is used to trigger every 5th W-Frame for the Modes SCAN, PAIRING and ROAMING.
SM: SendDownlink_7	Sending of the Regular Downlink over the air on the frequency selected in state „Start_next_Frame_5“.
SM:Check_W-Device_Configured_8	This state checks, if the actual Slot (W-Device) is configured.
SM: WaitULink_9	Waiting for the reception of the actual Uplink until the Uplink has been received or the Timer T_{ULink} exceeds (See Figure 144 and Figure 145 Regular ULink). Note: The CRC 32 of a regular ULink is XOR-ed by W-Device with the last 4 octets of the W-Device's U-ID (see 13.7 Final XOR of a regular ULink).
SM: Check_IMA_10	This state handles the IMA supervision for the actual Slot, since the W-Device is synchronized but Uplink has not been received.
SM: Check_Mode_11	This state is called every 5th W-Sub-cycle for the Modes SCAN, PAIRING and ROAMING to select the DLink which shall be sent on a configuration frequency.
SM: Mode_Scan_12	This submachine handles the DLink and ULinks for SCAN mode.
SM: SendScanRequest_13	This state handles the generation of the Scan Request Downlink (See 13.3.1 Scan Downlink)
SM: WaitOnResponse_14	This state handles the reception of the Scan response Uplinks (up to four Scan response uplinks are possible, see 13.5.2. Scan Response Uplink)
SM: Mode_Pairing_15	This substate machine handles the Pairing mode.
SM: Check_Pair_State_16	This state handles the generation of the next Pairing downlink depending on the Pairing „STATE“

STATE NAME	STATE DESCRIPTION
SM: SendPairRequest_17	This state handles the transmission of the Pairing Request Downlink (see 13.3.2. Pairing Request Downlink). If STATE = REQUEST_BUTTON, use „Pairing by Button“ DLink, see Figure 141. Pairing by Button If STATE = REQUEST_U-ID, use „Pairing by UniqueID“ DLink, see Figure 141.
SM: SendNegotiation1_Request_18	This state handles the transmission of the Pairing Negotiation 1 Downlink (see Figure 142. Negotiation 1 Downlink)
SM: SendNegotiation2_Request_19	This state handles the transmission of the Pairing Negotiation 2 Downlink (See Figure 143. Negotiation 2 Downlink)
SM: WaitOnPairResponse_20	This state handles the reception of the Pairing response Uplink.

2275

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<p>Activation of PL by System Management via <i>PL_SetTrackConfig</i>. Calculate the frequency hopping table dependent on the parameters MasterID, BlackList and Track_N (see 18.2.: Creation of frequency hopping table HT01 with care to blacklisting). Setting the internal variable TrackSync = MASTER or SLAVE (see 5.5.2.1 <i>PL_SetTrackConfig</i>)</p> <p><i>Note:</i> MASTER: Generates the synchronization hardware signal (HWTRIG) (output) for slave tracks for synchronization. SLAVE: The Track shall use the (input) synchronization hardware signal to send the DLinks, see T13 and T14.</p>
T2	1	1	<p>Activation by System Management through <i>PL_SetSlotConfig(ParameterList)</i>. <i>PL_SetSlotConfig</i> prepares the corresponding Slot “_X” given in Slotnumber (Slot_N) for a proper connection in the following way:</p> <p>Slot_N: Points to the receive time within the TDMA slot assignment (See Figure 39.: Format of a W-Sub-cycle with DSlots and Figure 40 Slots and DSlots)</p> <p>UniqueID: The last 4 octets of the UniqueID (Device Distinguishing ID) is used as final XOR of the CRC32 checksum (see 13.7.: Final XOR of a regular ULink)</p> <p>SlotType: Defines the length of the ULink (see Figure 37 Uplink- SSlot and Figure 38 Uplink- DSlot) to setup the transceiver receive length.</p> <p>IMATime: Defines the number of W-Sub-cycles to observe the presence of the W-Device (see clause 14.3.5 for encoding). Set SlotCfg_X = OK.</p> <p><i>Note: PL_SetMode shall return PARAMETER_CONFLICT if the SlotType is DSlot and Slot_N not even.</i></p>
T3	1	2	<p>Activation by System Management through <i>PL_SetMode(CYCLIC)</i>. Set internal variable Mode = CYCLIC. Set CycleCount = 0. Set radio Tx power for the transceiver. Start Timer $T_{DLinkStart}$ with the value of M_SWITCH_TX_RX (208 μs), see Table 1</p>
T4	1	3	<p>Activation by System Management through <i>PL_SetMode(ROAMING)</i>. Set internal variable Mode = ROAMING. Set CycleCount = 0. Set radio Tx power for the transceiver. Start Timer $T_{DLinkStart}$ with the value of M_SWITCH_TX_RX (208 μs), see Table 1.</p>
T5	2	1	<p>Stop the transmission of DLinks and reset the W-Track transceiver. Radio operation is deactivated after this command. Invoke <i>PL_AHTStatus(STOP)</i></p>
T6	3	1	See T5.
T7	5	5	See T2.
T8	5	5	<p>Update the radio transmit buffer with payload for next DLink, delivered from MH via <i>PL_Transfer.req</i>. <i>Note:</i> If the <i>PL_Transfer.req</i> is not called from MH, set the payload to zero (dummy_DLink).</p>

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T9	5	5	<i>Unpairing is triggered by W-Port handler via Service PL_Pairing.req(UNPAIRING, Slot_N).</i> Set Bit in SlotCfg_X = NOT OK. This marks the Slot as unused. Set Bit in DeviceSynced_X = COMLOST. Invoke PL_State(DeviceSynced) to report the W-Device's states DL-mode handler.
T10	5	5	Set Mode = SCAN. This activates the handling of the DLink and ULinks every 5th Frame (see T26). Start timer T _{T-Scan} with the value SCAN_TIMEOUT.
T11	5	5	Set Mode = PAIRING. This activates the handling of DLink and ULinks every 5th Frame (see T26). Set PairingEnd_X = NO. Set STATE = REQUEST_BUTTON or REQUEST_U-ID, dependent on the parameter PL_Pairing(Method). Start timer T _{T-Pairing} with the value PAIRING_UNIQUE_TIMEOUT or PAIRING_BUTTON_TIMEOUT, dependent on the parameter given via PL_Pairing(Method, Timeout).
T12	5	0	See T5.
T13	5	6	<i>The HW-Track is configured as SyncSlave.</i> Start next W-Sub-cycle on rising edge of external trigger HWTRIG from the master Track. If WakeUpCountdown higher than 0, decrement by 1.
T14	5	6	<i>The HW-Track is configured as SyncMaster.</i> Start next W-Sub-cycle if Timer T _{DLinkStart} exceeded. Set the hardware trigger HWTRIG (output) to HIGH. If WakeUpCountdown higher than 0, decrement by 1.
T15	6	7	Increment CycleCount. Update the ACK field in the radio output buffer with Device_ACK_Cyclic (See Figure 139 W-Frame encodings)
T16	7	8	<i>Transceiver has sent DLink.</i> Start Timer T _{ULinksEnd} with the value of M_RX_Uplink. If the Timer exceeds, all ULinks have been processed and the W-Frame ends. Set Device_ACK_Cyclic= 0.
T17	8	9	<i>This Slot (_X) is configured, if the Unique-ID is <> 0. Set up the Radio to receive the Slot and detect a possible Slot timeout:</i> Switch the transceiver to RX to receive this configured ULink. For the slot timeout detection start timer T _{ULink} on dependence of the SlotType (see Table 1 Transceiver timings): SLOT: DxTX_ULink for Slot + D_GUARD (96 T _{BIT} + 8 T _{BIT}) DSLOT: DxTX_ULink_D for DSLOT + D_GUARD (200 T _{BIT} + 8 T _{BIT}) Update CRC32 final XOR with Device Distinguishing ID for this Slot (_X), see 13.7 Final XOR of a regular ULink. <i>For additional information about timing see Figure 39.: SSlots and DSLOTS.</i>
T18	8	8	<i>This Slot_X is not configured.</i> Increment _X to check / setup next ULink. Note: A Slot is not configured, if it's unique ID = 0
T19	8	5	<i>WFrameComplete since timer T_{ULinksEnd} exceeded.</i> Start Timer T _{DLinkStart} with the value of M_SWITCH_TX_RX (208 μs), see Table 1 Transceiver timings. Invoke PL_Transfer.ind(WFrameComplete = YES). If TrackSync = MASTER set the hardware trigger HWTRIG (output) to LOW.
T20	9	8	Increment ULink Slot (_X)

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T21	9	8	<p>First ULink of Slot_X (W-Device_X) received. Set W-Device as synchronized:</p> <p>Set DeviceSynced_X = SYNCED. Set Device_ACK_Cyclic_X = 1 Invoke PL_State.ind(DeviceSynced). Invoke PL_Transfer.ind(ULinkType = IMA, Slot_N = _X, Ack/Nack, WFrameComplete = NO). Set IMATimeActual_X = 0. Increment ULink Slot (_X) To complete a pairing request in case of retransmits during pairing: If PairingEnd_X = NO, set PairingEnd_X = YES and set Mode = CYCLIC or ROAMING (dependent on previous track mode)</p>
T22	9	10	<p>No ULink has been received in the given time of timer T_{ULink}.</p> <p>Invoke PL_Transfer.ind(ULinkType = NOUPLINK, Slot_N = _X, NACK, WFrameComplete = NO). Increment ULink Slot (_X)</p>
T23	9	8	<p>ULink has been received.</p> <p>Set Device_ACK_Cyclic_X = 1, Set IMATimeActual_X = 0. Increment ULink Slot (_X).</p> <p>If the W-Device has sent data (see 13.4. Regular ULink Frame Annex B): Invoke PL_Transfer.ind(Data, DataLength, ULinkType = DATA, Slot_N = _X, Ack/Nack, WFrameComplete = NO) If the W-Device has sent a IMA-Frame (see Figure 146 and Figure 147. IMA-Uplink Frame Annex B): Invoke PL_Transfer.ind(ULinkType = IMA, Slot_N = _X, Ack/Nack, WFrameComplete = NO).</p>
T24	10	8	Increment IMATimeActual_X for I am alive time observation.
T25	10	8	<p>IMATimeMax reached. A Latency error occurred.</p> <p>Set DeviceSynced_X = COMLOST. Report all W-Device states through an invoke of PL_State(DeviceSynced).</p>
T26	6	11	<p>5th W-Sub-cycle reached. Handle every 5th Frame for the modes Pairing, Scan and Roaming.</p> <p>Set CycleCount = 0.</p>
T27	4	0	See T5.
T28	4	11	See T26.
T29	11	12	<p>Load the "Scan Request" (see 13.3.1. Scan Request) downlink into radio output buffer and start the radio transmission. Update the ACK field in radio the output buffer with the Device_ACK_Service (See Figure 140 Scan Request).</p>
T30	12	4	See T19.
T31	11	15	-
T32	15	4	See T19.
T33	15	4	<p>WFrameComplete since timer $T_{ULinksEnd}$ exceeded.</p> <p>Start Timer $T_{DLinkStart}$ with the value of M_SWITCH_TX_RX (208µs), see Table 1 Transceiver timings. Invoke PL_Transfer.ind(WFrameComplete = YES). If TrackSync = MASTER set the hardware trigger HWTRIG (output) to LOW. Set Mode = CYCLIC or ROAMING, depending on initial track mode, see T3 / T4.</p>
T34	13	13	<p>Timer T_{T-Scan} expired, leave scan mode after this W-Sub-cycle.</p> <p>Set Mode = CYCLIC Invoke PL_ScanEnd.ind</p>

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T35	13	14	<i>Transceiver has sent the DLink.</i> Start Timer T _{ULinksEnd} with the value of M_RX_Uplink. <i>If the Timer exceeds, all ULinks have been processed and the W-Frame ends.</i> Set Device_ACK_Service_X = 0.
T36	14	14	<i>A Scan Request response uplink has been received.</i> Set Device_ACK_Service_X = 1. Invoke PL_Scan.ind(SlotType, UniqueID, Protocol VersionRevisionID). See 5.5.2.3. PL_Scan (master).
T37	14	4	See T19.
T38	16	16	<i>Timer TPairing expired.</i> Invoke PL_Pairing.ind(PAIRING_TIMEOUT). Set PairingEnd_X = YES;
T39	16	17	Load the pairing request downlink in the radio output buffer, dependent on pairing mode and send downlink: If STATE = REQUEST_BUTTON, use pairing request downlink "Pairing Request by Button", see Figure 141. If STATE = REQUEST_U_ID, use pairing request downlink "Pairing Request by UniqueID" see Figure 141. Update the ACK field in the radio output buffer with Device_ACK_Service (See Figure 141 Pairing Request by Button or Pairing Request by UniqueID).
T40	17	20	See T35.
T41	20	20	<i>Radio received MSG_UPLINK_Pair_Failed (see Table 162 Uplink-MSG-Types):</i> Set Device_ACK_Service_X = 1. Invoke PL_Pairing ind(PAIRING_WRONG_SLOTTYPE). Set PairingEnd_X = YES;
T42	20	20	<i>Radio received MSG_UPLINK_Pair_Button_Resp (see Table 162 Uplink-MSG-Types).</i> Set Device_ACK_Service_X = 1. Set STATE = NEGOTIATION_1.
T43	20	20	<i>Radio received MSG_UPLINK_Pair_Unique_Resp (see Table 162. Uplink-MSG-Types).</i> Set Device_ACK_Service_X = 1. Set STATE = NEGOTIATION_1.
T44	20	20	<i>Radio received MSG_UPLINK_Pair Neg 1_Resp (see Table 162 Uplink-MSG-Types).</i> Set Device_ACK_Service_X = 1. Set STATE = NEGOTIATION_2.
T45	20	20	<i>Radio received MSG_UPLINK_Pair Neg 2_Resp (see Table 162 Uplink-MSG-Types).</i> Set Device_ACK_Service_X = 1. Invoke PL_Pairing.ind(PAIRING_SUCCESS). Set PairingEnd_X = YES;
T46	20	4	See T19.
T47	20	4	See T33.
T48	16	18	Load the Negotiation_1 Downlink in the radio output buffer and send the Downlink (see 13.3.3 Pairing Negotiation Downlink). Update the ACK field in radio output buffer with Device_ACK_Service_X (See 13.3.3 Pairing Negotiation Downlink)
T49	18	20	See T35.
T50	16	19	Load the Negotiation_2 Downlink in the radio output buffer and send Downlink (see 13.3.3. Pairing Negotiation Downlink). Update the ACK field in radio output buffer with Device_ACK_Service_X (See 13.3.3 Pairing Negotiation Downlink)
T51	19	20	See T35.
T52	5	5	-

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T53	1	1	Calculate the frequency hopping table dependent on the parameters MasterID, BlackList and Track_N (see 18.2.: Creation of frequency hopping table HT01 with care to blacklisting). Setting the internal variable TrackSync = MASTER or SLAVE (see 5.5.2.1 PL_SetTrackConfig) Note: MASTER: Generates the synchronization hardware signal (HWTRIG) (output) for slave tracks for synchronization. SLAVE: The Track shall use the (input) synchronization hardware signal to send the DLinks, see T13 and T14.
T54	5	5	Stop Timer TPairing. Set PairingEnd_X = YES;
T55	5	5	-
T56	5	5	Activation by System Management through PL_SetHopTable. Load the new hopping table to HT02
T57	5	5	Activation by System Management through PL_SetWakeUpTime(WakeUpTime). Set internal variable WakeUpCountdown = WakeUpTime.
T58	5	5	Activation by Data Link Command Handler through PL_CmdTrig. Command: Case WAKE_UP_TIME: Invoke PL_WakeUpTime(WakeUpCountdown, Slot_N) Case W_DEVICE_AWAKE: Indicates low energy W-Device sent IMA at WakeUpTime, if all low energy W-Devices sent an IMA then return PL_CmdTrig.cnf(JUMP) Case W_DEVICE_NOT_AWAKE: Indicates low energy W-Device did not send IMA at WakeUpTime, return PL_CmdTrig.cnf(WAKE_UP_ABORT) and PL_AHTStatus(WAKE_UP_ABORT) Case JUMP: Switch to new hopping table HT02 starting with HOP-1 frequency, invoke PL_AHTStatus(JUMP_SUCCESS) Case JUMP_FAIL: Indicates a W-Device did not acknowledge JUMP command. Invoke PL_AHTStatus(JUMP_FAIL)

2276

INTERNAL ITEMS	TYPE	DEFINITION
T _{DLinkStart}	Const Time	See Table 1, M_SWITCH_TX_RX
T _{ULinksEnd}	Const Time	See Table 1, M_RX_ULink
T _{ULink}	Time	Timer to switch radio to RX and to check if an ULink has been received within the given time. The timer shall be loaded dependent on the Slot-Type: SSLOT: DxTX_ULink for SSlot + D_GUARD (96 T _{BIT} + 8 T _{BIT}) DSLOT: DxTX_ULink_D for DSlot + D_GUARD (200 T _{BIT} + 8 T _{BIT})
T _{T-Pairing}	Time	Timer is used with the values PAIRING_BUTTON_TIMEOUT or PAIRING_UNIQUE_TIMEOUT, see T10.
T _{T-Scan}	Const Time	Timer is used with the value SCAN_TIMEOUT, see T10.
Mode	Variable	This variable is used to select the different DLinks. Permitted values: CYCLIC, ROAMING, SCAN or PAIRING.
CycleCount	Variable	W-Sub-cycle Counter.
TrackSync	Variable	Defines, whether the Track is running as W-Frame synchronization master or slave

INTERNAL ITEMS	TYPE	DEFINITION
		Permitted values: MASTER or SLAVE (see 5.5.2.1 PL_SetTrackConfig).
ULinkReceived	Bool	Flag which shall be set by the radio hardware if an Uplink was received.
DLinkSent	Bool	Flag which shall be set by the radio hardware if the downlink has been sent.
PairingEnd_X	Bool	Flag which indicates if the pairing is completed. Permitted values: YES, NO.
SlotCfg_X	Bool	Flag which indicates if the corresponding slot is configured. Permitted values: YES, NO.
DeviceSynced_X	Bool	Flag which indicates if the W-Device for the corresponding slot is available / synchronized. Permitted values: SYNCED, COMLOST. See 5.5.2.7 PL_State.
IMATimeActual_X	Variable	Variable to count the number of W-Sub-cycles, if a Device is synchronized but no ULink has been received, see T24.
IMATimeMax_X	Variable	This Variable keeps the value IMATime in W-Sub-cycles (see clause 14.3.5 for encoding), delivered via the service PL_SetSlotConfig, see 5.5.2.5
Device_ACK_Cyclic_X	Variable	This Variable keeps the bit coded acknowledgement for received ULink in Cyclic Mode
Device_ACK_Service_X	Variable	This Variable keeps the bit coded acknowledgement for received ULink in ServiceMode
STATE	Variable	Variable to keep the states during pairing procedure, see Figure 55. Submachine for Mode_Pairing_15 Permitted Values: REQUEST_BUTTON, REQUEST_U_ID, NEGOTIATION1, NEGOTIATION2.
PAIRING_BUTTON_TIMEOUT	Parameter	This parameter is delivered via service PL_Pairing. See 5.5.2.6. PL_Pairing-Service and 5.6.1.1. Retry handling during Pairing Mode.
PAIRING_UNIQUE_TIMEOUT	Constant	Fixed to 3 s, see 5.6.1.1 Retry handling during Pairing Mode.
SCAN_TIMEOUT	Constant	Fixed to 5 s, see 5.6.1.1 Retry handling during Scan Mode.
WakeUpCountdown	Variable	This variable counts down to 0, starting value delivered via the service PL_SetWakeUpTime. Current value sent to AHT via PL_WakeUpTime


2277
2278

Note: X marks the variables which are individual in each Slot_N. The range of _X is 0 to 7 SlotNumbers

2279 5.6.3 PL W-Device state machine

2280 Figure 56 shows the main state machine of the W-Device Physical Layer. The state machine handles the
2281 initial initialization of the W-Device, Pairing, Unpairing and Cyclic operation. Depending on the pairing
2282 request, the W-Device is either configured as a Roaming or as a Cyclic W-Device. The main difference
2283 between two modes is the reaction on a communication Sync_lost event. In case the W-Device is configured
2284 for roaming, it goes in to the Unpaired_2 state immediately. Otherwise, it goes to the Paired_4 state and
2285 waits until W-Master comes back in range or pairing by button is activated by application layer.
2286
2287

2288



2289
2290

Figure 56 PL W-Device state machine

2291

Table 32 State transition tables of the W-Device physical layer (normal device)

STATE NAME	STATE DESCRIPTION
Idle_0	Waiting for activation via System Management through Service PL_SetMode.
CheckConfig_1	Check for availability of ConnectionParameter in non-volatile memory (see Table 140 ConnectionParameter).
Unpaired_2	Waiting for a Scan Request or a Pairing Request by UniqueID (via W-Master) or a button-press on the W-Device. The W-Device shall listen on configuration-channels (see 5.4.4) for receiving configuration downlinks via UniqueID (call by U-ID). If a W-Master Pairing Request Downlink(MSG_DLink_PAIR_UNIQUE) is received, start the timer ($T_{T-Unique}$).
Pairing_3	Waiting for Pairing Request by button from W-Master (MSG_DLink_PAIR_BUTTON). W-Device shall listen on the configuration channels (see Figure 141) to receive a configuration downlinks (call by button)
Paired_4	The W-Device has a valid ConnectionParameter setting. It shall wait on the frequency at Col_N for synchronization. When resynchronization at Col_N is not successful within an appropriate time, Col_N shall subsequently be incremented for the next synchronisation cycle. See also 17.1.5 W-Master not reachable.
Connected_5	The W-Device is connected to its paired W-Master via regular W-communication cycles (see Figure 139)
Re_pairing_6	Waiting for configuration-channels for Scan Request or Pairing Request by UniqueID (via W-Master).

2292

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>Activation by System Management through PL_SetMode.req(Start). (see Table 120 Transition T1).</i>
T2	1	2	The Device Radio has no valid ConnectionParameter settings stored (see Table 140) Invoke PL_State.ind(UNPAIRED)
T3	2	3	<i>The W-Device's pairing (by button) state is entered via service PL_Pairing.req(PAIRING_BUTTON) through SM_SetDeviceMode(PAIRING_BUTTON).</i> Start timer (T _{T-Button}).
T4	3	2	Invoke PL_Pairing.ind(TIMEOUT) (see Table 186) if timer (T _{T-Button}) expired.
T5	3	4	<i>Pairing by Button sequence was successfully executed. (See Figure 49 Configuration sequence for pairing by Button)</i> Valid ConnectionParameter were successfully received. Store ConnectionParameter in non-volatile memory. Invoke PL_Pairing.ind(PERMANENT) to report a successful pairing. Set SyncCounter to 0. Set received DataSyncword (see clause 5.2.4). Stop timer (T _{T-Button}).
T6	2	4	<i>Pairing by UniqueID sequence was successfully executed. (See Figure 48 Configuration sequence for pairing by UniqueID)</i> Valid ConnectionParameter were successfully received. Store ConnectionParameter in non-volatile memory. Invoke PL_Pairing.ind(PERMANENT) to report a successful pairing. Set SyncCounter to 0. Set received DataSyncword (see Table 161).
T7	2	4	<i>Pairing by UniqueID sequence was successfully executed. (See Figure 50 Message Sequence Chart for Roaming / temporary connection)</i> Valid ConnectionParameter were successfully received. Store ConnectionParameter in volatile memory only. Invoke PL_Pairing.ind(TEMPORARY) to report a successful pairing. Set SyncCounter to 0 Set received DataSyncword (see Table 161).
T8	4	4	Send IMA ULink to the W-Master on each received DLink (e.g. see Figure 48 Configuration sequence for pairing by UniqueID / Start of synchronization) If the DLink has been received successfully, increment SyncCounter (SyncCounter = SyncCounter+1) Otherwise set the SyncCounter to 0.
T9	4	5	<i>The connection is synchronized, if SyncCounter >= Sync.</i> Set SyncLostCounter to 0. Invoke PL_State.ind(SYNCED) service indication to report that the connection is established. Stop timer (T _{T-Unique}). Stop timer (T _{T-Button}).
T10	5	4	The synchronization is lost, if SyncLostCounter > 5 * MaxRetry. Invoke PL_State.ind(COMLOST) service indication to report that the connection has been lost. Set SyncCounter to 0.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T11	5	2	<i>Unpairing was triggered by MasterCommand via Service PL_Pairing.req(UNPAIRING).</i> Invoke PL_State.ind(COMLOST) service indication to report that the W-Device is not connected. Delete non-volatile ConnectionParameter settings (see Table 140). Set SyncCounter to 0. Set Roaming to 0.
T12	5	2	The synchronization is lost, if SyncLostCounter > 5 * MaxRetry Invoke PL_State.ind(COMLOST) service indication to report that the W-Device is not connected. Delete volatile ConnectionParameter settings (see Table 140) Set SyncCounter to 0. Set Roaming to 0.
T13	4	2	Delete non-volatile ConnectionParameter settings (see Table 140). Set SyncCounter to 0. Set Roaming to 0.
T14	4	2	See T11.
T15	4	6	<i>The W-Device's re_pairing state is entered via Service PL_Pairing.req(PAIRING_BUTTON) by SM_SetDeviceMode (PAIRING).</i> Start timer (T _{T-Button}).
T16	6	4	See T4.
T17	6	4	See T6, Stop timer (T _{T-Button}).
T18	5	5	Invoke PL_Transfer_ind to report the Frametrigger (W-Frame-Sub-cycle) to message-handler in following cases: Case 1: <i>DLink received, data for this W-Device are available (DataLength>0); see clause 5.6.3.1).</i> Set SyncLostCounter to 0. Case 2: <i>DLink received without data for this W-Device (DataLength=0, see clause 5.6.3.1).</i> Set SyncLostCounter to 0. Case 3: <i>No DLink received while W-Device is still synchronized / connected. Acknowledge=0. DataLength=0. (The Frametrigger shall be generated by timer with a time of W-Frame-Sub-cycle).</i> Increment SyncLostCounter.
T19	5	5	Update the radio transmit buffer with payload for the next ULink, delivered from MH via PL_Transfer.req. <i>Note: If the PL_Transfer.req is not called from MH, set the payload to zero (dummy ULink, see clause 5.6.3.1).</i>
T20	1	4	<i>The Radio has stored a valid ConnectionParameter settings (see Table 140).</i> Invoke PL_State.ind(PAIREd)

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T21	Any	0	Any state shall be left through a call of <i>PL_SetMode(Stop) Service via System Management.</i>
T22	5	5	Invoke <i>PL_QualityService.cnf</i>
T23	5	5	Activation by System Management through <i>PL_SetHopTable.</i> Load the new hopping table to HT02
T24	5	5	Activation by System Management through <i>PL_SetWakeUpTime.</i> Return <i>PL_CmdTrig.cnf(WakeUpTime)</i>
T25	5	5	Activation by Data Link Command Handler through <i>PL_CmdTrig.</i> Command: Case WAKE_UP_TIME: No action <i>Cmd handler is waiting for WakeUpTime via PL_CmdTrig.cnf(WakeUpTime).</i> Case JUMP: Switch to new hopping table HT02 starting with HOP-1 frequency

2293

INTERNAL ITEMS	TYPE	DEFINITION
SyncCounter	Variable	Counter for received downlink frames (see T8).
Sync	Constant	Sync = 3.
SyncLostCounter	Variable	Counter for lost downlink frames (see T9 and T16).
Roaming	Variable	This volatile Flag indicates, whether the W-Device is paired permanently or temporary (see T6, T7, T10, T12). Variable shall be initialized to 0 during initialization and is transmitted during pairing procedure.
MaxRetry	Variable	Value to generate Sync_Lost. This Variable is transmitted via service <i>DL_SetParam.</i>
WakeUpTime	variable	Value for low energy W-Device, sent to Cmd handler via <i>PL_CmdTrig.cnf()</i>
T _{T-Unique}	Time	See Table 186, definition of PAIRING_UNIQUE_TIMEOUT
T _{T-Button}	Time	See Table 186, definition of PAIRING_BUTTON_TIMEOUT

2294

2295 **5.6.3.1 DLink processing in the W-Device via PL**

2296 On the reception of each DLink, the PL shall parse the DLink payload to collect all W-Messages directed to
 2297 this addressed W-Device or any broadcast Master-Command. The collected W-Messages (ControlOctets
 2298 included) shall be sent to the DL-A message handler via Transfer.ind. If there are one or more W-Messages
 2299 for the current Device received, the PL shall generate an acknowledgement, which shall be automatically
 2300 transmitted in the following uplink. If Transfer.req was not invoked, then the payload shall be set to zero
 2301 (dummy Uplink).
 2302

6 Data Link Layer (DL-A)

The data link layers are concerned with the delivery of messages between a W-Master and a W-Device. A set of DL-services is available to the application layer (AL) for the exchange of Process Data (PD) and Event or ISDU data. Another set of DL-services is available to system management (SM) for the retrieval of Device identification parameters and the setting of state machines within the DL. The DL uses PL-Services for controlling the physical layer (PL). The DL takes care of the error detection of messages (whether internal or reported from the PL) and the appropriate remedial measures (e.g. retry). The data link layers are structured due to the nature of the data categories into Process Data handlers and Event / ISDU handlers which are in turn using a Message handler to deal with the requested transmission of messages. Each handler comprises its own state machine. The data link layer is subdivided in a DL-A section with its own internal services and a DL-B section with the external services. The DL uses additional internal administrative calls between the handlers which are defined in the "internal items" section of the associated state-transition tables.

6.1 General (W-Master)

Figure 57 shows an overview of the structure and the services of the W-Master's data link layer.





Figure 57 Structure and services of the data link layer (W-Master)

6.1.1 Track and W-Device-Mapper (TDMapper)

The track and W-Device mapper is used to assign a W-Port to a specific Track number (Track_N) and Slot number (Slot_N). Each Slot_N represents a W-Device, whereupon the W-Device communicates via this Slot to the W-Master. The Slot_N is transmitted during pairing to the selected W-Device. The configuration of the TDMapper is done by SM_SetPortConfig service (via DL_TDConfig). This mapping table enables a flexible assignment of W-Devices without changing of the W-Port, e.g. distribution of W-Devices within the tracks.

2330



2331

Figure 58 Track and W-Device-Mapper (TDMapper)


2332

6.2 General (W-Device)

2333

Figure 59 shows an overview of the structure and the services of the W-Device's data link layer.

2334



2335

Figure 59 Structure and services of the data link layer (W-Device)

2336

2337 **6.3 DL-A services**2338 **6.3.1 Overview**

2339

2340

2341

2342

2343

Table 33 lists the assignment of W-Master and W-Device to their roles as initiator (I) or receiver (R) in the context of the execution of their individual DL-A services.

Table 33 DL-A services within W-Master and W-Device

Service name	W-Master	W-Device
MCmd	R	I
ISDUMsg	R	I
DownLinkAck	I	
UplinkAck		I
EventMsg	I	R
PDOOutMsg	R	I
PDInMsg	I	R
Key (see 3.3.5) I Initiator of service R Receiver (responder) of service		

2344

2345 **6.3.2 MCmd (W-Master and W-Device)**

2346

2347

2348

2349

2350

The MCmd service provides the MasterCommand to change e.g. the W-Device STARTUP, PREOPERATE and OPERATE states. The parameters of the service primitives are listed in Table 34.

Table 34 MCmd

Parameter Name	.req	.ind
Argument	M	M
SendWMessage	M	
Slot_N	M	
Broadcast	M	
MasterCommand	C	M
Length	C	
DLType	C	

2351

2352

2353

2354

For further abbreviations and definitions of service parameters see clause 3.3.2 in REF 1.

2355

2356

2357

2358

2359

2360

2361

2362

2363

2364

2365

2366

Argument

The service-specific parameters are transmitted in the argument.

SendWMessage

This parameter signals, if a W-Message (and possible data) shall be added to the Downlink.

Permitted values:

YES (Message handler shall compile the Control Octet and add possible data to transmit)

NO (No W-Message needs to be sent)

Slot_N

This parameter contains the Slot number for the corresponding W-Device.

Permitted values: 0 to 7

Broadcast

This parameter signals, if a MasterCommand shall be received by all connected W-Devices in the Track, use is restricted according to Table 165. Permitted values:

2367 YES
 2368 NO
 2369 **MasterCommand**
 2370 This parameter contains the MasterCommand, see 14.1.1 and Table 165.
 2371 **Length**
 2372 This parameter contains the length of data to transmit. If no MasterCommand shall be sent, set Length
 2373 to 0. Permitted values: 0 or 1.
 2374 **DLType**
 2375 This parameter informs the Message handler whether the MasterCommand is transmitted in
 2376 PreDownLink (for low energy W-Devices) or FullDownLink.
 2377 Permitted values:
 2378 PreDLink (MasterCommand shall be transmitted in the PreDownLink).
 2379 FullDLink (MasterCommand shall be transmitted in the FullDownLink).
 2380

2381 **6.3.3 ISDUMsg (W-Master and W-Device)**

2382
 2383 The ISDUMsg service is used to set up the ISDU-request Data for the next message to be sent. In turn, the
 2384 confirmation of the service contains the data from the receiver. The parameters of the service primitives
 2385 are listed in Table 35
 2386

Table 35 ISDUMsg

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
SendWMessage	M			
Slot_N	M			
Data	C	C		
Length	C	M		
FlowCtrl	C	M		
Result (+)			S	S
SendWMessage			M	
Slot_N				M
Data			C	C(=)
Length			C	M
FlowCtrl			C	M
Result (-)			S	S
Slot_N				M
ErrorInfo			M	M

2387 **Argument**

2388 The service-specific parameters are transmitted in the argument.

2389 **SendWMessage**

2390 This parameter signals, if a W-Message (possibly containing data) shall be added to the Downlink.

2391 Permitted values:

2392 YES (Message handler shall compile the Control Octet and add possible data to transmit)

2393 NO (No W-Message needs to be sent)

2394 **Slot_N**

2395 This parameter contains the Slot number for the corresponding W-Device.

2396 Permitted values: 0 to 7

2397 **Data**

2398 This parameter contains the data to transmit. Data type: Octet string
 2399

2400 **Length**
 2401 This parameter contains the length of data to transmit. Permitted values: 0 to 32
 2402 **FlowCtrl**
 2403 This parameter contains the flow control value (see Table 75).
 2404 **Result (+):**
 2405 This selection parameter indicates that the service has been executed successfully.
 2406 **SendWMessage**
 2407 This parameter signals, if a W-Message (and possible data) shall be added to the Uplink.
 2408 Permitted values:
 2409 YES (Message handler shall compile the Control Octet and add possible data to transmit)
 2410 NO (No W-Message needs to be sent)
 2411 **Slot_N**
 2412 This parameter contains the Slot number for the corresponding W-Device.
 2413 Permitted values: 0 to 7
 2414 **Data**
 2415 This parameter contains the read data values.
 2416 **Length**
 2417 This parameter contains the length of the received data package. Permitted values: 0 to 32
 2418 **FlowCtrl**
 2419 This parameter contains the flow control value (see Table 75).
 2420 **Result (-):**
 2421 This selection parameter indicates that the service failed.
 2422 **Slot_N**
 2423 This parameter contains the Slot number for the corresponding W-Device.
 2424 Permitted values: 0 to 7
 2425 **ErrorInfo**
 2426 This parameter contains the error information.
 2427 Permitted values:
 2428 NO_COMM (no communication available)
 2429 STATE_CONFLICT (service unavailable within current state)

2432 6.3.4 DownLinkAck (W-Master)

2433
 2434 The service DownLinkAck is only available on the W-Master. The service triggers the appropriate handler
 2435 (PD handler, Cmd handler, EV handler, or ISDU handler) to provide their data for the next DLink. Also, this
 2436 service delivers the acknowledgement from the last ULink. With this acknowledgement, each handler has
 2437 to decide, if new data may be send in DLink, or if the last data have to be retransmitted. The parameters of
 2438 the service are listed in Table 36.
 2439
 2440

Table 36 DownLinkAck

Parameter Name	.ind
Argument	M
Slot_N	M
ComChannel	M
Length	M
PreDLSet	C
Acknowledge	M

2441 **Argument**

2442 The service-specific parameters are transmitted in the argument.

2443 **Slot_N**

2444 This parameter contains the Slot number for the corresponding W-Device.

2445 Permitted values: 0 to 7

2446 **ComChannel**

2447 This parameter indicates the selected handler.

2448 Permitted values: PDOUTHANDLER, CMDHANDLER, EVHANDLER, ISDUHANDLER.
 2449 **Length**
 2450 This parameter contains the remaining space for the next DLink.
 2451 Range: 0 to 37 Bytes
 2452 **PreDLSet**
 2453 This parameter is only used for the CMDHANDLER to support LP-Devices which indicates, if the
 2454 PreDownLink is already in use.
 2455 Permitted values:
 2456 NO (PreDownLink is empty and can be used)
 2457 YES (PreDownLink is already in use)
 2458 **Acknowledge**
 2459 This parameter indicates, whether the last uplink has been confirmed or not.
 2460 PD handler, Cmd handler, Event handler and ISDU handler shall decide if a retransmit is needed or
 2461 not.
 2462

2463 **6.3.5 UpLinkAck (W-Device)**

2464 The service UpLinkAck is only available on the W-Device. The service triggers the appropriate handler (PD
 2465 handler, EV handler, or ISDU handler) to provide data for the next Uplink message. With the Acknowledge
 2466 from the last downlink each handler has to decide, if new data have to be send, or the last data have to be
 2467 retransmitted. The parameters of the service are listed in Table 37
 2468
 2469

Table 37 UpLinkAck

Parameter Name	.ind
Argument	M
ComChannel	M
Length	M
Acknowledge	M

2470 **Argument**

2471 The service-specific parameters are transmitted in the argument.
 2472

2473 **ComChannel**

2474 This parameter indicates the selected handler.

2475 Permitted values: PDHANDLER, EVHANDLER, ISDUHANDLER.

2476 **Length**

2477 This parameter contains the remaining space for the next Uplink.

2478 Range: 0 to 15 octets

2479 **Acknowledge**

2480 This parameter indicates, whether the last uplink has been confirmed or not.

2481 PD handler, Event handler and ISDU handler shall decide if a retransmit is needed or not.
 2482

2483 **6.3.6 EventMsg (W-Master and W-Device)**

2484 The EventMsg service is used to provide events through the diagnosis communication channel.
 2485 The parameters of the service primitives are listed in Table 38.
 2486
 2487

Table 38 EventMsg

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M	M	
SendWMessage	M		M	
Slot_N		M	M	
Data	C	C		M
Length	C	M	C	M
FlowCtrl	C	M	C	M

2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518

Argument

The service-specific parameters are transmitted in the argument.

SendWMessage

This parameter signals, if a W-Message (possibly containing data) shall be added to the Downlink or Uplink.

Permitted values:

YES (Message handler shall compile the Control Octet and add possible data to transmit)

NO (No W-Message needs to be sent)

Slot_N

This parameter contains the Slot number for the corresponding W-Device.

Permitted values: 0 to 7

Data

This parameter contains the whole or segmented Event Data which contains EventQualifier and EventData.

Data type: Octet string (3 Octet)

Note: EventQualifier see A.6.4 in REF 1

EventData see Table 180

Length

This parameter contains the length of data to transmit. If no event shall be sent, set Length to 0.

Permitted values: 0 (W-Master acknowledge) or 3 (W-Device event).

FlowCtrl

This parameter contains the flow control value (see Table 75). In case of EOS (end of service), no data are delivered.

6.3.7 PDOutMsg (W-Master and W-Device)

The PDOutMsg service is used to provide the Process Data through the process communication channel from W-Master to a W-Device. This service delivers the Control Octet (CO) with PDOut data to or from the Message handler. The parameters of the service primitives are listed in Table 39.

Table 39 PDOutMsg

Parameter Name	.req	.ind	.cnf
Argument	M	M	
SendWMessage	M		
Slot_N	M		
Data	C	C	
Length	C	M	
FlowCtrl	C	M	
PDOutInvalid	C	M	
Result (+)			S
Slot_N			M
Result (-)			S
Slot_N			M
ErrorInfo			M

2519
2520
2521
2522
2523
2524
2525

Argument

The service-specific parameters are transmitted in the argument.

SendWMessage

This parameter signals, if a W-Message (and possible data) shall be added to the Downlink.

Permitted values:

YES (Message handler shall compile the Control Octet and add possible data to transmit)

2526 NO (No W-Message needs to be sent)
 2527 **Slot_N**
 2528 This parameter contains the Slot number (W-Device Address) for the corresponding W-Device.
 2529 Permitted values: 0 to 7
 2530 **Data**
 2531 This parameter contains the whole or segmented Process Data to be transferred from W-Device to W-
 2532 Master.
 2533 Data type: Octet string
 2534 **Length**
 2535 This parameter contains the length of the received output Process Data. Permitted values: 0 to 32
 2536 **FlowCtrl**
 2537 This parameter contains the flow control value (see Table 75).
 2538 **PDOInvalid**
 2539 This parameter is used to inform the Message handler to generate the “Process Data Out Invalid” via
 2540 Function Code in the DLink Control Octet
 2541 **Result (+):**
 2542 This selection parameter indicates that the service has been executed successfully.
 2543 **Slot_N**
 2544 This parameter contains the Slot number for the corresponding W-Device.
 2545 Permitted values: 0 to 7
 2546 **Result (-):**
 2547 This selection parameter indicates that the service failed.
 2548 **Slot_N**
 2549 This parameter contains the Slot number for the corresponding W-Device.
 2550 Permitted values: 0 to 7
 2551 **ErrorInfo**
 2552 This parameter contains the error information.
 2553 Permitted values:
 2554 NO_COMM (no communication available)
 2555 STATE_CONFLICT (service unavailable within current state)
 2556

2557 6.3.8 PDInMsg (W-Master and W-Device)

2558 The PDInMsg service is used to provide the Process Data to be sent through the process communication
 2559 channel from a W-Device to its W-Master.
 2560 This service delivers the Control Octet (CO) with PDIn data to or from the Message handler. The parameters
 2561 of the service primitives are listed in Table 40.
 2562
 2563

Table 40 PDInMsg

Parameter Name	.req	.ind	.cnf
Argument	M	M	
SendWMessage	M		
Slot_N		M	
Data	C	C	
Length	C	M	
FlowCtrl	C	M	
PDInInvalid	C	M	
Result (+)			S
Result (-)			S
ErrorInfo			M

2564 Argument

2565 The service-specific parameters are transmitted in the argument.
 2566

2567 **SendWMessage**
 2568 This parameter signals, if a W-Message (and possibly also data) shall be added to the Uplink.
 2569 Permitted values:
 2570 YES (Message handler shall compile the Control Octet and add possible data to transmit)
 2571 NO (No W-Message needs to be sent)
 2572 **Slot_N**
 2573 This parameter contains the Slot number (Device Address) for the corresponding W-Device.
 2574 Permitted values: 0 to 7
 2575 **Data**
 2576 This parameter contains the whole or segmented Process Data to be transferred from W-Device to W-
 2577 Master.
 2578 Data type: Octet string
 2579 **Length**
 2580 This parameter contains the length of the transmitted input Process Data. Permitted values: 0 to 32
 2581 **FlowCtrl**
 2582 This parameter contains the flow control (see Table 75).
 2583 **PDInInvalid**
 2584 This parameter is used to inform the Message handler to generate the "Process Data In Invalid"-
 2585 Function Code in ULink Control Octet
 2586 **Result (+):**
 2587 This selection parameter indicates that the service has been executed successfully.
 2588 **Result (-):**
 2589 This selection parameter indicates that the service failed.
 2590 **ErrorInfo**
 2591 This parameter contains the error information.
 2592 Permitted values:
 2593 NO_COMM (no communication available)
 2594 STATE_CONFLICT (service unavailable within current state)
 2595

2596 **6.4 Acknowledgments (DownLinkAck and UpLinkAck)**

2597 W-Devices acknowledge correct reception of the downlink message within their uplink messages. Within
 2598 the next downlink, the W-Master acknowledges correct reception of the last uplink messages to each W-
 2599 Device. In case of negative acknowledgments, both the W-Master and W-Devices use this information to
 2600 initiate transmission retries.

2601 **6.5 Message handler**

2602


2603 **6.5.1 General**

2604 The layer DL-A comprises the Message handler as shown in Figure 60, Figure 61 and Figure 62.
 2605

2606
2607
2608
2609
2610
2611
2612

6.5.2 State machine of the W-Master Message handler (DL-A)


Figure 60 shows the state machine of the W-Master Message handler. The two sub-state machines describe the order how the different W-Messages are placed in the downlink payload. The submachine Compile_PDOut (see Figure 61) handles the placement of MasterCommands and process data for all slots (0 to 7) in a first step. In a second step, the submachine Compile_Acyclic (see Figure 62) handles the placement of acyclic data for Event and ISDU.



2613
2614
2615
2616

Figure 60 State machine of the W-Master Message handler


2617



2618
2619

Figure 61 Sub-State machine `Compile_PD-Out_7` of the message handler

2620



2621
2622
2623

Figure 62 Sub-State machine Compile Acyclic 11 of the message handler

2624

Table 41 State transition tables of the W-Master Message handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by W-Master DL-mode handler through MH_Conf_ACTIVE (see Figure 65). Set RemainingLength to DLink-Payload (37 Octet).
Idle_1	Waiting for trigger PL_Transfer.ind service indication. The PL_Transfer service delivers the Slotnumber (0 up to 7) and further parameters within a W-Sub-cycle, which represents a W-Device at this Slot.
Process_ULink_2	Check message for valid ULink Control Octets. For message encoding of the ULink Control Octet see Figure 136, ULink Control Octet
Check_last_DLink_3	Check if data have been sent for this W-Device / Slot_N in last downlink
SM: Get_CMD_4	The Message handler starts to compile the message for the next DLink using the DownLinkAck service to acquire a MasterCommand from the Command handler. The Message handler waits on the MCmd.req service and then changes to state GetPDOOut_5.
SM: GetPDOOut_5	The Message handler uses the DownLinkAck service to acquire PDOOut data from the PDOOut handler. The Message handler waits for the PDOOutMsg.req service to complement an already acquired MCmd.
SM: CyclicData_Ready_6	MasterCommand and / or PDOOut data are ready for this Slot_N_X.
Compile_PDOOut_7	Compile MCmd and PDOOut W-Messages for actual Slot / W-Device as part of the next DLink from the Service MCmd.req and PDOOutMsg.req. Each handler shall deliver the DLink Control Octet with its corresponding data. With the internal Variable W-FRAME_COMPLETE all MasterCommands and PDOOut data has been compiled for all 0 up to 7 Slot_Ns / Devices. See Sub-State machine MH_XX.
SM: GetEvent_8	The Message handler uses the DownLinkAck service to acquire a possible Event response from the Event handler. The Message handler waits on the EventMsg.rsp service to complement the already acquired PDOOut / MCmd.
SM: GetISDU_9	The Message handler uses the DownLinkAck service to acquire ISDU from the ISDU handler. The Message handler waits on the ISDUMsg.req service to complement the already acquired PD / MCmd / Event data.
SM: AcyclicData_Ready_10	Acyclic data (Event, ISDU) are ready for this Slot_N_X.
Compile_Acyclic_11	After the compilation of MasterCommand / PDOOut data for each Slot / W-Device, compile acyclic data (Event, ISDU) for all Slots/Devices until the DLink payload is filled up (RemainingLength = 0). Each handler shall deliver the DLink Control Octet with its corresponding data. Remaining acyclic data can be sent in the following DLink, after possible PDOOut data are compiled. See Sub-State machine MH_YY.

2625

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	The DL-mode handler activates the Message handler via MH_Conf_ACTIVE.
T2	1	7	PL_Transfer.ind reported an IMA ULink. If PL_Transfer.ind delivers WFrameComplete, set W-FRAME_COMPLETE to 1, otherwise to 0. Set IMACounter_X = 0. Invoke service DownLinkAck (Slotnumber, CMDHANDLER, RemainingLength, PreDLSet, Acknowledge) to acquire MasterCommand from Command handler. Store Acknowledge in ACK_Buf_X for this Slotnumber.
T3	1	2	PL_Transfer.ind reported a received ULink (see Figure 144 and Figure 145) with data for SlotNumber_X. If PL_Transfer.ind delivers WFrameComplete, set W-FRAME_COMPLETE = 1, otherwise to 0. Set IMACounter_X = 0. Set RetryCounter_X = 0. Store Acknowledge in ACK_Buf_X for this Slotnumber.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T4	1	3	No ULink has been received for SlotNumber_X. Increment IMACounter_X. If PL_Transfer.ind delivers WFrameComplete, set W-FRAME_COMPLETE = 1, otherwise to 0. Clear Acknowledge in ACK_Buf_X for this Slotnumber.
T5	2	7	Process the received data from ULink with SlotNumber_X to the appropriate handler. Invoke PDInMsg.ind, EventMsg.ind and ISDUMsg.cnf service indications. Invoke service DownLinkAck (Slotnumber, CMDHANDLER, RemainingLength, PreDLSet, Acknowledge) to acquire MasterCommand from Command handler for SlotNumber_X delivered via PL_Transfer.ind.
T6	3	3	A local IMA timeout event shall be reported via invocation of service EventMsg.ind(IOLW_IMATimeout, LOCAL) to the W-Master application.
T7	3	7	For the current SlotNumber_X, data have been sent in last DLink (stored via DL_Data_sent_X) which was not confirmed via the ACK-Bit in ULink (since no ULink received). Increment RetryCounter_X. Set DL_Data_sent_X = 0. Invoke service DownLinkAck (Slotnumber, CMDHANDLER, RemainingLength, PreDLSet, Acknowledge) to acquire MCMD from Command handler for SlotNumber_X delivered via PL_Transfer.ind.
T8	3	7	Invoke service DownLinkAck (Slotnumber, CMDHANDLER, RemainingLength, PreDLSet, Acknowledge) to acquire MCMD from Command handler for the SlotNumber_X delivered via PL_Transfer.ind.
T9	4	5	If MCmd.req(SendWMessage=YES): Compile downlink Control Octet, place in FullDownLink payload and set DL_Data_sent_X = 1. Decrease RemainingLength with the delivered length from (MCmd.req + 1 octet for downlink CO). If MCmd.req(SendWMessage=NO): No compilation of downlink CO necessary. Acquire PDOOut for SlotNumber_X through invocation of the DownLinkAck(Slotnumber, PDOUTHANDLER, RemainingLength, Acknowledge) service.
T10	4	5	If MCmd.req(SendWMessage=YES): set DL_Data_sent_X = 1 and set PreDLSet = YES. Acquire PDOOut for Slot_X / W-Device_X through invocation of the DownLinkAck(PDOUTHANDLER) service. DownLinkAck service delivers the remaining Payload-Bytes (RemainingLength) for the next DLink and ACK of last DLink-Frame (Retry-Handling) to the PDOOut handler.
T11	5	6	If PDOOutMsg.req(SendWMessage=YES): Place W-Message to DLink payload and decrease RemainingLength with the delivered length from PDOOutMsg.req – 2 (for Control Octet). Set DL_Data_sent_X = 1.
T12	7	7	A local MaxRetry event shall be reported via invocation of service EventMsg.ind(IOLWM_Retry_Error LOCAL) to the W-Master application.
T13	7	1	W-Frame is not complete. Wait for next ULink / next Slotnumber via PL_Transfer.ind in state Idle_1.
T14	7	11	W-Frame is complete, all ULinks have been received. Compile data for Event and ISDU for all Slots subsequently via T17: Set SlotCounter to 0. Acquire Event through invocation of the DownLinkAck(SlotCounter, EVHANDLER, RemainingLength, ACK_Buf_X) service.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T15	8	9	If EventMsg.rsp(SendWMessage=YES): Set DL_Data_sent_X = 1. Place W-Message to DLink payload and decrease RemainingLength with the delivered length from EventMsg.rsp – 2 (for Control Octet). Acquire ISDU through invocation of the DownLinkAck(SlotCounter, ISDUHANDLER, RemainingLength, ACK_Buf_X) service.
T16	9	10	If ISDUMsg.req(SendWMessage=YES): Set DL_Data_sent_X = 1, place W-Message to DLink payload and increment SlotCounter to acquire data for next Slot.
T17	11	11	Invoke DownLinkAck(SlotCounter, EVHANDLER, RemainingLength, ACK_Buf_X) to acquire acyclic data (Event, ISDU) for the next Slot counted in SlotCounter. See Sub-State machine Compile_Acyclic_11.
T18	11	1	All acyclic data for all Slots / Devices have been acquired. Downlink is ready to send. Invoke PL_Transfer.req to send DLink within the next W-Sub-Cycle. Set RemainingLength to DLink-Payload (37 Octet) for composition of the following DLink. Set PreDLSet = NO to indicate a free PreDownLink for the next W-Sub-cycle.
T19	1	0	W-Device Message handler changes state to Inactive_0.

2626

INTERNAL ITEMS	TYPE	DEFINITION
RemainingLength	Variable	Remaining length in DLink payload.
W-FRAME_COMPLETE	Variable	Marks the W-Sub-cycle as completed, if all ULinks have been processed.
SlotCounter	Variable	Counter to compile the acyclic data for all Slots / Devices
RetryCounter_X	Variable	Counter for not acknowledged DLinks.
IMACounter_X	Variable	Counter to observe ULink-IMA-frames which shall be sent by W-Device_X.
DL_Data_sent_X	Variable	Variable to store the information, that data have been sent in last DLink for the corresponding Slot / W-Device.
PreDLSet	Bool	Marks if the PreDownlink will be used or not.

2627

2628

2629

2630

2631

2632

2633

Note 1: _X marks the variables which individual for every Slotnumber. The range of _X is 0 to 7 SlotNumbers

Note 2: If a W-Message shall be sent (SendWMessage = YES), the Message handler must compile the control octet of the corresponding DL-B handler as defined in Table 42 Compilation of Downlink Control Octet.

2634

6.5.3 Compilation of DLink Control Octet

2635

2636

2637

2638

The Master Message handler (see Figure 60) shall compile the control octet for a DLink delivered with the data via the corresponding DL-B handler as defined in Table 42.

See Figure 134 for definition of DLink Control Octet.

2639

Table 42 Compilation of Downlink Control Octet

Compiled Control Octet handler: ↓	→	Slot-number (delivered by handler)	Channel Code (ChC) (created by Message handler)	Flow Control (FC) (delivered by handler)	Data Length (DLen) (delivered by handler)	Data follows
MCcmd.req		Slot_N	5 (MasterCommand)	MasterCommand (delivered by handler)		No
PDUOutMsg.req		Slot_N	1 (Process data out)	FlowCtrl	0 to 31 See Note 1	Yes
				FlowCtrl (ABORT)	0	No
			2 (Process data out invalid)	-	-	No
EventMsg.rsp (Event Ack)		Slot_N	4 (EVENT)	-	-	No
ISDUMsg.req		Slot_N	3 (ISDU)	FlowCtrl	0 to 31 See Note 1	Yes
				FlowCtrl = EOS or ABORT	0	No
Empty Downlink See Note 2		-	0 (INVALID)	-	-	No

2640

Note 1:

2641

Data Length is coded from 0 to 31 which means, that the transmitted data are 1 to 32 Octet.

2642

2643

2644

Note 2:

2645

An empty downlink (all payload data zero) is automatically created by PL, if the W-Master has no data to send to any W-Device.


2646

2647

2648
2649
2650
2651
2652
2653

6.5.4 State machine of the W-Device Message handler (DL-A)


Figure 63 shows the state machine of the W-Device Message handler. The Message handler is triggered via PL for each W-Sub-cycle to distribute received W-Messages and / or as trigger to send W-Messages within an ULink. The sub state machine CreateMessage_8 handles the compilation of ULink W-Messages in a predefined order.



2654
2655
2656

Figure 63 State machine of the W-Device Message handler

2657



2658
2659

Figure 64 W-Device Message handler sub state machine “CreateMessage_8” (DL-A)

Table 43 State transition tables of the W-Device Message handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through MH_Conf_ACTIVE (see Table 43, Transition T1).
Idle_1	Waiting for Trigger (each W-Sub-cycle) through PL_Transfer.ind service indication (T2).
ProcessMessage_2	Check message for valid DLink Control Octet. For message encoding of the DLink Control Octet see Figure 134
InitializeMessage_3	Set RemainingLength of ULink payload to 2 (SSlot-W-Device) or 15 (DSlot-W-Device).
SM: GetPDIn_4	The Message handler starts to compile the message for the next ULink using the UpLinkAck service to acquire PDIn from the Process Data handler. The Message handler waits on the PDInMsg.req service and then changes to state GetEvent_5.
SM: GetEvent_5	The Message handler uses the UpLinkAck service to acquire an Event from the Event handler. The Message handler waits on the EventMsg.req service to complement the already acquired PDIn.
SM: GetISDU_6	The Message handler uses the UpLinkAck service to acquire ISDUMsg.rsp from the ISDU handler. The Message handler waits on the ISDUMsg service to complement the already acquired PD / Event.
SM: Message_Ready_7	ULink data ready
CreateMessage_8	Compile Message for next ULink from PDInMsg.req, EventMsg.req and ISDUMsg.rsp services (see submachine). For the Message encoding of the ULink Control Octet see Figure 136.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>DL-mode handler activates Message handler via MH_Conf_ACTIVE.</i>
T2	1	2	<i>Service PL_Transfer_ind indicates a received (or lost) DLink.</i> If PL_Transfer_ind delivers pos. Acknowledge, set IMACounter = 0, Set RetryCounter = 0. If PL_Transfer_ind delivers neg. Acknowledge, increment RetryCounter.
T3	2	3	-
T4	2	3	A real-time fault shall be reported via invocation of service DL_MaxRetry. <i>Note:</i> <i>The parameter MaxRetry is delivered via service DL_SetParam.</i>
T5	3	4	Invoke MCmd.ind, ISDUMsg.ind and PDUOutMsg.ind service indications to distribute received W-Messages. Acquire PDIn through invocation of the service UpLinkAck(PDHANDLER, RemainingLength, Acknowledge).
T6	4	5	If PDInMsg.req(SendWMessage=YES): Place W-Message to ULink payload and decrease RemainingLength with the delivered length from PDInMsg.req – 1 (for Control Octet). Acquire Event through invocation of the service UpLinkAck(EVENTHANDLER, RemainingLength, Acknowledge).
T7	5	6	If EventMsg.req(SendWMessage=YES): Place W-Message to ULink payload and decrease RemainingLength with the delivered length from PDInMsg.req – 1 (for Control Octet). Acquire ISDU through invocation of the service UpLinkAck(ISDUHANDLER, RemainingLength, Acknowledge).
T8	6	7	If ISDUMsg.rsp(SendWMessage=YES): Place W-Message to ULink payload and set RemainingLength to 2 (SSlot-W-Device) or 15 (DSlot-W-Device).
T9	8	1	<i>No ULink-Data have to be sent.</i> Increment IMACounter.
T10	8	1	Invoke service PL_Transfer.req(Data, DataLength) with ULink-Data for transmission to W-Master.
T11	8	1	To indicate its presence to W-Master, the W-Device shall send an IMA-Frame, if IMACounter >= SendIMA through invocation of service PL_Transfer.req(DataLength=0).
T12	1	0	<i>The W-Device Message handler changes state to Inactive_0.</i>

2662

INTERNAL ITEMS	TYPE	DEFINITION
RemainingLength	Variable	Remaining length in ULink payload.
RetryCounter	Variable	Counter for not acknowledged ULinks.
IMACounter	Variable	Counter to send ULink-IMA-frames.
SendIMA	Variable	Limit for IMACounter (see T11) to send an IMA-ULink to W-Master. This value is calculated by the following formula: $SendIMA = (IMATime \text{ in } W\text{-Sub-cycle}) - MaxRetry - 10$

2663

2664 **6.5.5 Compilation of ULink Control Octet**

2665 The Device Message handler (see Figure 63) shall compile the control octet for an ULink delivered via the
 2666 corresponding DL-B handler as defined in Table 44. See Figure 136 for definition of ULink Control Octet.
 2667
 2668

Table 44 Compilation of Uplink Control Octet

Compiled Control Octet handler: ↓	→	Channel Code (ChC) (created by Message handler)	Flow Control (FC) (delivered by handler) See Note 1	Data follows
		PDInMsg.req	1 (Process data in)	FlowCtrl
2 (Process data in invalid)	FlowCtrl = ABORT		No	
EventMsg.req	4 (EVENT)	-	No	
	3 (ISDU)	FlowCtrl = EOS or ABORT	Yes	
ISDUMsg.rsp	3 (ISDU)	FlowCtrl = EOS or ABORT	No	
	No Control Octet needed. See Table 26			
IMA Uplink				

2669 Note: For uplink W-Messages the length of data is coded in the Flow Control.
 2670
 2671

2672 **7 Data Link Layer (DL-B)**

2673 **7.1 DL-B services**

2674 **7.1.1 Overview of services within W-Master and W-Device**

2675 This clause defines the services of the data link layer to be provided to the application layer and system
 2676 management via its external interfaces. Table 45 lists the assignments of W-Master and W-Device to their
 2677 roles as initiator or receiver for the individual DL services. Empty fields indicate no availability of this service
 2678 on W-Master or W-Device.
 2679
 2680

Table 45 Service assignments within W-Master and W-Device

Service name	W-Master	W-Device
DL_PDTrig	I	I
DL_PDInputTransport	I	
DL_Control	I, R	I, R
DL_PDOutputUpdate	R	
DL_PDOutputTransport		I
DL_PDInputUpdate		R
DL_Event	I	R
DL_ISDUTransport	R	I
DL_ISDUAbort	R	I
DL_TDConfig	R	
DL_Read	R	I
DL_Write	R	I
DL_SetMode	R	
DL_Mode	I	I
DL_MaxRetry		I
DL_SetParam	R	R
Key (see 3.3.5) All services are defined from the view of the affected layer towards the layer above. - I Initiator of a service (towards the layer above) - R Receiver (responder) of a service (from the layer above)		

7.1.2 DL_PDTrig (W-Master and W-Device)

The data link layer uses the DL_PDTrig service to indicate the end of a W-MasterCycleTime period after start of Process Data reception to the application layer. This service has no parameters. The service primitives are listed in Table 46

Table 46 DL_PDTrig

Parameter Name	.ind
<none>	

7.1.3 DL_PDInputTransport (W-Master)

The data link layer on the W-Master uses the DL_PDInputTransport service to transfer the content of input data (Process Data from W-Device to W-Master) to the application layer. The parameters of the service primitives are listed in Table 47

Table 47 DL_PDInputTransport

Parameter Name	.ind
Argument	M
InputData	M

Argument

The service-specific parameters are transmitted in the argument.

InputData

This parameter contains the Process Data to be transmitted to the application layer.

Parameter type: Octet string

7.1.4 DL_Control (W-Master and W-Device)

The W-Master uses the DL_Control service to convey control information via the process data channel to the corresponding technology specific device application and to get control information via the PD handler (see clause 12.9 PDVALID PDINVALID). The parameters of the service primitives are listed in Table 48.

Table 48 DL_Control

Parameter Name	.req	.ind
Argument	M	M
ControlCode	M	M(=)

Argument

The service-specific parameters are transmitted in the argument.

ControlCode

This parameter indicates the status of the Process Data (PD)

Permitted values:

PDIN_VALID (Input Process Data valid)

PDIN_INVALID (Input Process Data invalid)

PDOUT_VALID (Output Process Data valid)

PDOUT_INVALID (Output Process Data invalid or missing)

7.1.5 DL_PDOutputUpdate (W-Master)

The W-Master's application layer uses the DL_PDOutputUpdate service to update the output data (Process Data from W-Master to W-Device) on the data link layer. The parameters of the service primitives are listed in Table 49.

Table 49 DL_PDOutputUpdate

Parameter Name	.req	.cnf
Argument	M	
OutputData	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

OutputData

This parameter contains the Process Data provided by the application layer.

Parameter type: Octet string

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

NO_COMM (no communication available),

STATE_CONFLICT (service unavailable within current state)

7.1.6 DL_PDOutputTransport (W-Device)

The data link layer on the W-Device uses the DL_PDOutputTransport service to transfer the content of output Process Data to the application layer (from W-Master to W-Device). The parameters of the service primitives are listed in Table 50.

Table 50 DL_PDOutputTransport

Parameter Name	.ind
Argument	M
OutputData	M

Argument

The service-specific parameters are transmitted in the argument.

OutputData

This parameter contains the Process Data to be transmitted to the application layer.
Parameter type: Octet string

7.1.7 DL_PDInputUpdate (W-Device)

The W-Device's application layer uses the DL_PDInputUpdate service to update the input data (Process Data from W-Device to W-Master) on the data link layer. The parameters of the service primitives are listed in Table 51.

Table 51 DL_PDInputUpdate

Parameter Name	.req	.cnf
Argument	M	
InputData	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

InputData

This parameter contains the Process Data provided by the application layer.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

NO_COMM (no communication available),

STATE_CONFLICT (service unavailable within current state)

7.1.8 DL_Event (W-Master and W-Device)

The service DL_Event transfers a status or error information. The W-Device application triggers the Event transfer. Additional DL_Event requests are ignored until the previous one has been confirmed (see Figure 77, Sequence chart for Event). The parameters of the service primitives are listed in Table 52.

2780

Table 52 DL_Event

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
Instance	M	M		
Type	M	M		
Mode	M	M		
EventCode	M	M		

2781

Argument

2782

The service-specific parameters are transmitted in the argument.

2783

Instance

2784

This parameter indicates the Event source.

2785

Permitted values: Application (see Table 136, see Table A.17 in REF 1)

2786

Type

2787

This parameter indicates the Event category.

2788

Permitted values: ERROR, WARNING, NOTIFICATION (see Table 138, see Table A.19 in REF 1)

2789

Mode

2790

This parameter indicates the Event mode.

2791

Permitted values: SINGLESHOT, APPEARS, DISAPPEARS (see Table 139, see Table A.20 in REF 1)

2792

EventCode

2794

This parameter contains a code identifying a certain Event (see clause 15, see Table D.1 in REF 1).

2795

Parameter type: 16 bit unsigned integer

2796

2797

2798

2799

7.1.9 DL_ISDUtransport (W-Master and W-Device)

2800

The DL_ISDUtransport service is used to transport an ISDU. This service is used by the W-Master to send a service request from the W-Master application layer to the W-Device. It is used by the W-Device to send a service response to the W-Master from the W-Device application layer. The parameters of the service primitives are listed in Table 53.

2801

2802

2803

2804

Table 53 DL_ISDUtransport

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
ValueList	M	M		
Result (+)			S	S
Data			C	C
Qualifier			M	M
Result (-)			S	S
ISDUtransportErrorInfo			M	M

2805

Argument

2806

The service-specific parameters are transmitted in the argument.

2807

ValueList

2808

This parameter contains the relevant operating parameters

2809

Parameter type: Record

2810

Index

2811

Permitted values: 0 to 65535

2812

Subindex

2813

Permitted values: 0 to 255

2814

Data

2815

Parameter type: Octet string

2816 **Direction**
 2817 Permitted values:
 2818 READ (Read operation),
 2819 WRITE (Write operation)

2820 **Result (+):**
 2821 This selection parameter indicates that the service has been executed successfully.

2822 **Data**
 2823 Parameter type: Octet string

2824 **Qualifier**
 2825 Permitted values: an I-Service W-Device response according to clause 7.4.312.11.1, see Table 70

2826 **Result (-):**
 2827 This selection parameter indicates that the service failed.

2828 **ISDUTransportErrorInfo**
 2829 This parameter contains the error information.

2830 Permitted values:
 2831 NO_COMM (no communication available),
 2832 STATE_CONFLICT (service unavailable within current state),
 2833 ISDU_TIMEOUT (ISDU acknowledgement time elapsed, see Figure 84, see Table 97 in
 2834 REF 1),
 2835 VALUE_OUT_OF_RANGE (Service parameter value violates range definitions)

2837 **7.1.10 DL_ISDUAbort (W-Master and W-Device)**

2838 The DL_ISDUAbort service aborts the current ISDU transmission. The service primitives are listed in Table
 2839 54.

2840 **Table 54 DL_ISDUAbort**

Parameter Name	.req	.ind
<none>		

2843 **7.1.11 DL_TDConfig (W-Master)**

2844 The DL_TDConfig service is used to configure the mapping of a W-Port to the corresponding Track and
 2845 Slot via W-Port Configuration Manager / System Management. The service primitives are listed in
 2846 Table 55.

2847 **Table 55 DL_TDConfig (W-Master)**

Parameter Name	.req	.cnf
Argument	M	
ValueList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

2849 **Argument**

2850 The service-specific parameters are transmitted in the argument.

2851 **ValueList**

2852 This parameter contains the parameters for the TDmapper. Parameter type: Record

2853 **Track_N**

2854 This parameter contains the track number.

2855 Permitted values: 0 to 4

2856 **Slot_N**

2857 This parameter contains the Slot number for the corresponding W-Device

2858 Permitted values: 0 to 7

2859 **Result (+):**

2860 This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

PARAMETER_CONFLICT (consistency of parameter set violated)

STATE_CONFLICT (service unavailable within current state)

7.1.12 DL_Read (W-Master and W-Device)

The DL_Read service is used by system management to read a W-Device parameter value in direct parameter page 1 or in the extended wireless parameter pages via ISDU. Therefore DL_Read uses the DL_ISDUtransport service. The parameters of the service primitives are listed in Table 56.

Table 56 DL_Read

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
Index	M	M		
Subindex	M	M		
Result (+)			M	S
Value			M	M(=)
Result (-)				S
ErrorInfo				M

Argument

The service-specific parameters are transmitted in the argument.

Index

This parameter contains the Index of the W-Device parameters in Page 1 or in the extended wireless parameter page (see Table 168Table 164).

Permitted values: see Table 171Table 168

Subindex

This parameter contains the Subindex of the W-Device parameter in Page 1 (see Table 164) or in the extended wireless parameter page.

Permitted values: For Page 1 values 1 to 15, for extended wireless parameters, see clause 14.3

Value

This parameter contains the W-Device parameter value to be written.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Value

This parameter contains read W-Device parameter values.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

NO_COMM (no communication available),

STATE_CONFLICT (service unavailable within current state)

7.1.13 DL_Write (W-Master and W-Device)

The DL_Write service is used by system management to write a W-Device parameter value to direct parameter page 1 or to the extended wireless parameter pages via ISDU. Therefore DL_Write uses the ISDUMsg service for ISDU and the MCcmd service in case of a Master command. The parameters of the service primitives are listed in Table 57.

Table 57 DL_Write

Parameter Name	.req	.ind	.cnf
Argument	M	M	
Index	M	M	
Subindex	M	M	
Value	M	M	
Result (+)			S
Result (-)			S
ErrorInfo			M

Argument

The service-specific parameters are transmitted in the argument.

Index

This parameter contains the Index of the W-Device parameters in Page 1 or in the extended wireless parameter page (see Table 168 Table 164).

Permitted values: see Table 171 Table 168

Subindex

This parameter contains the Subindex of the W-Device parameter in Page 1 (see Table 164) or in the extended wireless parameter page.

Permitted values: For Page 1 values 1 to 15, for extended wireless parameters, see clause 14.3

Value

This parameter contains the W-Device parameter value to be written.

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values:

NO_COMM (no communication available),

STATE_CONFLICT (service unavailable within current state)

7.1.14 DL_SetMode (W-Master)

The DL_SetMode service is used by system management to set up the data link layer's state machines and to send the characteristic values required for operation to the data link layer. The parameters of the service primitives are listed in Table 58.

2933

Table 58 DL_SetMode

Parameter Name	.req	.cnf
Argument	M	
Mode	M	
ValueList	U	
Result (+)		S
W-Port		M
Result (-)		S
W-Port		M
ErrorInfo		M

2934

Argument

2935

The service-specific parameters are transmitted in the argument.

2936

Mode

2937

This parameter indicates the requested mode of the W-Master's DL on an individual W-Port.

2938

Permitted values:

2939

INACTIVE (handler shall change to the INACTIVE state),

2940

STARTUP (handler shall change to STARTUP state),

2941

PREOPERATE (handler shall change to PREOPERATE state),

2942

OPERATE (handler shall change to OPERATE state)

2943

ValueList

2944

This parameter contains the relevant operating parameters.

2945

Data structure: record

2946

 PDInputLength (to be propagated to Message handler and PDIn handler)

2947

 PDOutputLength (to be propagated to Message handler)

2948

Result (+):

2949

This selection parameter indicates that the service has been executed successfully.

2950

W-Port

2951

This parameter contains the number of the related W-Port.

2952

Result (-):

2953

This selection parameter indicates that the service failed.

2954

W-Port

2955

This parameter contains the number of the related W-Port.

2956

ErrorInfo

2957

This parameter contains the error information.

2958

Permitted values:

2959

STATE_CONFLICT (service unavailable within current state),

2960

PARAMETER_CONFLICT (consistency of parameter set violated)

2961

2962

7.1.15 DL_Mode (W-Master and W-Device)

2963

The DL uses the DL_Mode service to report to system management that a certain operating status has

2964

been reached. The parameters of the service primitives are listed in Table 59.

2965

2966

Table 59 DL_Mode

Parameter Name	.ind
Argument	M
W-Port	C
RealMode	M

2967

Argument

2968

The service-specific parameters are transmitted in the argument.

RealMode

This parameter indicates the status of the DL-mode handler.

Permitted values:

- 2972 INACTIVE (handler changed to the INACTIVE state)
- 2973 COMLOST (communication lost)
- 2974 ACTIVE (handler changed to the ACTIVE state)
- 2975 STARTUP (handler changed to the STARTUP state)
- 2976 PREOPERATE (handler changed to the PREOPERATE state)
- 2977 OPERATE (handler changed to the OPERATE state)

7.1.16 DL_MaxRetry (W-Device)

The service DL_MaxRetry indicates a real-time fault to application for W-Device dependent error handling, when RetryCounter exceeded the configured value MaxRetry.

The parameters of the service are listed in Table 60.

Table 60 DL_MaxRetry

Parameter Name	.ind
<none>	

7.1.17 DL_SetParam (W-Master and W-Device)

The DL_SetParam service is used to change parameters for retry and IMA handling in the Message handler.

The parameters of the service primitives are listed in Table 61.

Table 61 DL_SetParam

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

ParameterList

This parameter contains the configured communication parameters for a W-Device.

Parameter type: Record

Record Elements:

MAXRetry

This parameter contains the maximum number of allowed retries in count of W-Sub-Cycles (see clause 14.3.6). This info is delivered to the Message handler and the W-Master-PDOOut handler.

IMATime

This parameter contains the I am alive time(see clause 14.3.5). This info is delivered to the Message handler.

MaxPDSEgLength (only W-Master)

This parameter contains the maximum segment length of the PDOOut data to the Message handler to distribute PDOOut data within multiple W-Cycles. This info is delivered to the W-Master-PDOOut handler.

LowPowerDevice

This info is delivered to the CommandHandler, ISDU handler and Process Data handler to switch a low energy W-Device to PreDownLink or FullDownLink.

3013 Permitted values: YES, NO.

3014 **Result (+):**

3015 This selection parameter indicates that the service has been executed successfully.

3016 **Result (-):**

3017 This selection parameter indicates that the service failed.

3018 **ErrorInfo**

3019 This parameter contains the error information.

3020 Permitted values:

3021 VALUE_OUT_OF_RANGE (service parameter value violates range definitions)

3022

3023 7.2 DL-mode handler

3024 7.2.1 General

3025 The W-Master DL-mode handler is responsible to establish communication using services of the Physical
3026 Layer (PL) and internal administrative calls to control and monitor the states of other handlers.

3027 The W-Device DL-mode handler receives MasterCommands to synchronize with the W-Master DL-mode
3028 handler states STARTUP, PREOPERATE, OPERATE and manages the activation and deactivation of
3029 handlers as appropriate.

7.2.2 State machine of the W-Master DL-mode handler

After reception of the service DL_SetMode(STARTUP) from system management, the W-Master waits for synchronization with the W-Device.

The purpose of state "Startup_2" is to check a W-Device's identity in state "PreOperate_3", the W-Master may assign parameters to the W-Device using ISDUs. Cyclic exchange of Process Data is performed in state "Operate". Within this state additional data such as Commands, Events and ISDUs can be transmitted.




Figure 65 State Machine of the W-Master DL-mode handler

3041

Table 62 State transition tables of the W-Master DL-mode handler

STATE NAME	STATE DESCRIPTION
Idle_0	Waiting for communication request from System Management (SM): DL_SetMode (STARTUP)
EstablishCom_1	Waiting for synchronization with W-Device
Startup_2	System Management uses the STARTUP state for W-Device identification, check and communication configuration (see Figure 96).
Preoperate_3	Commands, Events and ISDU without Process Data
Operate_4	Process Data, Commands, Events and ISDU

3042

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke MH_Conf_ACTIVE to activate Message handler.
T2	1	2	Activate Command handler (call CH_Conf_ACTIVE see Table 62 DL-mode handler W-Master) and ISDU handler (call IH_Conf_ACTIVE see Figure 72 ISDU-handler W-Master) Indicate state via service DL_Mode.ind (ACTIVE) and DL_Mode.ind (STARTUP) to SM.
T3	2	3	SM requested the PREOPERATE state. Activate Event handler (call EH_Conf_ACTIVE see Figure 72. EventHandler). Invoke DL_Mode.ind (PREOPERATE) to SM.
T4	3	4	SM requested the OPERATE state. Activate the Process Data handler (PD_Conf_ACTIVE see PDHandler W-Master). Invoke DL_Mode.ind (OPERATE) to SM.
T5	2	4	SM requested the OPERATE state. Activate the Process Data handler (call PD_Conf_ACTIVE see Figure PDHandler W-Master) and Event handler (call EH_Conf_ACTIVE see Figure 72..EVHandler W-Master). Invoke DL_Mode.ind (OPERATE) to SM.
T6	3	2	SM requested the STARTUP state. Deactivate Event handler (call EH_Conf_INACTIVE). Invoke DL_Mode.ind (STARTUP) to SM.
T7	4	2	SM requested the STARTUP state. Deactivate Process Data (call PD_Conf_INACTIVE) and Event handler (call EH_Conf_INACTIVE). Invoke DL_Mode.ind (STARTUP) to SM.
T8	2	0	Physical Layer delivers state through Service PL_State.ind(COMLOST) Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (COMLOST) to SM.
T9	1	0	SM requested the INACTIVE state. Deactivate all handlers (call xx_Conf_INACTIVE). Invoke DL_Mode.ind (INACTIVE) to SM.
T10	3	0	SM requested the INACTIVE state. Deactivate all handlers (call xx_Conf_INACTIVE). Invoke DL_Mode.ind (INACTIVE) to SM.
T11	3	0	Physical Layer delivers state through Service PL_State.ind(COMLOST) Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (COMLOST) to SM (see Figure 96. State machine of the W-Port handler)
T12	4	0	Physical Layer delivers state through Service PL_State.ind(COMLOST) Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (COMLOST) to SM
T13	4	0	SM requested the INACTIVE state. Deactivate all handlers (call xx_Conf_INACTIVE). Invoke DL_Mode.ind (INACTIVE) to SM.


3043

INTERNAL ITEMS	TYPE	DEFINITION
xx_Conf_ACTIVE	Call	This call activates the respective handler. xx is substitute for MH (Message handler), IH (ISDU handler), CH (Command handler), and/or EH (Event handler)
xx_Conf_INACTIVE	Call	This call deactivates the Message handler. xx is substitute for MH (Message handler), IH (ISDU handler), CH (Command handler), and/or EH (Event handler)

3044

3045 **7.2.3 State machine of the W-Device DL-mode handler**

3046 Figure 66 shows the state machine of the W-Device DL-mode handler. In state PreOperate_2 and
 3047 Operate_3 different sets of handlers within the W-Device are activated.
 3048



3049

Figure 66 State machine of the W-Device DL-mode handler

3050

Table 63 State transition tables of the W-Device DL-mode handler

3051

STATE NAME	STATE DESCRIPTION
Idle_0	Waiting for established connection
Startup_1	Compatibility check (see Figure 97)
PreOperate_2	On-request Data exchange (parameter, commands, Events) without Process Data
Operate_3	Process Data (PD) and On-request Data exchange (parameter, commands, Events)

3052

3053

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>Physical Layer delivers state through service PL_State.ind(SYNCED).</i> Activate Message handler (call MH_Conf_ACTIVE in Figure 63) , ISDU handler (call IH_Conf_ACTIVE in Figure 73) and Command handler (call CH_Conf_ACTIVE in Figure 75). Indicate state via service DL_Mode.ind (ACTIVE) to SM.
T2	1	2	<i>W-Device command handler received MasterCommand (MCmd_PREOPERATE).</i> Activate Event handler (call EH_Conf_ACTIVE in Figure 78). Indicate state via service DL_Mode.ind (PREOPERATE) to SM.
T3	2	1	<i>W-Device command handler received MasterCommand (MCmd_STARTUP).</i> Deactivate Event handler (call EH_Conf_INACTIVE in Figure 78). Indicate state via service DL_Mode.ind (STARTUP) to SM.
T4	2	3	<i>W-Device command handler received MasterCommand (MCmd_OPERATE).</i> Activate Process Data handler (call PD_Conf_ACTIVE in Figure 70). Indicate state via service DL_Mode.ind (OPERATE) to SM.
T5	2	0	<i>Physical Layer delivers state through Service PL_State.ind(COMLOST).</i> Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (INACTIVE) to SM (see Figure 106 and Table 120)
T6	1	3	<i>W-Device command handler received MasterCommand (MCmd_OPERATE).</i> Activate Process Data handler (call PD_Conf_ACTIVE in Figure 70) and Event handler (call EH_Conf_ACTIVE in Figure 78). Indicate state via service DL_Mode.ind (OPERATE) to SM.
T7	3	1	<i>W-Device command handler received MasterCommand (MCmd_STARTUP).</i> Deactivate Process Data handler (call PD_Conf_INACTIVE in Figure 70) and Event handler (call EH_Conf_INACTIVE in Figure 78). Indicate state via service DL_Mode.ind (STARTUP) to SM.
T8	3	0	<i>Physical Layer delivers state through Service PL_State.ind(COMLOST).</i> Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (INACTIVE) to SM (see Figure 106 and Table 120)
T9	1	0	<i>Physical Layer delivers state through Service PL_State.ind(COMLOST).</i> Deactivate all handlers (call xx_Conf_INACTIVE). Indicate state via service DL_Mode.ind (INACTIVE) to SM (see Figure 106 and Table 120)

3054
3055

7.3 Process Data handler

The transport of output Process Data is performed using the services DL_PDOutputUpdate and DL_PDOutputTransport.
 The transport of input Process Data is performed using the services DL_PDInputUpdate and DL_PDInputTransport.
 Via service DL_Control Process Data can be set to valid or invalid.

7.3.1 State machine of the W-Master Process Data Out handler




Figure 67 State machine for W-Master PDOut handler

3066
3067**Table 64 StateTransition tables of the W-Master PDOOut handler**

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through PD_Conf_ACTIVE (see Table 63, Transition T1).
PDOOut_Wait_1	Waiting for DL_PDOutputUpdate from application.
PDOOut_Active_2	handler active and waiting on DownLinkAck_ind_PD.
PDOOut_Compiled_3	Compile W-Message under conditions of DLink Control Octet (see Figure 134, DLink Control Octet) Maximum segment length shall be limited by parameter MaxPDSegLength (via DL_SetParam) to distribute PDOOut data (see Figure 128 PDOOut distribution sequence chart) Set Variable PDOOut_Completion to PDOOUT_COMPLETE if all PDOOut data Octets are transmitted otherwise set to PDOOUT_INCOMPLETE. PDOOut-Data transmission uses the mechanism of segmented data transfer, see 7.7.1 "Transmission of Segmented Data (PD, EV, ISDU)". For Retry-Handling see 7.7.2 "Retry-Handling of segmented Data (PD, EV, ISDU)".
PDOOut_Cycletimer_4	Handle timing / distribution for PDOOut segmented data within multiple W-Sub-cycles. If a data segment was not acknowledged, send retry immediately with next W-Sub-cycle. In case of an acknowledged data segment wait for „x“ W-Sub-cycles and send the next data segment (distribution). Note: „x“ = MaxRetry

3068

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	No Process Data (PDOOut) to send, invoke PDOOutMsg.req(SendWMessage = NO).
T2	0	1	<i>W-Master DL-mode handler enables Process Data handler via PD_Conf_ACTIVE.</i> Set PD_OutStatus to PDOUT_INVALID
T3	1	1	No Process Data (PDOOut) to send, invoke PDOOutMsg.req(SendWMessage = NO).
T4	1	1	Set PD_OutStatus to PDOUT_VALID.
T5	1	2	In case of low energy W-Device: Invoke MCmd.req(FullDLink) and wait for pos. Acknowledge from Cmd handler to switch low energy W-Device to FullDownLink.
T6	1	2	In case of low energy W-Device: Invoke MCmd.req(FullDLink) and wait for pos. Acknowledge from Cmd handler to switch a low energy W-Device to FullDownLink. Set PD_OutStatus to PDOUT_INVALID.
T7	2	3	Set cycle_count = 0
T8	2, 3, 4	0	<i>W-Master DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.</i>
T9	4	3	Increase cycle_count, if cycle_count equals MaxRetries set cycle_count back to 0. <i>Resend data in next W-Message (retry.)</i>
T10	3	4	If „PD_OutStatus = PDOUT_INVALID“ invoke PDOOutMsg.req(PDOOutInvalid), otherwise invoke PDOOutMsg.req to output Process Data with max. Length of MaxPDSegLength Octets to Message handler PDOOutMsg.req(SendWMessage = YES, Slot_N, Data, Length, FlowCtrl).
T11	4	3	Set cycle_count = 0, Set Segment_sent = NO (send new segment in next W-Message).
T12	4	4	Set Segment_sent = YES, no Process Data (PDOOut) to send, invoke PDOOutMsg.req(SendWMessage = NO). Increase cycle_count.
T13	4	4	No Process Data (PDOOut) to send, invoke PDOOutMsg.req(SendWMessage = NO). Increase cycle_count.
T14	4	1	<i>Last PDOOut transmission (last segment) is complete and acknowledged.</i> In case of low energy W-Device: Invoke MCmd.req(PreDLink) to switch low energy W-Device back to PreDownLink. If „PD_OutStatus = PDOUT_VALID“ invoke DL_PDOutputUpdate.cnf
T15	1	0	<i>W-Master DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.</i>
T16	0	0	Invoke DL_PDOutputUpdate.cnf(NO_COMM)
T17	1	1	Invoke DL_PDOutputUpdate.cnf(STATE_CONFLICT)
T18	2	2	Invoke DL_PDOutputUpdate.cnf(STATE_CONFLICT)
T19	3	3	Invoke DL_PDOutputUpdate.cnf(STATE_CONFLICT)
T20	4	4	Invoke DL_PDOutputUpdate.cnf(STATE_CONFLICT)

INTERNAL ITEMS	TYPE	DEFINITION
PD_OutStatus	Variable	Indicate if PDOut is valid or invalid 0 = PDOUT_INVALID 1 = PDOUT_VALID
cycle_count	Variable	Counting variable for W-Sub-cycles
Segment_sent	Variable	Indicate if segment is sent and acknowledged. NO = Segment not sent and acknowledged YES = Segment sent and acknowledged
PDOut_Completion	Variable	Indicate if PDOut transmission is complete. 0 = PDOUT_INCOMPLETE 1 = PDOUT_COMPLETE

3070
3071

3072 7.3.1.1 Sequence diagram for PDOut distribution

3073

3074 This sequence chart shows an example communication between W-Master Message handler and W-Master
3075 PDOut handler, dependent on the following parameters, configured via SM_SetPortConfig / DL_SetParam.
3076 The parameters are used to distribute PDOut data in one or more W-Cycles, if e.g. a W-Cycle of 5 ms is
3077 not needed.

3078 **MaxPDSegLength:**

3079 Limits the PDOut data which shall be delivered to the Message handler.
3080 E.g. by this the PDOutData will be splitted in 2 W-Cycles.

3081 **MaxRetry:**

3082 Contains the maximum number of allowed retries for the last sent data(segment)
3083

3084




Figure 68 Sequence diagram for PDOut distribution

3085
3086

7.3.2 State machine of the W-Master Process Data In handler

Figure 69 shows the state machine of the W-Master Process Data In handler.




Figure 69 State machine for W-Master PDIn handler

Table 65 State transition tables of the W-Master PDIn handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through PD_Conf_ACTIVE (see Table 63, Device DL-Mode-handler Transition T1).
PDInActive_1	handler active and waiting for next Message handler demand via PDInMsg.ind service.
Handle_PDIn_2	Handle PDIn-Data. PDIn-Data transmission uses the mechanism of segmented data transfer, see. 7.7.1 "Transmission of Segmented Data (PD, EV, ISDU)". For Retry-Handling see 7.7.2 "Retry-Handling of segmented Data (PD, EV, ISDU)".

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	<i>Ignore Process Data (PDIn).</i>
T2	0	1	<i>W-Master DL-mode handler enables Process Data handler via PD_Conf_ACTIVE.</i>
T3	1	2	<i>Message handler delivers input Process Data or segment of input Process Data.</i> Start Timer "MasterCycleTime"(one-shot, not retriggerable) at each start of Process Data reception. See Note 1.
T4	2	1	-
T5	2	1	Invoke DL_PDInputTransport.ind (see 7.1.3) Invoke DL_Control.ind (PDIN_VALID).
T6	2	1	Invoke DL_PDTrig.ind. See Note 1.
T7	1	1	DLink Control Octet contained „Process Data In Invalid”. Invoke DL_Control.ind (PDIN_INVALID).
T8	1	0	<i>W-Master DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.</i>

3096

INTERNAL ITEMS	TYPE	DEFINITION
PDIn_complete	Guard	All segments have been received, PDIn data are complete and received data length of all segments are equal to the W-Device ProcessDataIn (see Table 164)
PDIn_incomplete	Guard	PDIn data are incomplete, wait for next data segment or received data length of all segments are not equal to the W-Device ProcessDataIn (see Table 164)
PDIn_invalid	Service	PDInMsg.ind delivered PDIN_INVALID (via ControlOctet)

3097

3098

3099

3100

3101

3102

Note 1: To minimize Jitter caused by different transmission qualities, especially with segmented data (variations on the numbers of retries) PDTrig can be used to get an equidistant time between reception of first data packet and activation of PDTrig.

7.3.3 State machine of the W-Device Process Data Out handler

Figure 70 shows the state machine of the W-Device Process Data Out handler.




Figure 70 State machine of the W-Device Process Data Out handler

Table 66 State transition tables of the W-Device PDOOut handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through PD_Conf_ACTIVE (see Table 63, Transition T1).
PDOActive_1	handler active and waiting on next Message handler demand via PDOOutMsg.ind service.
Handle_PDOOut_2	Handle PDOOut-Data. PDOOut-Data transmission uses the mechanism of segmented data transfer, see. 7.7.1 Transmission of Segmented Data (PD, EV, ISDU). For Retry-Handling see clause 7.7.2 "Retry-Handling of segmented Data (PD, EV, ISDU)".

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	Ignore Process Data (PDOOut).
T2	0	1	W-Device DL-mode handler enables Process Data handler via PD_Conf_ACTIVE.
T3	1	2	Message handler delivers output Process Data or segment of output Process Data. Start Timer "MasterCycleTime" (one-shot, not retriggerable) at each start of Process Data reception.
T4	2	1	-
T5	2	1	Invoke DL_PDOutputTransport.ind (see 7.1.6) Invoke DL_Control.ind (PDOUTINVALID).
T6	2	1	Invoke DL_PDTrig.ind (see 7.1.2).
T7	1	1	DLink Control Octet contained „Process Data Out Invalid“. Invoke DL_Control.ind (PDOUTINVALID).
T8	1	0	DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.

7.3.4 State machine of the W-Device Process Data In handler

Figure 71 shows the state machine of the W-Device Process Data In handler.




Figure 71 State machine of the W-Device Process Data In handler

Table 67 State transition tables of the W-Device PDIn handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through PD_Conf_ACTIVE (see Table 63, Transition T1).
PDInWait_1	Waiting for DL_PDInputUpdate from application.
PDInActive_2	handler active and waiting on UpLinkAck_ind_PD.
Handle_PDIn_3	Handle PDIn-Data. PDIn-Data transmission uses the mechanism of segmented data transfer, see. 7.7.1 Transmission of Segmented Data (PD, EV, ISDU). For Retry-Handling see 7.7.2 “Retry-Handling of segmented Data (PD, EV, ISDU)”.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	No Process Data (PDin) to send, invoke PDin.req(SendWMessage = NO).
T2	0	1	<i>W-Device DL-mode handler enables Process Data handler via PD_Conf_ACTIVE.</i>
T3	1	1	No Process Data (PDin) to send, invoke PDin.req(SendWMessage = NO).
T4	1	2	Prepare input Process Data for PDInMsg.req for next Message handler demand
T5	2	3	<i>Message handler requests PDIn-Data.</i> Invoke PDInMsg.req to deliver input Process Data to Message handler PDInMsg.req(SendWMessage, Data, Length, FlowCtrl).
T6	3	2	-
T7	3	1	<i>Last PDIn transmission (last segment) is complete and acknowledged.</i> Invoke DL_PDInputUpdate.cnf
T8	2	0	<i>DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.</i>
T9	1	2	Invoke PDInMsg.req(PDIN_INVALID) to generate „Process Data In Invalid“ in ULink Control Octet.
T10	1	0	<i>DL-mode handler disables Process Data handler via PD_Conf_INACTIVE.</i>
T11	2	2	Invoke DL_PDInputUpdate.cnf(STATE_CONFLICT)
T12	3	3	Invoke DL_PDInputUpdate.cnf(STATE_CONFLICT)
T13	0	0	Invoke DL_PDInputUpdate.cnf(NO_COMM)

3118
3119

7.4 Indexed Service Data Unit (ISDU) handler

The general structure of an ISDU is demonstrated in Figure 48 and specified in detail in Clause A.5.in REF 1

The ISDU allows accessing data objects (parameters and system commands) to be transmitted. The data objects shall be addressed by the “Index” element.

7.4.1 State machine of the W-Master ISDU handler

Figure 72 shows the state machine of the W-Master ISDU handler




Figure 72 State machine of the W-Master ISDU handler

Table 68 State transition tables of the W-Master ISDU handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation
Idle_1	Waiting for transmission of next ISDU Data. Services DL_Read and DL_Write are mapped to DL_ISDU_Transport.
WaitAckIH_2	Waiting for DownlinkAck_IH
ISDURequest_3	Transmission of ISDU request data. ISDU data transmission uses the mechanism of segmented data transfer “see 7.7.1 Transmission of Segmented Data (PD, EV, ISDU)”. For Retry-Handling see 7.7.2 “Retry-Handling of segmented Data (PD, EV, ISDU)”.
ISDUWait_4	Waiting for response from W-Device. Observe ISDUTime
ISDUErrror_5	Error handling after detected errors: Invoke negative DL_ISDU_Transport response with ISDUTransportErrorInfo
ISDUResponse_6	Get response data from W-Device. ISDU data transmission uses the mechanism of segmented data transfer “see 7.7.1 Transmission of Segmented Data (PD, EV, ISDU)”. For Retry-Handling see 7.7.2 “Retry-Handling of segmented Data (PD, EV, ISDU)”.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	-
T2	1	2	Set InitService to ISDU In case of low energy W-Device: Invoke MCmd.req(FullDLink) and wait for pos. Acknowledge from Cmd handler to switch low energy W-Device to FullDownLink
T3	2	3	If enough space left in the downlink, invoke ISDUMsg.req (SendWMessage = YES, Slot_N, Length, data, flowCtrl = START).
T4	2	2	If enough space left in the downlink, invoke ISDUMsg.req with FlowCTRL under conditions of Table 75 (FlowCTRL / DLink CO) ISDUMsg.req(SendWMessage = YES, Slot_N, Length, data, flowCtrl). After all data were sent, invoke ISDUMsg.req with EOS (without data) ISDUMsg.req(SendWMessage = YES, Slot_N, EOS) (see 7.7.1 Transmission of segmented data)
T5	2	3	Start timer (ISDUTime)
T6	3	5	Stop timer (ISDUTime)
T7	5	5	Receive ISDU response data via ISDUMsg.cnf
T8	5	1	Invoke positive DL_ ISDUtransport confirmation when last segment (EOS) has been received (see 7.7.1 Transmission of segmented data) In case of low energy W-Device : Invoke MCmd.req(PreDLink) to switch low energy W-Device to PreDownLink
T9	3	4	-
T10	5	4	-
T11	4	1	<i>On receiving DownLinkAck_ind_IH invoke ISDUMsg.req with ISDU abortion:</i> ISDUMsg.req (flowCtrl = ABORT). Invoke negative DL_ ISDUtransport confirmation In case of low energy W-Device : Invoke MCmd.req(PreDLink) to switch low energy W-Device to PreDownLink
T12	2	4	-
T13	4	1	<i>In case of lost communication, the Message handler informs the DL-mode handler which in turn uses the administrative call IH_Conf_INACTIVE. No actions during this transition required.</i>
T14	1	0	-
T15	3	4	-
T16	5	4	-
T17	2	4	-
T18	1	1	<i>No ISDU data to send.</i> Invoke ISDUMsg.req(SendWMessage = NO).
T19	3	3	<i>No ISDU data to send.</i> Invoke ISDUMsg.req(SendWMessage = NO).
T20	5	5	<i>No ISDU data to send.</i> Invoke ISDUMsg.req(SendWMessage = NO).
T21	2	5	-
T22	2	5	-
T23	1	2	Set InitService to READ In case of low energy W-Device: Invoke MCmd.req(FullDLink) and wait for pos. Acknowledge from Cmd handler to switch low energy W-Device to FullDownLink
T24	1	2	Set InitService to WRITE In case of low energy W-Device: Invoke MCmd.req(FullDLink) and wait for pos. Acknowledge from Cmd handler to switch low energy W-Device to FullDownLink
T25	3	1	Return DL_Write.cnf

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T26	6	1	Return positive DL_Read confirmation when last segment (EOS) has been received (see clause 7.7.1 Transmission of segmented data) In case of low energy W-Device : Invoke MCmd.req(PreDLink) to switch low energy W-Device to PreDownLink

3131

INTERNAL ITEMS	TYPE	DEFINITION
Data written	Service	Last segment (EOS) has been received and acknowledged
ISDUTime	Time	Measurement of W-Device response time (ISDU acknowledgement time, see Table 97 in REF 1)
Error	Variable	Any detectable error within the ISDU transmission or DL_ISDUAbort requests, or any violation of the ISDU acknowledgement time
InitService	Guard	Variable to store the service request DL_ISDUTransport.req = ISDU DL_Read.req = READ DL_Write.req = WRITE

3132

7.4.2 State machine of the W-Device ISDU handler

3133

Figure 73 shows the state machine of the W-Device ISDU handler.

3134

3135




Figure 73 State machine of the W-Device ISDU handler

3136

3137

3138

3139

Table 69 State transition tables of the W-Device ISDU handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through IH_Conf_ACTIVE (see Table 63, Transition T2).
Idle_1	Waiting for next ISDU transmission
ISDURequest_2	Reception of ISDU request. ISDU data transmission uses the mechanism of segmented data transfer "Transmission of Segmented Data (PD, EV, ISDU)". For Retry-Handling see 7.7.2 "Retry-Handling of segmented Data (PD, EV, ISDU)".
ISDUWait_3	Waiting for data from application layer to transmit (see DL_ISDUtransport)
ISDUWaitParam_4	Waiting for data from system management to transmit (see DL_Read)
ISDUResponse_5	Transmission of ISDU response data via Message handler. ISDU data transmission uses the mechanism of segmented data transfer "Transmission of Segmented Data (PD, EV, ISDU)". For Retry-Handling see 7.7.2 "Retry-Handling of segmented Data (PD, EV, ISDU)".

3140

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Activation by the W-Device DL-mode handler.
T2	1	2	Start receiving of ISDU request data.
T3	2	2	Receive ISDU request data.
T4	2	3	Invoke DL_ISDUtransport.ind to AL if last segment (EOS without data, see clause 7.1.9) has been received
T5	3	0	Deactivation by the W-Device DL-mode handler.
T6	3	5	Response from AL.
T7	5	5	Message handler requests ISDU response. Invoke ISDUMsg.rsp(SendWMessage = YES, Data, Length, FlowCtrl) to deliver ISDU response data to Message handler.
T8	5	1	-
T9	2	1	Invoke DL_ISDUAbort
T10	3	1	Invoke DL_ISDUAbort
T11	5	1	Invoke DL_ISDUAbort
T12	1	0	Deactivation by the W-Device DL-mode handler
T13	2	1	Signal ISDU error
T14	2	0	Deactivation by the W-Device DL-mode handler
T15	5	0	Deactivation by the W-Device DL-mode handler
T16	2	1	Invoke DL_Write.ind to SM if last segment (EOS without data, see clause 7.1.9) has been received, see clause 7.1.13.
T17	2	4	Invoke DL_Read.ind to SM if last segment (EOS without data, see clause 7.1.9) has been received, see 7.1.12.
T18	4	0	Deactivation by the W-Device DL-mode handler.
T19	4	5	Response from SM.

3141

INTERNAL ITEMS	TYPE	DEFINITION
ISDUStart	Service	ISDUMsg.ind(Data, Length, Start)
ISDUWrite	Service	ISDUMsg.ind(Data, Length, FlowCtrl)
ISDUReceiveComplete	Guard	If ISDUMsg.ind(EOS) received
ISDURespStart	Service	DL_ ISDUTransport.rsp(ValueList)
ISDUSendComplete	Guard	If ISDUMsg.rsp(EOS) sent and acknowledged
ISDUAbort	Service	ISDUMsg.ind(Abort)
ISDUError	Guard	If ISDU structure is incorrect
ISDUType	Guard	This variable shall be set to the following values: WRITE (ISDU write with index from Table 171) READ (ISDU read with index from Table 171) ISDU (ISDU read or write and no index from Table 171)

3142
3143
3144
3145
3146
3147
3148
3149
3150

7.4.3 General structure and encoding of ISDUs

The encoding of ISDU data (I-Service-octet and data) delivered by the ISDU handler shall be implemented equal to IO-Link (see A.5 in REF 1.), with the exception of the definition of the nibble "I-Service". This specification shall only support the I-Service Read Request or Write Request with 16-bit Index and Subindex, as defined in Table 70.

Table 70 Definition of the nibble "I-Service"

I-Service (binary)	Definition		Index format
	W-Master	W-Device	
0000	Reserved	Reserved	
0001	Reserved	Reserved	
0010	Reserved	Reserved	
0011	Write Request	Reserved	16-bit Index and Subindex
0100	Reserved	Write Response (-)	none
0101	Reserved	Write Response (+)	none
0110	Reserved	Reserved	
0111	Reserved	Reserved	
1000	Reserved	Reserved	
1001	Reserved	Reserved	
1010	Reserved	Reserved	
1011	Read Request	Reserved	16-bit Index and Subindex
1100	Reserved	Read Response (-)	none
1101	Reserved	Read Response (+)	none
1110	Reserved	Reserved	
1111	Reserved	Reserved	

3151
3152

7.5 Command handler

The Command handler translates change requests for W-Device mode from W-Master’s system management into corresponding MasterCommands.

7.5.1 State machine of the W-Master command handler




Figure 74 State machine of the W-Master command handler

Table 71 State transition tables of the W-Master command handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by W-Master DL-mode handler through CH_Conf_ACTIVE (see Table 62 DL-mode handler).
Idle_1	Waiting for new command from SM: DL_SetMode (change W-Device mode, for example to OPERATE), or waiting on DownLinkAck service primitive.
MasterCommand_2	Prepare data for MCmd.req service primitive. Waiting for demand from DownLinkAck service
WaitForIMA_3	Waiting for low energy W-Device to wake up and transmit an IMA message
WakeUpAck_4	Waiting for Ack on WakeUp MasterCommand
WakeUpTime_5	Check if low energy W-Device is awake
JumpSequence_6	Jump sequence started, waiting for an acknowledgement
WaitForJump_7	Countdown until end of Jump sequence

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>Activation by DL-mode handler.</i>
T2	1	1	The service DL_Write(DEVICEMODE) translates into: INACTIVE: MCcmd.req (MasterCommand = 0x5C) STARTUP: MCcmd.req (MasterCommand = 0x97) PREOPERATE: MCcmd.req (MasterCommand = 0x9A) OPERATE: MCcmd.req (MasterCommand = 0x99) For further MasterCommand definitions see Table 165.
T3	2	2	PreDownLink already in use, invoke MCcmd.req(SendWMessage=NO).
T4	2	2	Invoke MCcmd.req(SendWMessage=YES, Slot_N, MasterCommand, PreDLink) to send MasterCommand in PreDownLink.
T5	2	2	Not enough space left in the FullDownLink, invoke MCcmd.req(SendWMessage=NO).
T6	2	2	Invoke MCcmd.req(SendWMessage=YES, Slot_N, MasterCommand, FullDLink) to send MasterCommand in FullDownLink.
T7	2	1	Invoke MCcmd.req(SendWMessage=NO) Invoke a positive DL_Write confirmation in case of: MasterCommand = 0x5C (Inactive) MasterCommand = 0x5F (UnParing) MasterCommand = 0x96 (DeviceIdent) MasterCommand = 0x97 (DeviceStartup) MasterCommand = 0x99 (DeviceOperate) MasterCommand = 0x9A (DevicePreoperate)
T8	1	1	No MasterCommand to send, invoke MCcmd.req(SendWMessage=NO).
T9	1	0	<i>Deactivation by DL-mode handler.</i>
T10	1	3	-
T11	3	4	Invoke MCcmd.req(SendWMessage=YES, Broadcast=NO, WakeUp, PreDLink)).
T12	4	1	Set WakeUpTimer = 0 Invoke PL_CmdTrig.req(WAKE_UP_TIME)
T13	1	5	if low energy W-Device is awake Invoke PL_CmdTrig.req(W_DEVICE_AWAKE) else invoke PL_CmdTrig.req(W_DEVICE_NOT_AWAKE)
T14	5	1	A low energy W-Device did not wake up, update is aborted.
T15	5	6	JumpCounter = MaxJump Invoke MCcmd.req(SendWMessage=YES, Broadcast=YES, JUMP, PreDLink)
T16	1	6	JumpCounter = MaxJump Invoke MCcmd.req(SendWMessage=YES, Broadcast=YES, JUMP, PreDLink)
T17	6	6	W-Device did not Acknowledge, decrease JumpCounter by 1. Invoke MCcmd.req(SendWMessage=YES, Broadcast=YES, JUMP, PreDLink)
T18	6	7	Decrease JumpCounter by 1
T19	7	7	Decrease JumpCounter by 1
T20	7	1	Invoke PL_CmdTrig.req(JUMP)
T21	6	1	Invoke PL_CmdTrig.req(JUMP_FAIL)

3164

INTERNAL ITEMS	TYPE	DEFINITION
DEVICEMODE	Label	Any of the MasterCommand definitions: INACTIVE, STARTUP, PREOPERATE or OPERATE For wireless, additional MasterCommand definitions are available (see Table 165.Mastercommand)
WakeUpTimer	Variable	This variable is a counter to WakeUpTime
WakeUpTime	Variable	This variable is the WakeUpTime of the low energy W-Device
JumpCounter	Variable	This variable is a countdown for switching to new hopping table
MaxJump	constant	Max number of jump retries, MaxJump = 0xE

3165

3166


7.5.2 State machine of the W-Device command handler

3167

Figure 75 shows the W-Device state machine of the Command handler. It is driven by MasterCommands from the Master's Command handler to control the W-Device modes.

3168

3169



3170

Figure 75 State machine of the W-Device command handler

3171

Table 72 State transition tables of the W-Device Cmd handler

3172

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation
Idle_1	Waiting for next MasterCommand
Command_Handler_2	Decompose MasterCommand and invoke specific actions: If MasterCommand = 0x5C then change W-Device state to INACTIVE. If MasterCommand = 0x97 then change W-Device state to STARTUP. If MasterCommand = 0x9A then change W-Device state to PREOPERATE. If MasterCommand = 0x99 then change W-Device state to OPERATE. For the complete MasterCommand list see Table 165
SetWakeUpTime_3	Wait for WakeUpTime to be set in SM
JumpHandler_4	Countdown until end of Jump sequence

3173

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Activation by the W-Device DL-mode handler through CH_Conf_ACTIVE.
T2	1	2	MasterCommand received Invoke DL_Write.ind(0x0000, 0x01, MCmd)
T3	2	1	Changing of W-Device State is accomplished
T4	1	0	Deactivation by the W-Device DL-mode handler through CH_Conf_INACTIVE.
T5	1	3	Set WakeUpTimer = 0, Increment by 1 every W-Sub-Cycle Invoke PL_CmdTrig.req(WAKE_UP_TIME)
T6	3	1	Set WakeUpTime value given by PL
T7	1	4	Set JumpCounter = last 4 bits of JUMP MCmd
T8	4	1	Invoke PL_CmdTrig.req(JUMP)

3174

INTERNAL ITEMS	TYPE	DEFINITION
DEVICEMODE	Label	Any of the MasterCommand definitions: INACTIVE, STARTUP, PREOPERATE or OPERATE For wireless, additional MasterCommand definitions are available (see Table 165.Mastercommand)
WakeUpTimer	Variable	This variable is a counter to WakeUpTime
WakeUpTime	Variable	This variable is the WakeUpTime of the low energy W-Device
JumpCounter	Variable	This variable is a countdown for switching to new hopping table

3175

3176

7.6 Event handler

3177

An Event transfers a status or an error information.

3178

3179

The Event request is sent from W-Device to Master. It is then processed by the Master and an Event Confirmation is sent back to the Device. Events are serviced one by one, so further Event requests are ignored until the current Event has been serviced and confirmed.

3180

3181

3182

The general structure and coding of Events is specified in Annex A.6. in REF 1

3183

EventCodes are specified in Table 180.

3184

7.6.1 State machine of the W-Master Event handler




Figure 76 State machine of the W-Master Event handler

Table 73 State transition tables of the W-Master Event handler DL

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation
Idle_1	Waiting for next Event indication
ReadEvent_2	Get Event data from W-Device through service Event indication. EV data transmission uses the mechanism of segmented data transfer (see 7.7.1 "Transmission of Segmented Data (PD, EV, ISDU)"). For Retry-Handling see 7.7.2
ConfEvent_3	Waiting for Event confirmation through service DL_Event.rsp from W-Master AL.
SendConf_4	Wait for DownLinkAck_ind_EV For Retry-Handling see 7.7.2

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	-
T2	1	2	Get Event StatusCode octet from service EventMsg.ind
T3	2	2	Get segmented data from EventMsg.ind
T4	2	3	After last segment (no data and EOS) has been received (see clause 7.7.1 Transmission of segmented data) invoke DL_Event indication to Master AL

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T5	3	4	-
T6	4	4	If enough space left in the downlink, invoke EventMsg.rsp(SendWMessage = YES, Slot_N) to deliver Event confirmation to Message handler
T7	4	1	-
T8	1	1	No Event confirmation to send, invoke EventMsg.rsp(SendWMessage = NO).
T9	2	2	No Event confirmation to send, invoke EventMsg.rsp(SendWMessage = NO).
T10	3	3	No Event confirmation to send, invoke EventMsg.rsp(SendWMessage = NO).
T11	0	0	No Event confirmation to send, invoke EventMsg.rsp(SendWMessage = NO).
T12	1	0	-
T13	2	0	-
T14	3	0	-
T15	4	0	-

3191




Figure 77 Sequence diagram: Single event scheduling

3192
3193

7.6.2 State machine of the W-Device Event handler

Figure 78 shows the state machine of the W-Device Event handler.




Figure 78 State machine of the W-Device Event handler

Table 74 State transition tables of the W-Device Event handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation by the W-Device DL-mode handler through EH_Conf_ACTIVE (see Table 63, Transition T1).
Idle_1	Waiting for Event indicated by DL_Event from application.
EventActive_2	Handler active and waiting for UpLinkAck_ind_EV.
HandleEvent_3	Handle EV data. EV data transmission uses the mechanism of segmented data transfer and retry handling, see clause 7.7.
EventWaitConf_4	Waiting for Event confirmation received from W-Master.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>Activation by the W-Device DL-mode handler through EH_Conf_ACTIVE.</i>
T2	1	2	Service DL_Event from AL indicates the occurrence of an Event.
T3	2	3	Message handler requests EV-Data through UpLinkAck_ind_EV. Invoke EventMsg.req(SendWMessage = YES, Data, Length, FlowCtrl) to deliver Event Data to Message handler.
T4	3	2	-
T5	3	4	Last EV transmission is complete (EOS without data) and acknowledged by W-Master see 7.7.1.
T6	4	1	<i>Event confirmation received from W-Master.</i> Invoke DL_Event.cnf
T7	4	0	<i>Deactivation by the W-Device DL-mode handler through EH_Conf_INACTIVE.</i> Invoke DL_Event.cnf(ErrorInfo = NO_COMM)
T8	1	0	<i>Deactivation by the W-Device DL-mode handler through EH_Conf_INACTIVE.</i>
T9	2	0	<i>Deactivation by the W-Device DL-mode handler through EH_Conf_INACTIVE.</i> Invoke DL_Event.cnf(ErrorInfo = NO_COMM)
T10	1	1	No Event to send, invoke EventMsg.req(SendWMessage = NO)
T11	0	0	No Event to send, invoke EventMsg.req(SendWMessage = NO)
T12	0	0	Invoke DL_Event.cnf(ErrorInfo = STATE_CONFLICT)

3203

INTERNAL ITEMS	TYPE	DEFINITION
Event complete	Service	EOS without data received and acknowledged

3204

3205

3206

7.7 Transmission of Segmented Data and retry handling

3207

3208

3209

3210

Data which can't be sent in one message have to be transmitted within a number of segments. To achieve a proper mechanism particularly in combination with possible retransmits, each DL-B handler (Process Data handler, ISDU handler and Event handler) must generate its own Flow Control considering the acknowledge of the last sent W-Message.

3211

7.7.1 Transmission of segmented Data

3212

3213

3214

3215

3216

The transmission of segmented data is possible for Process Data (e.g. for distribution of process data within a W-Cycle, see Figure 68, Events and ISDU Data). The ULink and DLink Control Octets accommodates a counter (=FlowControl). FlowControl is controlling the segmented data flow by counting the sequences necessary to transmit segmented data (see Table 75).

3217

3218

3219

3220

3221

3222

3223

3224

3225

3226

3227

- A segment begins with FlowControl = START.
- All following segments use FlowControl = COUNT to number each data segment. In case of a retry during COUNT, take account to 7.7.2.
- The transmission of the last segment differs between Process Data and Event- or ISDU-data:
 - a. Last segment for Process Data Out (transmitted via DLink):
To indicate a complete data transmission to W-Device set FlowControl = EOS immediately.
 - b. Last segment for Process Data In (transmitted via ULink):
To indicate a complete data transmission to W-Master set FlowControl = PDataLength (see Table 75 column Process Data In)
 - c. Last segment for acyclic Event- and ISDU-data (transmitted via DLink or ULink):
To indicate a complete data transmission, the Event handler or ISDU-handler shall send a

separate W-Message with FlowControl = EOS and without data to achieve data consistency due to retransmits.

Note:

A MasterCommand as well as an Event acknowledge doesn't need segmentation, since this W-Message are transmitted without data (see Table 42).

Table 75 Flow Control for segmented data

FlowControl (FC)			
FlowControl (FC)	Definition		
0x00 to 0x07	COUNT Counter within a data segment. Increments beginning with 1 after an START. Jumps back from 7 to 0 in case of an overflow.		
0x08	START Start of a segment, i.e., start of a ISDU- request or a response. For the start of a request, any previously incomplete service may be rejected. For a start request associated with a response, a W-Device shall send "No Service" until its application returns response data		
0x09	EOS End of Segment indicates a completed transmission. (Event- or ISDU: separate EOS within next DLink)		
0x0A	ABORT Abort entire service. The W-Master responds by rejecting received response data. The W-Device responds by rejecting received request data and may generate an abort.		
	Definition for <u>DLink</u> Control Octet See Note 1	Definition for <u>ULink</u> Control Octet See Note 2	
		Process Data In (data transmission complete)	Event- or ISDU data (separate EOS within next ULink)
0x0B	Unused	PDataLength = 1 octet	DataLength = 1 octet
0x0C...0x17	Unused	PDataLength = 2...13 octet	DataLength = 2...13 octet
0x18	Unused	PDataLength = 14 octet	DataLength = 14 octet
0x19 to 0x1F	Reserved	Reserved	Reserved

Note 1:

The DLink Control Octet (see Figure 134) contains a separate field to transmit the length of data. Therefore, these values are unused.

Note 2:

The ULink Control Octet (see Figure 136) is coded by only one octet (reduced overhead). Therefore, the DataLength is coded within the Flow Control.

Additionally see 12.6. Example for DLink data transmission and 12.7 Examples for ULink data transmission for data transmission examples.

7.7.2 Retry-Handling

For an appropriate data transmission, the "Sender" shall retransmit its last W-Message, if the service DownLinkAck or UpLinkAck delivered a negative Acknowledge (NACK or not received message) to the corresponding handler (ProcessData-, Event-, Command-, or ISDU-handler) see 5.5.2.8.

7.7.2.1 Retry handling in case of not Segmented data

The corresponding handler shall retransmit its last W-Message, depending on the remaining payload in the DLink or ULink (see service 6.3.4 DownLinkAck and 6.3.5 UpLinkAck)

3253 7.7.2.2 Retry handling in case of Segmented data / Flow Control

3254 If the "Sender" does not receive an ACK for its last sent W-Message, it has to forward NACK to the layer
3255 above and it has to resend the last data and the value of the last FlowCtrl.

3256 If the "Receiver" thereupon gets new FlowCtrl = last FlowCtrl, it has to reject the last received data segment
3257 and use the new received data segment instead. This behavior is essentially, since a W-Message with a
3258 ACK could be corrupted (e.g. on air), which leads in a NACK on the receiver side.

3259
3260 Note: "Sender" or "Receiver" can be W-Master or W-Device

3261

8. Application Layer (AL)

8.1 General

Figure 79 shows an overview of the structure and services of the W-Master application layer(AL)




Figure 79 Structure and services of the application layer (W-Master)

Figure 80 shows an overview of the structure and services of the W-Device application layer (AL).




Figure 80 Structure and services of the application layer (W-Device)

8.2 Application Layer services

This clause defines the services of the application layer (AL) to be provided to the W-Master and W-Device applications and system management via its external interfaces. Table 76 lists the assignments of W-Master and W-Device to their roles as initiator or receiver for the individual AL services. Empty fields indicate no availability of this service on W-Master or W-Device.

Table 76 AL services within W-Master and W-Device

Service name	W-Master	Device
AL_Read	R	I
AL_Write	R	I
AL_Abort	R	I
AL_NewInput	I	
AL_GetInput	R	
AL_SetInput		R
AL_PDTrig	I	I
AL_GetOutput		R
AL_NewOutput		I
AL_SetOutput	R	
AL_Event	I	R
AL_Control	I, R	I, R
Key (see 3.3.5) All services are defined from the view of the affected layer towards the layer above. - I Initiator of a service (towards the layer above) - R Receiver (responder) of a service (from the layer above)		

8.2.1 AL_Read (W-Master and W-Device)

The AL_Read service is used to read ISDU Data from a IO-Link Wireless W-Device connected to a specific W-Port. The parameters of the service primitives are listed in Table 77.

Table 77 AL_Read

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
W-Port	M			
Index	M	M		
Subindex	M	M		
Result (+)			S	S(=)
W-Port				M
Data			M	M(=)
Result (-)			S	S(=)
W-Port				M
ErrorInfo			M	M(=)

Argument

The service-specific parameters are transmitted in the argument.

W-Port

This parameter contains the W-Port number for the ISDU Data to be read.

Index

This parameter indicates the address of the ISDU Data objects to be read from the W-Device.

Index 0 in conjunction with Subindex 0 addresses the entire set of Direct Parameters in Page 1 or in conjunction with Subindex 1 to 16 the individual parameters.

3293 Index 1 in conjunction with Subindex 0 addresses the entire set of Direct Parameters in Page 2 or
 3294 in conjunction with Subindex 1 to 16 the individual parameters from address 16 to 31 (W-Bridge).
 3295 Subindex 0 in conjunction with the wireless parameter page addresses the entire set of Wireless
 3296 Parameters (see Extended Parameter Pages for IO-Link Wireless in Table 168).
 3297 Permitted values: 0 to 65535 (Figure 155 parameter via ISDU)
 3298 **Subindex**
 3299 This parameter indicates the element number within a structured ISDU Data object. A value of 0
 3300 indicates the entire set of elements.
 3301 Permitted values: 0 to 255
 3302 **Result (+):**
 3303 This selection parameter indicates that the service has been executed successfully.
 3304 **W-Port**
 3305 This parameter contains the W-Port number of the requested ISDU Data.
 3306 **Data**
 3307 This parameter contains the read values of the ISDU Data.
 3308 Parameter type: Octet string
 3309 **Result (-):**
 3310 This selection parameter indicates that the service failed.
 3311 **W-Port**
 3312 This parameter contains the W-Port number of the requested ISDU Data.
 3313 **ErrorInfo**
 3314 This parameter contains the error information.
 3315 Permitted values: see Clause 13.8, see Annex C in REF 1
 3316 NOTE: The AL maps DL ErrorInfos into its own AL ErrorInfos using Annex C in REF 1
 3317
 3318

3319 **8.2.2 AL_Write (W-Master and W-Device)**

3320 The AL_Write service is used to write ISDU Data to a IO-Link Wireless W-Device connected to a specific
 3321 W-Port. The parameters of the service primitives are listed in Table 78.
 3322
 3323

Table 78 AL_Write

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M		
W-Port	M			
Index	M	M		
Subindex	M	M		
Data	M	M(=)		
Result (+)			S	S(=)
W-Port				M
Result (-)			S	S(=)
W-Port				M
ErrorInfo			M	M(=)

3324 **Argument**

3325 The service-specific parameters are transmitted in the argument.

3326 **W-Port**

3327 This parameter contains the W-Port number for the ISDU Data to be written.

3328 **Index**

3329 This parameter indicates the address of the ISDU Data objects to be written to the W-Device.

3330 Indexes from Table 171 always return a negative result.

3331 Index 1 in conjunction with Subindex 0 addresses the entire set of Direct Parameters in Page 2 or
 3332 in conjunction with Subindex 1 to 16 the individual parameters from address 16 to 31 (W-Bridge),
 3333 it returns always a positive result.

3334 Permitted values: 0 to 65535
 3335 **Subindex**
 3336 This parameter indicates the element number within a structured ISDU Data object. A value of 0
 3337 indicates the entire set of elements (only possible if all subindices have write access rights!).
 3338 Permitted values: 0 to 255
 3339 **Data**
 3340 This parameter contains the values of the ISDU Data.
 3341 Parameter type: Octet string
 3342 **Result (+):**
 3343 This selection parameter indicates that the service has been executed successfully.
 3344 **W-Port**
 3345 This parameter contains the W-Port number of the ISDU Data.
 3346 **Result (-):**
 3347 This selection parameter indicates that the service failed.
 3348 **W-Port**
 3349 This parameter contains the W-Port number of the ISDU Data.
 3350 **ErrorInfo**
 3351 This parameter contains the error information.
 3352 Permitted values: see clause 13.8, see IO-Link Interface and System Specification Annex C in REF
 3353 1
 3354

3355 **8.2.3 AL_Abort (W-Master and W-Device)**

3356 The AL_Abort service is used to abort a current AL_Read or AL_Write service on a specific W-Port.
 3357 Invocation of this service abandons the response to an AL_Read or AL_Write service in progress on the
 3358 W-Master. The parameters of the service primitives are listed in Table 79
 3359
 3360

Table 79 AL_Abort

Parameter Name	.req	.ind
Argument	M	M
W-Port	M	

3361 **Argument**

3362 The service-specific parameters are transmitted in the argument.

3363 **W-Port**

3364 This parameter contains the W-Port number of the service to be abandoned
 3365

3366 **8.2.4 AL_NewInput (W-Master)**

3367
 3368 The AL_NewInput local service indicates the receipt of updated input data within the Process Data of a W-
 3369 Device connected to a specific W-Port. The parameters of the service primitives are listed in
 3370 Table 80.
 3371
 3372

Table 80 AL_NewInput

Parameter Name	.ind
Argument	M
W-Port	M

3373 **Argument**

3374 The service-specific parameters are transmitted in the argument.

3375 **W-Port**

3376 This parameter specifies the W-Port number of the received Process Data
 3377
 3378

8.2.5 AL_GetInput (W-Master)

The AL_GetInput service reads the input data within the Process Data provided by the data link layer of a W-Device connected to a specific W-Port. The parameters of the service primitives are listed in Table 81

Table 81 AL_GetInput

Parameter Name	.req	.cnf
Argument	M	
W-Port	M	
Result (+)		S
W-Port		M
InputData		M
Result (-)		S
W-Port		M
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

W-Port

This parameter specifies the W-Port number of the received Process Data.

Result (+):

This selection parameter indicates that the service has been executed successfully.

W-Port

This parameter specifies the W-Port number of the received Process Data.

InputData:

This parameter contains the values of the requested process input data of the specified W -Port.

Parameter type: Octet string

Result (-):

This selection parameter indicates that the service failed.

W-Port

This parameter contains the W-Port number for the Process Data.

ErrorInfo

This parameter contains the error information. Permitted values: NO_DATA (DL did not provide Process Data)

8.2.6 AL_SetInput (W-Device)

The AL_SetInput local service updates the input data within the Process Data of a W-Device. The parameters of the service primitives are listed in Table 82.

Table 82 AL_SetInput

Parameter Name	.req	.cnf
Argument	M	
InputData	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

InputData

This parameter contains the Process Data values of the input data to be transmitted.

3412 Parameter type: Octet string
 3413 **Result (+):**
 3414 This selection parameter indicates that the service has been executed successfully.
 3415 **Result (-):**
 3416 This selection parameter indicates that the service failed.
 3417 **ErrorInfo**
 3418 This parameter contains the error information.
 3419 Permitted values:
 3420 NO_COMM (no communication available),
 3421 STATE_CONFLICT (service unavailable within current state)
 3422

3423 **8.2.7 AL_PDTrig (W-Master and W-Device)**

3424
 3425 The AL_PDTrig service indicates the end of a W-MasterCycleTime period after each start of Process Data
 3426 reception. The W-Device application can use this service to achieve equidistant Process Data periods (see
 3427 Note 1) by eliminating jitter due to retry handling.
 3428 The parameters of the service primitives are listed in Table 83.
 3429
 3430

Table 83 AL_PDTrig

Parameter Name	.ind
Argument	M
W-Port	C

3431 **Argument**

3432 The service-specific parameters are transmitted in the argument.

3433 **W-Port**

3434 This parameter contains the W-Port number of the received new Process Data (W-Master only).
 3435 Note 1: To minimize Jitter caused by different transmission qualities, especially with segmented data
 3436 (variations on the numbers of retries) PDTrig can be used to get an equidistant time between
 3437 reception of first data packet and activation of PDTrig.
 3438

3439 **8.2.8 AL_GetOutput (W-Device)**

3440 The AL_GetOutput service reads the output data within the Process Data provided by the data link layer
 3441 of the W-Device. The parameters of the service primitives are listed in Table 84.
 3442
 3443

Table 84 AL_GetOutput

Parameter Name	.req	.cnf
Argument	M	
Result (+)		S
OutputData		M
Result (-)		S
ErrorInfo		M

3444 **Argument**

3445 The service-specific parameters are transmitted in the argument.

3446 **Result (+):**

3447 This selection parameter indicates that the service has been executed successfully.

3448 **OutputData**

3449 This parameter contains the Process Data values of the requested output data.
 3450 Parameter type: Octet string

3451 **Result (-):**

3452 This selection parameter indicates that the service failed.

3453 **ErrorInfo**

3454 This parameter contains the error information.

3455 Permitted values:
 3456 NO_DATA (DL did not provide Process Data)
 3457

3458 **8.2.9 AL_NewOutput (W-Device)**

3459 The AL_NewOutput local service indicates the receipt of updated output data within the Process Data of a
 3460 W-Device. This service has no parameters. The service primitives are shown in Table 85.

Table 85 AL_NewOutput

Parameter name	.ind
<None>	

3463

3464 **8.2.10 AL_SetOutput (W-Master)**

3465 The AL_SetOutput local service updates the output data within the Process Data of a W-Master. The
 3466 parameters of the service primitives are listed in Table 86.

Table 86 AL_SetOutput

Parameter Name	.req	.cnf
Argument	M	
W-Port	M	
OutputData	M	
Result (+)		S
W-Port		M
Result (-)		S
W-Port		M
ErrorInfo		M

3469

Argument

3470 The service-specific parameters are transmitted in the argument.

W-Port

3471 This parameter contains the W-Port number of the Process Data to be written.

OutputData

3472 This parameter contains the output data to be written at the specified W-Port.

3473 Parameter type: Octet string

Result (+):

3474 This selection parameter indicates that the service has been executed successfully.

W-Port

3475 This parameter contains the W-Port number for the Process Data.

Result (-):

3476 This selection parameter indicates that the service failed.

W-Port

3477 This parameter contains the W-Port number for the Process Data.

ErrorInfo

3478 This parameter contains the error information.

3479 Permitted values:

3480 NO_COMM (no communication available),

3481 STATE_CONFLICT (Service unavailable within current state)

3482

3483

8.2.11 AL_Event (W-Master and W-Device)

The AL_Event service indicates one pending status or error message. The source of one Event can be local (W-Master) or remote (W-Device). The Event can be triggered by a communication layer or by an application. The parameters of the service primitives are listed in Table 87.

Table 87 AL_Event

Parameter Name	.req	.ind	.rsp	.cnf
Argument	M	M	M	
W-Port		M	M	
Instance	M	M		
Mode	M	M		
Type	M	M		
Origin		M		
EventCode	M	M		
Result (+)				S
Result (-)				S
ErrorInfo				M

Argument

The service-specific parameters are transmitted in the argument.

W-Port

This parameter contains the W-Port number of the Event data. **Instance**

This parameter indicates the Event source. Permitted values: Unknown, Application (see Table 136, see Table A.17 in REF 1)

Mode

This parameter indicates the Event mode. Permitted values: SINGLESHOT, APPEARS, DISAPPEARS (see Table 139, see Table A.20 in REF 1)

Type

This parameter indicates the Event category. Permitted values: ERROR, WARNING, NOTIFICATION (see Table 180, see Table A.19 in REF 1)

Origin

This parameter indicates whether the Event was generated in the local communication section or remotely (in the W-Device). Permitted values: LOCAL, REMOTE

EventCode

This parameter contains a code identifying a certain Event. Permitted values: see Table 180, see Annex D in REF 1)

Result (+):

This selection parameter indicates that the service has been executed successfully.

Result (-):

This selection parameter indicates that the service failed.

ErrorInfo

This parameter contains the error information.

Permitted values: STATE_CONFLICT (Service unavailable within current state), NO_COMM (no communication available)

8.2.12 AL_Control (W-Master and W-Device)

The AL_Control service contains the Process Data qualifier status information transmitted to and from the W-Device application. The parameters of the service primitives are listed in Table 88.

Table 88 AL_Control

Parameter Name	.req	.ind
Argument	M	M
W-Port	C	C
ControlCode	M	C
MaxRetry		C

Argument

The service-specific parameters are transmitted in the argument.

W-Port

This parameter contains the number of the related W-Port.

ControlCode

This parameter contains the qualifier status of the Process Data (PD).

Permitted values:

PDIN_VALID (Input Process Data valid)

PDIN_INVALID (Input Process Data invalid)

PDOUT_VALID (Output Process Data valid, see Table 135).

PDOUT_INVALID (Output Process Data invalid, see Table 135).

MaxRetry (W-Device only)

This parameter contains information of a real-time fault.

Permitted Values:

YES (MaxRetry occurred)

NO (MaxRetry not occurred)

8.3 Application layer protocol

8.3.1 Overview


The application layer manages the data transfer with all its assigned W-Ports. That means, AL service calls need to identify the particular W-Port they are related to.

8.3.2 ISDU processing

8.3.2.1 ISDU state machine of the W-Master AL

Figure 81 shows the state machine for the handling of ISDU Data within the application layer. "AL_Service" represents any AL service in Table 76 related to ISDU. "W-Portx" indicates a particular wireless W-Port number

3555



3556
3557
3558

Figure 81 ISDU state machine of the W-Master AL

Table 89 State transition tables of the ISDU W-Master AL

STATE NAME	STATE DESCRIPTION
Idle_0	AL_Read or AL_Write invocations from the W-Master applications or from the W-Master Port handler (see Figure 79) can be accepted within this state.
Check_Arguments_1	Within this state the arguments of the AL_Read/AL_Write service call are checked (see 8.2.1, 8.2.2 for permitted values), and the internal items Argument_Error and Arguments_OK are set accordingly.
Await_DL_ISDU_cnf_2	The W-Master AL remains in this state until a DL_ISDUtransport.cnf is received.

3559

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	-
T2	0	1	-
T3	1	0	Invoke AL_Read.cnf/AL_Write.cnf with negative Result.
T4	1	2	Invoke DL_ISDUtransport.req.
T5	2	2	Invoke AL_Read.cnf with negative Result.
T6	2	2	Invoke AL_Write.cnf with negative Result.
T7	2	0	Invoke DL_ISDUAbort.req.
T8	2	0	Invoke AL_Read.cnf/AL_Write.cnf
T9	0	0	-


3560

INTERNAL ITEMS	TYPE	DEFINITION
Argument_Error	Bool	Illegal values within the service body, for example "W-Port number or Index out of range"
Arguments_OK	Bool	No errors in the arguments.

3561

3562 **8.3.2.2 ISDU state machine of the W-Device AL**

3563 Figure 82 shows the state machine for the handling of ISDU Data within the application layer of a W-Device.
 3564



3565

3566

3567

Figure 82 ISDU state machine of the W-Device AL

Table 90 State transition tables of the ISDU W-Device AL

STATE NAME	STATE DESCRIPTION
Idle_0	The W-Device AL is waiting on subordinated DL service calls triggered by W-Master messages.
Await_AL_RW_rsp_1	The W-Device AL is waiting on a response from the technology specific application (read or write access via ISDU).

3568

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke AL_Read.
T2	0	1	Invoke AL_Write.
T3	1	0	Invoke DL_ISDUTransport(read)
T4	1	0	Invoke DL_ISDUTransport(write)
T5	1	0	Current waiting on AL_Read or AL_Write abandoned.

3569

INTERNAL ITEMS	TYPE	DEFINITION
DirRead	Bool	Access direction: DL_ISDUTransport(read) causes an AL_Read
DirWrite	Bool	Access direction: DL_ISDUTransport(write) causes an AL_Write

3570
3571
3572
3573
3574

8.3.2.3 Sequence diagrams for ISDU Data

Figure 83 through Figure 86 demonstrate complete interactions between W-Master and W-Device for several ISDU Data exchange use cases.





Figure 83 Sequence diagram: ISDU Read Data

3575
3576

3577
3578

Figure 84 demonstrates the behavior of ISDU Data exchange in case of a timeout (5 s). A W-Device shall respond within less than the "ISDU acknowledgement time" (see clause 10.7.5 in REF 1).




3579

Figure 84 Sequence diagram: ISDU read Data in case of timeout

3580
3581

Figure 85 demonstrates the behavior of ISDU Data exchange in case of an error such as requested Index not available (see Table C.1 in REF 1).




3582

Figure 85 Sequence diagram: ISDU read Data in case of error

3583 Figure 86 demonstrates the behavior of ISDU Data exchange in case of interaction with a low energy W-
3584 Device.

3585
3586 If a W-Port is paired with a low energy (LP) W-Device with LowPowerDevice attribute activated, the W-
3587 Master shall send a MasterCommand to switch the LP W-Device to listen to the Full-Downlink prior to the
3588 ISDU data transmission.

3589 After ISDU data transmission, the W-Master shall send a MasterCommand to switch the LE W-Device
3590 back to Pre-Downlink.




3591 **Figure 86 Sequence diagram for low energy W-Devices: ISDU Data**
3592

3593 **8.3.3 Event processing**

3594 **8.3.3.1 Event state machine of the W-Master AL**

3595 Figure 87 shows the Event state machine of the W-Master application layer.
 3596



3597 **Figure 87 Event state machine of the W-Master AL**

3598 **Table 91 State transition tables of the Event W-Master AL**

3599

STATE NAME	STATE DESCRIPTION
Event_idle_0	The W-Master AL is ready to accept DL_Events (diagnosis information) from the DL.
DU_Event_handling_1	Analyze Event data and invoke AL_Event.ind to Diagnosis Unit. The W-Master AL remains in this state as long as the Diagnosis Unit (see 11.5) did not acknowledge the AL_Event.ind.

3600

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	1	2	Invoke AL_Event.ind
T2	2	1	Invoke DL_Event.rsp

3601

INTERNAL ITEMS	TYPE	DEFINITION
-		

3602
 3603

8.3.3.2 Event state machine of the W-Device AL

Figure 88 shows the Event state machine of the W-Device application layer




Figure 88 Event state machine of the W-Device AL

Table 92 State transition tables of the Event W-Device AL

STATE NAME	STATE DESCRIPTION
Event_Idle_0	The W-Device AL is ready to accept one AL_Event (diagnosis information) from the technology specific W-Device applications for the transfer to the DL. The W-Device applications can create one new Event during this time.
Await_Event_response_1	The W-Device AL propagated an AL_Event with diagnosis information and waits on a DL_Event confirmation of the DL. The W-Device AL shall not accept any new AL_Event during this time.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke DL_Event.req
T2	1	0	Invoke AL_Event.cnf

8.3.3.3 Single Event scheduling

Figure 93 shows how a single Event from a W-Device is processed, in accordance with the relevant state machines.




Figure 89 Sequence diagram: Single Event scheduling

8.3.4 Process Data transfer

8.3.4.1 Process Data (PD) state machine of the W-Device-AL

Figure 90 shows the Process Data state machine of the W-Device application layer




Figure 90 PD state machine of the W-Device-AL

3626

Table 93 State transition tables of the PD W-Device AL

STATE NAME	STATE DESCRIPTION
Idle_0	The W-Device AL is waiting on subordinated AL and DL service calls.

3627

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	Invoke DL_PDInputUpdate with Process Data In from AL.
T2	0	0	Read Process Data Out.
T3	0	0	Invoke AL_PDTrig.
T4	0	0	DL_PDOutputTransport delivers Process Data Out from DL. Invoke AL_NewOutput.
T5	0	0	Invoke AL_Control with Process Data Out qualifier status from DL.
T6	0	0	Invoke AL_Control with real-time fault.
T7	0	0	Invoke DL_Control with Process Data In qualifier status from AL.
T8	0	0	Invoke AL_SetInput.cnf

3628

3629

8.3.4.2 Process Data cycles

3630

Figure 91 and Figure 92 demonstrate complete interactions between W-Master and W-Device for output and input Process Data use cases.

3631


3632

Figure 74 demonstrates how the AL and DL services of W-Master and W-Device are involved in the cyclic exchange of output Process Data. The W-Device application is able to acquire the current values of output PD via the AL_GetOutput service.

3633

3634

3635



3636

Figure 91 Sequence diagram for output Process Data

3637

3638
 3639
 3640
 3641
 3642

Figure 92 demonstrates how the AL and DL services of W-Master and W-Device are involved in the cyclic exchange of input Process Data. The W-Master application is able to acquire the current values of input PD via the AL_GetInput service.




Figure 92 Sequence diagram for input Process Data

3643
 3644

3645 9. System management (SM)

3646 9.1 General

3647 The system management (SM) services are used for the coordinated startup and configuration of the
3648 possible operational modes within the W-Master and the corresponding W-Devices. Since the difference
3649 between the SM of the W-Master and the W-Device is significant, the structure of this clause separates the
3650 services and protocols of W-Master and W-Device.

3651 It must be noted that some of the functionality described in this clause is implemented within the underlying
3652 PL, such as the handling of the wireless messages.

3653 The following subclauses describe the possible operational modes and associated procedures.
3654
3655
3656

3657 9.1.1 Service Mode

3658 When a track is configured to operate in ServiceMode, the frequency hopping table also utilizes the
3659 configuration frequency channels. The ServiceMode can be configured as Scan Mode, Pairing Mode or
3660 Roaming Mode. Scan and Pairing Mode are terminating automatically after the intended procedure is
3661 completed. Roaming Mode stays permanently active and a discovery procedure is regularly carried out by
3662 issuing "Scan Request" messages on the configuration channels. This is required for the "Handover
3663 Connect" procedure.
3664

3665 9.1.2 Cyclic Mode

3666 In Cyclic Mode, the W-Master track communicates with the W-Device via the assigned data channel by
3667 utilizing the frequency hopping table without configuration frequencies. This mode is utilized with fixed W-
3668 Devices.

3669 After successful pairing of all W-Devices for a track, the W-Master can switch via SM_SetTrackMode the
3670 mode from ServiceMode to Cyclic Mode. On the W-Device, the Cyclic Mode is immediately entered after
3671 successful sending of the final "Pairing Negotiation Response". Scan, Pairing and Roaming is no longer
3672 possible on this track in this mode.

3673 9.1.2.1 IMATime monitoring

3674 The IMATime is continuously supervised within the PL. The IMATime is transferred within the extended
3675 wireless parameter set to the W-Device during the STARTUP procedure via SM_SetPortConfig.

3676 The monitoring is started after the W-Device is synchronized. In case of an IMATimeout a COMLOST and
3677 an IOLW_IMATimeout event (see clause 15.1) will be generated towards the application.

3678 When an offered IMATime (e.g. from PDCT) is rejected by the W-Device, this is indicated via an ISDU
3679 ErrorType (e.g. PAR_VALOUTOFRNG) towards the application. In this case, the W-Master executes a
3680 DL_Read(IMATime) and starts monitoring using the value from the W-Device until the application changes
3681 this setting.

3682 Note: The allowed range of the IMATime must be described in the IODD of the W-Device.

3683 9.2 System management of the W-Master

3684 9.2.1 Overview

3685 The W-Master SM


- 3686 • Establishes the required communication protocol revision.
- 3687 • Checks the W-Device compatibility (actual W-Device identifications match expected values).
- 3688 • Adjusts adequate cycle times.
- 3689 • Computes the frequency hopping tables.
- 3690 • Assigns W-Port numbers to the wireless communication relations.

3691 For this it uses the following services shown in Figure 93.

- 3692 • SM_SetMasterConfig sets the common configuration of the W-Master for all tracks.
- 3693 • SM_SetTrackMode sets the mode of a wireless track.
- 3694 • SM_GetTrackMode gets the mode of a wireless track.
- 3695 • SM_TrackScanEnd indicates the end of the scan mode.
- 3696 • SM_TrackScanResult reports a new unpaired W-Device within the track's proximity to the application.
- 3697 • SM_SetPortConfig transfers the necessary parameters (configuration data) from Configuration
3698 Management (CM) to System Management (SM). The communication is then started implicitly.

- 3699 • SM_PortMode reports the result of the setup back to CM, in case of negative result via corresponding
- 3700 "errors", such as mismatching revisions and incompatible W-Devices.
- 3701 • SM_GetPortConfig reads the actual and effective parameters.
- 3702 • SM_Operate switches the ports into the "OPERATE" mode.
- 3703 • SM_GetPortQuality delivers the quality of the port connection.
- 3704 • SM_PortPairing handles the pairing process.

3705



3706
3707
3708
3709
3710
3711

Figure 93 Structure and services of the W-Master system management

The Configuration Manager in a W-Master consists of Master Configuration Manager, Track Configuration Manager and Port Configuration Manager. During initialization, the W-Master's Configuration management (CM) first reads the configuration for the W-Master (MasterID, Blacklist). In the next step, the W-Master

3712 Configuration will be applied, and the radios will be switched on by SM_SetMasterConfig and the W-Master
 3713 starts sending Downlinks on the track specific frequency channels until it gets an answer from a W-Device
 3714 in the corresponding uplink slot. The W-Devices are then synchronized, and the W-Master application may
 3715 call the DL service DL_SetMode (STARTUP) to create the required instances of the Master DL-mode
 3716 handler.
 3717

3718 Figure 94 demonstrates the actions between the layers W-Master application (W-Master App),
 3719 Configuration Management (CM), System Management (SM), Data Link (DL) and Application Layer (AL) for
 3720 the startup use case of a particular port.
 3721

3722 This particular use case is characterized by the following statements:

- 3723 • The W-Device for the available configuration is connected and inspection is successful
- 3724 • The W-Device uses the correct RevisionID according to this specification
- 3725 • The configured InspectionLevel is "type compatible" (SerialNumber is read out of the W-Device, but
 3726 not checked).
 3727

3728 Dotted arrows in Figure 94 represent response services to an initial service.
 3729




Figure 94 Sequence chart of the use case "port x setup"

3730
3731

3732 **9.2.2 System management W-Master services**

3733
3734 **9.2.2.1 Overview**

3735 System management provides the SM W-Master services to the user via its upper interface. Table 94 lists
3736 the assignment of the W-Master to its role as initiator or receiver for the individual SM services.
3737
3738

Table 94 SM services within the W-Master

Service Name		W-Master
SM_SetMasterConfig	Set common configuration of the W-Master for all tracks	R
SM_SetTrackMode	Set mode of a wireless track	R
SM_GetTrackMode	Get mode of a wireless track	R
SM_TrackScanResult	Report a new unpaired W-Device within the track's proximity to the application	I
SM_TrackScanEnd	Indicates the end of the scan mode	I
SM_SetPortConfig	Set configuration of a virtual wireless port	R
SM_GetPortConfig	Get configuration of a virtual wireless port	R
SM_PortPairing	Pair W-Device to W-Master	R
SM_PortMode	Reports the mode of a wireless port	I
SM_GetPortQuality	Acquire quality of a W-Device connection	R
SM_Operate	Activate a wireless port	R
Key (see 3.3.5) I: Initiator of service R: Receiver (Responder) of service		

3739
3740

3741 **9.2.2.2 SM_SetMasterConfig**

3742 The SM_SetMasterConfig service is used to set up the W-Master configuration. This configuration is used
3743 for all tracks. The parameters of the service primitives are listed in Table 95
3744
3745

Table 95 SM_SetMasterConfig

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

3746 **Argument**

3747 The service-specific parameters are transmitted in the argument.

3748 **ParameterList**

3749 This parameter contains the configured master parameters of a W-Master.

3750 Parameter type: Record

3751 Record Elements:

3752 **MasterID**

3753 This parameter contains the MasterID of the W-Master (see Table 165)

3754 Permitted values: 1 to 29

3755 **BlackList**
 3756 This parameter contains the frequency channels which shall not be used by the W-Master.
 3757 Permitted values: 0x0000 0000 0000 0000 0000 to 0x7FFF FFFF FFFF FFFF FFEE
 3758 (bitwise coded 1MHz channels 2-79 (LSB first))
 3759 **SyncMaster:**
 3760 This parameter specifies the track number which shall run as W-Frame synchronization
 3761 master (see 5.5.2.1. Parameter "TrackSynchronization" in service PL_SetTrackConfig)
 3762 Permitted values:
 3763 0 (SyncMaster is track 0)
 3764 ...
 3765 4 (SyncMaster is track 4)
 3766 5 (all tracks using an external synchronization signal)
 3767 **AHTEnable:**
 3768 This parameter contains the AHT operation mode. Permitted values:
 3769 ENABLE
 3770 DISABLE
 3771 **Result (+):**
 3772 This selection parameter indicates that the service has been executed successfully
 3773 **Result (-):**
 3774 This selection parameter indicates that the service failed
 3775 **ErrorInfo**
 3776 This parameter contains the error information
 3777 Permitted values:
 3778 STATE_CONFLICT (service unavailable within current state)
 3779 PARAMETER_CONFLICT (consistency of parameter set violated)
 3780

3781 **9.2.2.3 SM_SetTrackMode**

3782 The SM_SetTrackMode service is used to set up one track with the requested track configuration. The
 3783 parameters of the service primitives are listed in Table 96.
 3784
 3785

Table 96 SM_SetTrackMode

Parameter Name	.req	.cnf
Argument	M	
TrackMode	M	
TxPower	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

3786

3787
3788
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3799
3800
3801
3802
3803
3804
3805
3806
3807
3808
3809
3810
3811
3812
3813

Argument

The service-specific parameters are transmitted in the argument.

TrackMode

This parameter indicates the requested operational modes of the track

Permitted values:

STOP (Communication disabled, radio turned off),

CYCLIC (W-Master is working in Cyclic mode (Full performance),

SCAN (W-Master is working in Scan mode (Limited performance)),

ROAMING (W-Master is working in Roaming mode. (Limited performance)).

TXPower

This parameter contains the requested transmit power level of the track

Permitted values: 1 to 255 (see Table 176).

Result (+):

This selection parameter indicates that the service has been executed successfully

Result (-):

This selection parameter indicates that the service failed

ErrorInfo

This parameter contains the error information

Permitted values:

PARAMETER_CONFLICT (consistency of parameter set violated)

STATE_CONFLICT (service unavailable within current state)

9.2.2.4 SM_GetTrackMode

The SM_GetTrackMode service is used to read the track configuration from the system management. The parameters of the service primitives are listed in Table 97.

Table 97 SM_GetTrackMode

Parameter Name	.req	.cnf
Argument	M	
Result (+)		S
ParameterList		M
Result (-)		S
ErrorInfo		M

3814
3815
3816
3817
3818
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3830
3831
3832
3833
3834
3835

Argument

The service-specific parameters are transmitted in the argument.

Result (+):

This selection parameter indicates that the service has been executed successfully

ParameterList

This parameter contains the configured track parameters of a W-Master track.

Parameter type: Record

Record Elements:

TrackMode

This parameter indicates the actual operational mode of the track

Permitted values: STOP, CYCLIC, SCAN, PAIRING, ROAMING

TXPower

This parameter contains the actual transmit power level of the track

Permitted values: 1 to 255 (see Table 176)

Result (-):

This selection parameter indicates that the service failed

ErrorInfo

This parameter contains the error information

Permitted values:

PARAMETER_CONFLICT (consistency of parameter set violated)

STATE_CONFLICT (service unavailable within current state)

9.2.2.5 SM_TrackScanResult

The SM_TrackScanResult service is used to report a new unpaired W-Device within the track’s proximity to the application. This is only done if the track is in ROAMING or SCAN mode. The parameters of the service primitives are listed in Table 98

Table 98 SM_TrackScanResult

Parameter Name	.ind
Argument	M
ParameterList	M

Argument:

The service-specific parameters are transmitted in the argument.

ParameterList

This parameter contains the information of the found W-Device.

Parameter Type: Record

Record Elements:

SlotType:

Type of the W-Device in Uplink given through W-Device application.

Permitted values: SSLOT, DSLOT (see Table 161).

UniqueID:

This parameter indicates the UniqueID of the W-Device. (see Figure 156)

RevisionID:

This parameter indicates the protocol version of the found W-Device (see clause B.1.5 in REF 1).

9.2.2.6 SM_TrackScanEnd (Master)

The SM_TrackScanEnd service is used to indicate the end of the scan mode. The parameters of the service primitive are listed in Table 99.

Table 99 SM_TrackScanEnd

Parameter Name	.ind
<none>	

9.2.2.7 SM_SetPortConfig

The SM_SetPortConfig service is used to set up the requested W-Device configuration. The parameters of the service primitives are listed in Table 100.

Table 100 SM_SetPortConfig

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
W-Port		M
Result (-)		S
W-Port		M
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

ParameterList

This parameter contains the configured W-Port and W-Device parameters of a W-Master W-Port.

3872 Parameter type: Record
 3873 Record Elements:

3874 **W-Port**
 3875 This parameter contains the W-Port number (see TDMapper, 6.1.1.).

3876 **Slot_N**
 3877 This parameter contains the Slot number within the corresponding track number (see
 3878 TDMapper, 6.1.1)

3879 **Track_N**
 3880 This parameter selects the track number with which the W-Port is assigned to (see
 3881 TDMapper, 6.1.1.)

3882 **SlotType**
 3883 This parameter indicates the expected SlotType for corresponding W-Device
 3884 Permitted values: SSLOT, DSLOT (see Table 161)

3885 **TargetMode**
 3886 This parameter indicates the requested operational mode of the W-Port
 3887 Permitted values: INACTIVE, CYCLIC, ROAMING

3888 **UniqueID**
 3889 Data length: 9 octets

3890 **ConfiguredCycleTime**
 3891 This parameter contains the requested cycle time for the OPERATE mode
 3892 Permitted values:
 3893 0 (FreeRunning)
 3894 Time (see clause 14.1.2)

3895 **IMATime**
 3896 This parameter contains the requested IMA time for the OPERATE mode
 3897 Permitted values: 2 octets, time encoded according to clause 14.3.5.

3898 **MaxRetry**
 3899 This parameter contains the maximum number of retries for a transmission in OPERATE
 3900 mode
 3901 Permitted values: see Table 175.

3902 **ConfiguredRevisionID (CRID)**
 3903 Data length: 1 octet for the RevisionID (see Table 163)

3904 **InspectionLevel:**
 3905 Permitted values: NO_CHECK, TYPE_COMP, IDENTICAL (see Table 101)

3906 **ConfiguredVendorID (CVID)**
 3907 Data length: 2 octets
 3908 NOTE VendorIDs are assigned by the IO-Link community

3909 **ConfiguredDeviceID (CDID)**
 3910 Data length: 3 octets

3911 **ConfiguredFunctionID (CFID)**
 3912 Data length: 2 octets

3913 **ConfiguredSerialNumber (CSN)**
 3914 Data length: up to 16 octets

3915 **PDInLength**
 3916 Data length of process data in
 3917 Permitted values: 0 to 32

3918 **PDOOutLength**
 3919 Data length of process data out
 3920 Permitted values: 0 to 32

3921 **MaxPDSegLength (only W-Master)**
 3922 This parameter contains the maximum segment length of the PDOOut data to the Message
 3923 handler to distribute PDOOut Data within multiple W-Cycles.

3924 **DeviceTXPower**
 3925 This parameter contains the transmit power level of the W-Device
 3926 Permitted values: 1 to 255, see 10.9 IODD for definition

3927 **LowPowerDevice**
 3928 Permitted values: YES, NO

3929 **Result (+):**
 3930 This selection parameter indicates that the service has been executed successfully

3931 **W-Port**

3932 This parameter contains the W-Port number
 3933 **Result (-):**
 3934 This selection parameter indicates that the service failed
 3935 **W-Port**
 3936 This parameter contains the W-Port number
 3937 **ErrorInfo**
 3938 This parameter contains the error information
 3939 Permitted values:
 3940 PARAMETER_CONFLICT (consistency of parameter set violated)
 3941 STATE_CONFLICT (service unavailable within current state)

3942 Table 101 specifies the coding of the different InspectionLevel

Table 101 Definition of the InspectionLevel (IL)

Parameter	InspectionLevel (IL)		
	NO_CHECK	TYPE_COMP	IDENTICAL
DeviceID (DID) (compatible)	-	Yes (RDID=CDID)	Yes (RDID=CDID)
VendorID (VID)	-	Yes (RVID=CVID)	Yes (RVID=CVID)
SerialNumber (SN)	-	-	Yes (RSN = CSN)
NOTE: For W-Devices with missing SerialNumber, the IL shall not be set to IDENTICAL.			

3946 Table 102 specifies the coding of the different Target Modes.

Table 102 Definitions of the Target Modes

Target Mode	Definition
INACTIVE	Communication disabled
CYCLIC	W-Master is working in Cyclic mode. (Full performance)
ROAMING	W-Master is working in Roaming mode. (Limited performance)

3951 **9.2.2.8 SM_GetPortConfig**

3952 The SM_GetPortConfig service is used to acquire the real (actual) W-Device configuration. The parameters
 3953 of the service primitives are listed in Table 103
 3954
 3955
 3956

Table 103 SM_GetPortConfig

Parameter Name	.req	.cnf
Argument	M	
W-Port	M	
Result (+)		S
ParameterList		M
Result (-)		S
W-Port		M
ErrorInfo		M

3957 **Argument**
 3958 The service-specific parameters are transmitted in the argument.
 3959 **W-Port**
 3960 This parameter contains the W-Port number

3961 **Result (+):**
3962 This selection parameter indicates that the service has been executed successfully
3963 **ParameterList**
3964 This parameter contains the configured W-Port and W-Device parameters of a W-Master W-Port.
3965 Parameter type: Record
3966 Record Elements:
3967 **W-Port**
3968 This parameter contains the W-Port number (see TDMapper, 6.1.1.).
3969 **Slot_N**
3970 This parameter contains the Slot number within the corresponding track number (see
3971 TDMapper, 6.1.1.)
3972 **Track_N**
3973 This parameter selects the track number which the W-Port is assigned to (see TDMapper,
3974 6.1.1.)
3975 **SlotType**
3976 This parameter indicates the expected SlotType for corresponding W-Device
3977 Permitted values: SSLOT, DSLOT (see Table 161)
3978 **TargetMode**
3979 This parameter indicates the requested operational mode of the W-Port
3980 Permitted values: INACTIVE, CYCLIC, ROAMING
3981 **UniqueID**
3982 Data length: 9 octets
3983 **RealCycleTime**
3984 This parameter contains the real (actual) cycle time for the OPERATE mode
3985 Permitted values:
3986 0 (FreeRunning)
3987 Time (see clause 14.1.2)
3988 **IMATime**
3989 This parameter contains the requested IMA time for the OPERATE mode
3990 Permitted values: 2 octets, time encoded according to clause 14.3.5.
3991 **MaxRetry**
3992 This parameter contains the maximum number of retries for a transmission in OPERATE
3993 mode
3994 Permitted values: see Table 175.
3995 **RealRevision (RRID)**
3996 Data length: 1 octet for the RevisionID (see B.1.5 in REF 1)
3997 **RealVendorID (RVID)**
3998 Data length: 2 octets
3999 NOTE VendorIDs are assigned by the IO-Link community
4000 **RealDeviceID (RDID)**
4001 Data length: 3 octets
4002 **RealFunctionID (RFID)**
4003 Data length: 2 octets
4004 **RealSerialNumber (RSN)**
4005 Data length: up to 16 octets
4006 **PDInLength**
4007 Data length of process data in
4008 Permitted values: 0 to 32
4009 **PDOOutLength**
4010 Data length of process data out
4011 Permitted values: 0 to 32
4012 **MaxPDSegLength (only W-Master)**
4013 This parameter contains the maximum segment length of the PDOOut data to the Message
4014 handler to distribute PDOOut
4015 Data within multiple W-Cycles.
4016 **DeviceTXPower**
4017 This parameter contains the transmit power level of the W-Device
4018 Permitted values: 1 to 255, see 10.9 IODD for definition
4019 **LowPowerDevice**
4020 Permitted values: YES, NO

Result (-):

This selection parameter indicates that the service failed

W-Port

This parameter contains the W-Port number

ErrorInfo

This parameter contains the error information

Permitted values:

PARAMETER_CONFLICT (consistency of parameter set violated)

9.2.2.9 SM_PortPairing

The SM_PortPairing service is used to pair a W-Device to the W-Master. The parameters of the service primitives are listed in Table 104

Table 104 SM_PortPairing

Parameter Name	.req	.cnf
Argument	M	
PairingMethod	M	
Timeout	M	
Result (+)		S
W-Port		M
Result (-)		S
W-Port		M
ErrorInfo		M

Argument

The service-specific parameters are transmitted in the argument.

PairingMethod

This parameter indicates the pairing mode which shall be used.

Permitted values: PAIRING_BUTTON, PAIRING_UNIQUE, UNPAIRING, PAIRING_ABORTED.

Timeout

This parameter contains the timeout for a pairing attempt in seconds. See Table 186 (definition of PAIRING_BUTTON_TIMEOUT, PAIRING_UNIQUE_TIMEOUT)

Permitted values: PAIRING_BUTTON_TIMEOUT, PAIRING_UNIQUE_TIMEOUT

Result (+):

This selection parameter indicates that the service has been executed successfully

W-Port

This parameter contains the W-Port number

Result (-):

This selection parameter indicates that the service failed

W-Port

This parameter contains the W-Port number

ErrorInfo

This parameter contains the error information

Permitted values:

PARAMETER_CONFLICT (consistency of parameter set violated)

STATE_CONFLICT (service unavailable within current state)

9.2.2.10 SM_PortMode

The SM_PortMode service is used to indicate changes or faults of the local communication mode. These shall be reported to the W-Master application. The parameters of the service primitives are listed in Table 105.

4064

Table 105 SM_PortMode

Parameter Name	.ind
Argument	M
W-Port	M
Mode	M

4065

Argument

4066

The service-specific parameters are transmitted in the argument.

4067

W-Port

4068

This parameter contains the W-Port number

4069

Mode

4070

Permitted values:

4071

PAIRING_SUCCESS (W-Device has been paired)

4072

PAIRING_TIMEOUT (W-Device hasn't been paired within the given timeout)

4073

PAIRING_WRONG_SLOTTYPE (W-Device has different SlotType as requested)

4074

INACTIVE (Communication disabled)

4075

PORTREADY (W-Port configuration successful)

4076

COMREADY (Communication established and inspection successful)

4077

OPERATE (W-Port is ready to exchange Process Data)

4078

COMLOST (Communication failed, new synchronization procedure required)

4079

REVISION_FAULT (Incompatible protocol revision)

4080

COMP_FAULT (Incompatible W-Device or Legacy-Device according to the InspectionLevel)

4081

SERNUM_FAULT (Mismatching SerialNumber according to the InspectionLevel)

4082

9.2.2.11 SM_GetPortQuality

4083

The SM_GetPortQuality service is used to acquire the quality of a W-Device connection. The parameters

4084

of the service primitives are listed in Table 106.

4085

4086

4087

Table 106 SM_GetPortQuality

Parameter Name	.req	.cnf
Argument	M	
W-Port	M	
Result (+)		S
W-Port		M
Quality		M
Result (-)		S
W-Port		M
ErrorInfo		M

4088

Argument

4089

The service-specific parameters are transmitted in the argument.

4090

W-Port

4091

This parameter contains the W-Port number

4092

Result (+):

4093

This selection parameter indicates that the service has been executed successfully

4094

W-Port

4095

This parameter contains the W-Port number

4096

Quality

4097

This parameter contains the quality of a W-Device connection.

4098

Permitted Values: 0 to 100%.

4099

Result (-):

4100

This selection parameter indicates that the service failed

4101 **W-Port**
 4102 This parameter contains the W-Port number
 4103 **ErrorInfo**
 4104 This parameter contains the error information
 4105 Permitted values:
 4106 STATE_CONFLICT (service unavailable within current state)

4107 **9.2.2.12 SM_Operate**

4108 The SM_Operate service prompts system management to calculate the MasterCycleTime of the ports when
 4109 they are acknowledged positively with Result (+). This service is effective on all the ports. The parameters
 4110 of the service primitives are listed in Table 107.
 4111
 4112

Table 107 SM_Operate

Parameter Name	.req	.cnf
Result (+)		S
Result (-)		S
ErrorInfo		M

4113
 4114 **Result (+):**
 4115 This selection parameter indicates that the service has been executed successfully

4116 **Result (-):**
 4117 This selection parameter indicates that the service failed

4118 **ErrorInfo**
 4119 This parameter contains the error information
 4120 Permitted values:
 4121 TIMING_CONFLICT (the requested combination of cycle times for the activated ports is not
 4122 possible)
 4123

4124 **9.2.3 SM W-Master protocol**


4125
 4126 **9.2.3.1 Overview**

4127 Due to the comprehensive configuration, parameterization, and operational features of IOLW the
 4128 description of the behavior with the help of state diagrams becomes rather complex. Similar to the DL state
 4129 machines 9.2.3 uses the possibility of submachines within the main state machines.
 4130 Comprehensive compatibility check methods are performed within the submachine states. These methods
 4131 are indicated by "do method" fields within the state graphs, for example in Figure 96.
 4132 The corresponding decision logic is demonstrated via activity diagrams (see Figure 98, Figure 99, Figure
 4133 100, and Figure 101).

4134 **9.2.3.2 SM W-Master State machines**

4135 **9.2.3.2.1 State Machine of the W-Master Track handler**

4136 Figure 95 shows the main state machine of the W-Master Track handler. The tracks will be configured
4137 (MasterID, Blacklist, ...) and after setting active, the different operating modes (CYCLIC, ROAMING, ...)
4138 can be set. The service PL_Scan delivers every single W-Device that has been found within a scan.
4139



4140
4141

Figure 95 State Machine of the W-Master Track handler

4142

Table 108 State transition table of the W-Master Track handler

STATE NAME	STATE DESCRIPTION
Idle_0	-
TrackInactive_1	State is entered after track configuration done via SM_SetMasterConfig. Waiting for activation of operating mode (CYCLIC or ROAMING).
CyclicMode_2	Track is active (CYCLIC mode). The gateway application is exchanging Process Data and ready to send or receive On-request Data.
ScanMode_3	Track is active (SCAN mode) and scanning for unpaired devices via the configuration channels. Found devices are reported to the application via SM_TrackScanResult.
PairingMode_4	Track is active (PAIRING mode). Additionally, the configuration channels are active. This state is left by PL_Pairing.ind automatically, if pairing is done.
RoamingMode_5	Track is active (ROAMING mode). Additionally, the configuration channels are active. Found devices are reported to the application via SM_TrackScanResult.

4143

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke PL_SetTrackConfig() to configure all available W-Master tracks with identical MasterID and Blacklist: PL_SetTrackConfig.req (MasterID, Blacklist, Track_N++, MASTER / SLAVE) The tracks shall be configured in the following way: Each track shall get a unique track number from 0 up to 4, (e.g. consecutively numbering → Track_N++) The number given in SM_SetMasterConfig(SyncMaster) selects the track which shall become TrackSynchronization = MASTER (except SyncMaster = 5).
T2	1	2	Invoke PL_SetMode (CYCLIC)
T3	1	5	Invoke PL_SetMode (ROAMING)
T4	5	5	Invoke PL_Pairing
T5	5	5	Invoke SM_TrackScanResult to report unpaired W-Devices within the track's proximity
T6	2	4	Invoke PL_Pairing (PAIRING_UNIQUE or PAIRING_BUTTON)
T7	4	2	Invoke SM_PortMode.ind (PAIRING_SUCCESS or PAIRING_TIMEOUT) after pairing is done.
T8	2	3	Invoke PL_SetMode (SCAN).
T9	3	3	See T5.
T10	3	2	Scan procedure is finished and reported by PL via service PL_ScanEnd.ind Invoke SM_TrackScanEnd.ind
T11	3	1	Invoke PL_SetMode (STOP)
T12	4	1	See T11.
T13	2	1	See T11.
T14	5	1	See T11.
T15	1	1	See T1
T16	4	2	<i>Pairing procedure is aborted by the W-Master application.</i> Invoke PL_Pairing(ABORT)

4144

INTERNAL ITEMS	TYPE	DEFINITION
AllTracksInactive	Bool	This value is set if all tracks are in the state TrackInactive_0

4145

9.2.3.2.2 State Machine of the W-Port-handler

Figure 96 shows the main state machine of the Master W-Port-handler. Two submachines for the compatibility and SerialNumber check are specified in subsequent sections. In case of communication disruption, the system management is informed via the service DL_Mode (COMLOST). Only the SM_SetPortConfig service allows reconfiguration of a port. The service SM_PortPairing allows pairing and unpairing of a W-Device. The service SM_Operate (effective on all ports) causes no effect in any state except in state "wait_7".

The SerialNumber of a pure W-Device shall follow the rules in clause 14.3.8 SerialNumber, since the pairing mechanism covers the identity check of the W-Device.

A W-Bridge shall route the SerialNumber of its connected wired IO-Link Device to support the SerialNumber check for InspectionLevel in the same way as for a pure wired device.




Figure 96 State Machine of the W-Port-handler

Table 109 shows the state transition tables of the Master W-Port-handler.

Table 109 State transition table of the W-Port-handler

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for configuration of W-Port from W-Port Config Manager
waitonDLStartup_1	Waiting for W-Device to be synced
Pairing_2	Waiting for pairing response from PL
CheckCompatibility_3	W-Port is started, and revision and W-Device compatibility is checked. See Figure 97.
waitonDLPreoperate_4	Wait until the PREOPERATE state is established and all the On-Request handlers are started. W-Port is ready to communicate.
InspectionFault_5	W-Port is ready to communicate. However, cyclic Process Data exchange cannot be performed due to incompatibilities.
CheckSerNum_6	SerialNumber is checked depending on the InspectionLevel (IL). See Figure 101.
wait_7	W-Port is ready to communicate and waits on service SM_Operate from CM.
SM Operate_8	W-Port is in state OPERATE and performs cyclic Process Data exchange.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke PL_SetSlotConfig with configuration of W-Port from W-Port Config Manager Invoke DL_SetMode.req (STARTUP) Invoke DL_SetParam(ValueList) Invoke DL_TDConfig(ValueList)
T2	1	2	Invoke PL_Pairing.req (PAIRING_BUTTON or PAIRING_UNIQUE) depending on PairingMethod in SM_PortPairing.
T3	2	1	Invoke SM_PortMode.ind to signal pairing state to application
T4	1	3	VerRetry = 0, CompRetry = 0
T5	1	1	Invoke PL_SetSlotConfig with updated configuration of W-Port Invoke DL_SetParam(ValueList) Invoke DL_TDConfig(ValueList)
T6	3,4,5,6,7,8	1	Invoke DL_SetMode.req (INACTIVE) and SM_PortMode.ind (COMLOST) due to communication fault
T7	3	4	Write MasterCmd (DevicePreoperate) , Invoke DL_SetMode.req (PREOPERATE, ValueList)
T8	3	5	Invoke SM_PortMode.ind (COMP_FAULT), Write MasterCmd (DevicePreoperate) , DL_SetMode.req (PREOPERATE, ValueList)
T9	3	5	Invoke SM_PortMode.ind (REVISION_FAULT), Write MasterCmd (DevicePreoperate) , DL_SetMode.req (PREOPERATE, ValueList)
T10	4	6	-
T11	6	7	Invoke SM_PortMode.ind (COMREADY)
T12	6	5	Invoke SM_PortMode.ind (SERNUM_FAULT)
T13	5,7,8	1	Write MasterCmd (UnPairing) Invoke PL_Pairing.req (UNPAIRING)
T14	7	8	Write MasterCmd (DeviceOperate) Invoke DL_SetMode.req (OPERATE, ValueList)
T15	8	8	Invoke SM_PortMode.ind (OPERATE)
T16	5,7,8	0	Write MasterCmd (Inactive) SM_PortMode.ind (INACTIVE), DL_SetMode.req (INACTIVE)

4166

INTERNAL ITEMS	TYPE	DEFINITION
CompOK	Bool	See Figure 99
CompFault	Bool	See Figure 99; error variable COMP_FAULT
RevisionFault	Bool	See Figure 98; error variable REVISION_FAULT
SerNumFault	Bool	See Figure 102; error variable SERNUM_FAULT
SerNumOK	Bool	See Figure 102
INACTIVE	Variable	A target mode in service SM_SetPortConfig
CYCLIC, ROAMING	Variables	Target Modes in service SM_SetPortConfig
MasterCmd	Service	DL_Write(0x00, 0x01, ..)

4167

4168

9.2.3.2.3 SM W-Master submachines

Figure 97 shows the Master W-Port-handler submachine checkCompatibility_3.




Figure 97 Submachine CheckCompatibility_3 of the W-Port-handler

Table 110 State transition table Submachine Check Compatibility 3 W-Port-handler

STATE NAME	STATE DESCRIPTION
ReadComParameter_20	Acquires communication parameters from Direct Parameter Page 1 (0x02 to 0x06) via service DL_Read (see Table 164.).
CheckVxy_21	A check is performed whether the configured revision (CRID) matches the real (actual) revision (RRID) according to Figure 98
CheckComp_22	Acquires identification parameters from Direct Parameter Page 1 (0x07 to 0x0D) via service DL_Read (see Table 164). The configured InspectionLevel (IL) defines the decision logic of the subsequent compatibility check "CheckComp" according to Figure 99
RestartDevice_23	Writes the compatibility parameters configured protocol revision (CRID) and configured DeviceID (CDID) into the W-Device according to Figure 100
JoinPseudoState_24	This pseudo state is used instead of a UML join bar. No guards involved.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T20	20	21	-
T21	21	22	-
T22	22	23	CompRetry = CompRetry +1
T23	24	20	-
T24	21	23	VerRetry = VerRetry +1

INTERNAL ITEMS	TYPE	DEFINITION
CompOK	Bool	See Figure 99
CompFault	Bool	See Figure 99; error variable COMP_FAULT
RevisionFault	Bool	See Figure 98; error variable REVISION_FAULT
RevisionOK	Bool	See Figure 98
SerNumFault	Bool	See Figure 102 error variable SERNUM_FAULT
SerNumOK	Bool	See Figure 102
V1.0	Bool	Real protocol revision of connected W-Device is in accordance with this standard
RetryStartup	Bool	See Figure 98 and Figure 99
VerRetry	Variable	Internal counter
CompRetry	Variable	Internal counter
WriteDone	Bool	Finalization of the restart service sequence

4179
4180
4181
4182
4183
4184
4185
4186
4187
4188

Some states contain complex logic to deal with the compatibility and validity checks. Figure 98 to Figure 101 are demonstrating the context. Figure 98 shows the decision logic for the protocol revision check in state "CheckVxy_21". In case of configured Devices, the following rule applies: if the configured revision (CRID) and the real revision (RRID) do not match, the CRID will be transmitted to the Device. If the Device does not accept, the Master returns an indication via the SM_Mode service with REV_FAULT.





Figure 98 Activities for state „CheckVxy_21“

4189
4190
4191

4192
4193


Figure 99 shows the decision logic for the compatibility check in state "CheckComp_22".



4194
4195
4196
4197
4198

Figure 99 Activities for state „CheckComp_22“

Figure 100 shows the activity (write parameter) in state "RestartDevice_23".




4199
4200
4201

Figure 100 Activities (write parameter) in state "RestartDevice_23"

4202
4203

Figure 101 shows the SM Master submachine "checkSerNum_6". This check is mandatory.



4204
4205
4206
4207

Figure 101 Submachine CheckSerNum_6 of the W-Port-handler

Table 111 State transition table Submachine CheckSerNum_6 of the W-Port-handler

STATE NAME	STATE DESCRIPTION
ReadSerNum_30	Acquires the SerialNumber from the W-Device via AL_Read.req (Index: 0x0015). A positive response (AL_Read(+)) leads to SReadOK = true. A negative response (AL_Read(-)) leads to SRead- = true.
CheckSerNum_61	The configured (CSN) stored in W-Master and the real (RSN) SerialNumber from the W-Device are checked against each other depending on the InspectionLevel (IL) according to Figure 102.

4208

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T30	30	31	
T31	30	31	

4209

INTERNAL ITEMS	TYPE	DEFINITION
SRead-	Bool	Negative response of service AL_Read (Index 0x0015)
SReadOK	Bool	SerialNumber read correctly
SERNumOK	Bool	See Figure 102
SERNumFault	Bool	See Figure 102

4210
4211
4212

4213 Figure 102 shows the decision logic (activity) for the state CheckSerNum_6.
 4214




Figure 102 Activities (check SerialNumber) for state CheckSerNum_6

4215
 4216
 4217 **9.2.3.2.4 State Machine of W-Master AHT handler**

4218 Figure 103 shows the main state machine of the W-Master AHT-handler. The hopping table will be
 4219 configured and updated to all tracks and connected W-Devices, see clause 18.4.
 4220




Figure 103 State Machine of the W-Master AHT-handler

4221
 4222

4223

Table 112 State transition table of the W-Master AHT-handler

STATE NAME	STATE DESCRIPTION
Idle_0	-
Monitoring_1	State monitors the hopping frequencies and decides if to perform an update. Data will be collected by radio manufacturer services
UpdateHT_2	Update sequence in progress.

4224

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke PL_GetHopTable(Track_N) for each Track number to accuire all the hopping tables of the W-Master. Set AHTEnable = Enable.
T2	1	2	Invoke PL_SetWakeUpTime.req(WakeUpTime) Invoke PL_SetHopTable to dedicated track Low energy W-Devices: Invoke DL_Write.req(WakeUp) All regular W-Devices: Invoke DL_Write.req(HopTable)
T3	2	2	Invoke DL_Write.req (HopTable + WakeUpTime)
T4	2	1	Status: JUMP_SUCCESS - Invoke PL_SetHopTable to all other tracks WAKE_UP_ABORT – restart sequence, invoke T2 JUMP_FAIL – return to previous HopTable, invoke T2 STOP - PL track has stopped, update aborted
T5	1	3	Set AHTEnable = Disable

4225

INTERNAL ITEMS	TYPE	DEFINITION
AHTEnable	variable	Indicates the AHT operaion mode, set by SM_SetMasterConfig
UpdateDecision	guard	Indicates a decision to update the hopping table

4226

9.3 System management of the W-Device

9.3.1 Overview

Figure 104 provides an overview of the structure and services of the W-Device system management.




Figure 104 Structure and services of the W-Device system management

The System Management (SM) of the W-Device provides the central controlling instance via the PL through all the phases of initialization, communication startup and communication.

4235 The Device SM interacts with the PL to establish the necessary radio adjustments (see Figure 56 PL W-
 4236 Device state machine), with the DL to get the necessary information from the W-Master and with the W-
 4237 Device applications to ensure the Device identity and compatibility (identification parameters).
 4238 The transitions between the W-Device PL states (see Figure 56) are initiated by the W-Master track
 4239 activities (scan, pairing, synchronization, ...) and triggered through the Device Data Link Layer via the
 4240 DL_Mode indications and DL_Write requests (commands).
 4241 The SM provides the Device identification parameters through the Device applications interface.
 4242 The sequence chart in Figure 105 demonstrates the two possibilities of pairing of a typical Device sequence.
 4243 It shows only the actions until the ComEstablish state. The remaining actions until the OPERATE state can
 4244 be taken from
 4245 Figure 108.
 4246



Figure 105 Sequence chart of a Device pairing

4247
4248

9.3.2 System management W-Device services

4249
4250

9.3.2.1 Overview

4251
4252
4253
4254

Subclause 9.3.2 describes the services the W-Device system management provides to its applications as shown in Figure 104

4255
4256

Table 113 lists the assignment of the W-Device to its role as initiator or receiver for the individual system management service.

4257

Table 113 System management services within the W-Device

Service Name		W-Device
SM_SetDeviceCom	Configure communication properties supported by W-Device	R
SM_GetDeviceCom	Read the current communication properties	R
SM_SetDeviceIdent	Configure W-Device identification data	R
SM_GetDeviceIdent	Read W-Device identification parameter	R
SM_SetDeviceMode	Set W-Device into a defined operational state during initialization	R
SM_Device Mode	Indicate changes of communication states to the W-Device application	I
Key (see 3.3.5) I: Initiator of service R: Receiver (Responder) of service		

4258

4259

4260

9.3.2.2 SM_SetDeviceCom

4261

The SM_SetDeviceCom service is used to configure the communication properties supported by the W-Device in the system management. The parameters of the service primitives are listed in Table 114.

4262

4263

4264

Table 114 SM_SetDeviceCom

Parameter Name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

4265

Argument

4266

The service-specific parameters are transmitted in the argument.

4267

ParameterList

4268

This parameter contains the configured communication parameters for a W-Device.

4269

Parameter type: Record

4270

Record Elements:

4271

MAXRetry

4272

This parameter contains the maximum number of allowed retries in count of W-Sub-Cycles (see clause 14.3.6).

4273

4274

IMATime

4275

This parameter contains the I am alive time. Permitted values: 2 octets, time encoded according to clause 14.3.5.

4276

4277

TXPower

4278

This parameter contains the transmission power for the W-Device (see Table 176).

4279

DLinkType

4280

This parameter contains the downlink type (see Table 23) for the radio to listen (full downlinks or pre-downlinks).

4281

4282

SlotType

4283

This parameter contains the uplink type (see Table 161) for the uplink capability of the radio (single slot or double slot).

4284

4285

UniqueID

4286

This parameter contains the UniqueID from the W-Device (see Figure 156).

4287

MinCycleTime

4288 This parameter contains the minimum cycle time supported by the W-Device (see 14.1.2)
 4289 **RevisionID (RID)**
 4290 This parameter contains the protocol revision (see clause 14.1.3) supported by the W-Device.
 4291 **ProcessDataIn**
 4292 This parameter contains the length of PD to be sent to the W-Master.
 4293 **ProcessDataOut**
 4294 This parameter contains the length of PD to be sent by the W-Master.
 4295 **Result (+):**
 4296 This selection parameter indicates that the service has been executed successfully.
 4297 **Result (-):**
 4298 This selection parameter indicates that the service failed.
 4299 **ErrorInfo**
 4300 This parameter contains the error information.
 4301 Permitted values:
 4302 PARAMETER_CONFLICT (consistency of parameter set violated)
 4303

4304 9.3.2.3 SM_GetDeviceCom

4305 The SM_GetDeviceCom service is used to read the current communication properties from the system
 4306 management. The parameters of the service primitives are listed in Table 115.
 4307
 4308

Table 115 SM_GetDeviceCom

Parameter Name	.req	.cnf
Argument	M	
Result (+)		S
ParameterList		M
Result (-)		S
ErrorInfo		M

4309 **Argument**
 4310 The service-specific parameters are transmitted in the argument.
 4311 **Result (+):**
 4312 This selection parameter indicates that the service has been executed successfully.
 4313 **ParameterList**
 4314 This parameter contains the configured communication parameters for a W-Device.
 4315 Parameter type: Record
 4316 Record Elements:
 4317 **MAXRetry**
 4318 This parameter contains the current number of allowed retries in count of W-Sub-cycles (see clause
 4319 14.3.6).
 4320 **IMATime**
 4321 This parameter contains the current I am alive time. Permitted values: 2 octets, time encoded
 4322 according to clause 14.3.5.
 4323 **TXPower**
 4324 This parameter contains the current transmission power for the W-Device (see Table 176).
 4325 **DLinkType**
 4326 This parameter contains the current downlink type (see Table 23) for the radio to listen (full
 4327 downlinks or pre-downlinks).
 4328 **SlotType**
 4329 This parameter contains the uplink type (see Table 161) for the uplink capability of the radio (single
 4330 slot or double slot).
 4331 **MasterCycleTime**
 4332 This parameter contains the MasterCycleTime to be set by the W-Master system management (see
 4333 clause 14.1.2). This parameter is only valid in the state SM_Operate.
 4334 **RevisionID (RID)**
 4335 This parameter contains the current protocol revision (see clause 14.1.3) within the system
 4336 management of the W-Device.

4337 **ProcessDataIn**
 4338 This parameter contains the current length of PD to be sent to the W-Master (see clause 14.1.4).
 4339 **ProcessDataOut**
 4340 This parameter contains the current length of PD to be sent by the W-Master (see clause 14.1.5).
 4341 **Result (-):**
 4342 This selection parameter indicates that the service failed.
 4343 **ErrorInfo**
 4344 This parameter contains the error information.
 4345 Permitted values:
 4346 STATE_CONFLICT (service unavailable within current state, should only be returned if no
 4347 communication parameters are set)
 4348

4349 **9.3.2.4 SM_SetDevicelIdent**

4350 The SM_SetDevicelIdent service is used to configure the W-Device identification data in the system
 4351 management. The parameters of the service primitives are listed in
 4352 Table 116.
 4353
 4354

Table 116 SM_SetDevicelIdent

Parameter name	.req	.cnf
Argument	M	
ParameterList	M	
Result (+)		S
Result (-)		S
ErrorInfo		M

4355 **Argument**
 4356 The service-specific parameters are transmitted in the argument.

4357 **ParameterList**
 4358 This parameter contains the configured identification parameter for a W-Device.
 4359 Parameter type: Record
 4360 Record Elements:
 4361 **VendorID (VID)**
 4362 This parameter contains the VendorID assigned to a W-Device (see B.1.8)
 4363 Data length: 2 octets
 4364 **DeviceID (DID)**
 4365 This parameter contains one of the assigned DeviceIDs (see B.1.9)
 4366 Data length: 3 octets
 4367 **FunctionID (FID)**
 4368 This parameter contains one of the assigned FunctionIDs (see B.1.10).
 4369 Data length: 2 octets

4370 **Result (+):**
 4371 This selection parameter indicates that the service has been executed successfully.

4372 **Result (-):**
 4373 This selection parameter indicates that the service failed.

4374 **ErrorInfo**
 4375 This parameter contains the error information.
 4376 Permitted values:
 4377 STATE_CONFLICT (service unavailable within current state)
 4378 PARAMETER_CONFLICT (consistency of parameter set violated)
 4379

4380 **9.3.2.5 SM_GetDevicelIdent**

4381 The SM_GetDevicelIdent service is used to read the W-Device identification parameter from the system
 4382 management. The parameters of the service primitives are listed in Table 117.
 4383

4384

Table 117 SM_GetDeviceIdent

Parameter name	.req	.cnf
Argument	M	
Result (+) ParameterList		S M
Result (-) ErrorInfo		S M

4385

Argument

4386

The service-specific parameters are transmitted in the argument.

4387

Result (+):

4388

This selection parameter indicates that the service has been executed successfully.

4389

ParameterList

4390

This parameter contains the configured communication parameters of the W-Device.

4391

Parameter type: Record

4392

Record Elements:

4393

VendorID (VID)

4394

This parameter contains the actual VendorID of the W-Device (see B.1.8)

4395

Data length: 2 octets

4396

DeviceID (DID)

4397

This parameter contains the actual DeviceID of the W-Device (see B.1.9)

4398

Data length: 3 octets

4399

FunctionID (FID)

4400

This parameter contains the actual FunctionID of the W-Device (see B.1.10).

4401

Data length: 2 octets

4402

Result (-):

4403

This selection parameter indicates that the service failed.

4404

ErrorInfo

4405

This parameter contains the error information.

4406

Permitted values:

4407

STATE_CONFLICT (service unavailable within current state should only be returned if no

4408

identification data are set).

4409

9.3.2.6 SM_SetDeviceMode

4410

The SM_SetDeviceMode service is used to set the W-Device into a defined operational state during

4411

initialization. The parameters of the service primitives are listed in Table 118

4412

4413

Table 118 Service SM_SetDeviceMode

Parameter Name	.req	.cnf
Argument Mode	M M	
Result (+)		S
Result (-) ErrorInfo		S M

4414

Argument

4415

The service-specific parameters are transmitted in the argument.

4416

Mode

4417

Permitted values:

4418

IDLE (W-Device changes to waiting for configuration via application)

4419

ESTABCOM (W-Device changes to waiting for synchronization or pairing by

4420

UniqueID)

4421

PAIRING_BUTTON (W-Device changes to waiting for pairing by button)

4422

Result (+):

4423

This selection parameter indicates that the service has been executed successfully.

4424

Result (-):

4425

This selection parameter indicates that the service failed.

4426

ErrorInfo

4427

This parameter contains the error information.

4428

Permitted values:

4429

STATE_CONFLICT (service unavailable within current state)

4430

4431 **9.3.2.7 SM_DeviceMode**

4432 The SM_DeviceMode service is used to indicate changes of communication states to the W-Device
 4433 application. The parameters of the service primitives are listed in Table 119.
 4434
 4435

Table 119 Service SM_DeviceMode

Parameter Name	.ind
Argument	M
Mode	M

4436 **Argument**

4437 The service-specific parameters are transmitted in the argument.
 4438

4438 **Mode**

4439 Permitted values:

4440 IDLE	(W-Device changed to waiting for configuration)
4441 ESTABCOM	(W-Device changed to the SM mode "SM_ComEstablish")
4442 UNPAIRED	(W-Device is unpaired at startup)
4443 PAIRED	(W-Device is paired at startup)
4444 TIMEOUT	(timeout occurred)
4445 PERMANENT	(W-Device has been paired permanently)
4446 TEMPORARY	(W-Device has been paired as roaming W-Device)
4447 PAIRING_BUTTON	(W-Device changed to waiting for pairing by button)
4448 STARTUP	(W-Device changed to the STARTUP mode)
4449 IDENT_STARTUP	(W-Device changed to the SM mode "SM_IdentStartup")
4450 IDENT_CHANGE	(W-Device changed to the SM mode "SM_IdentCheck")
4451 PREOPERATE	(W-Device changed to the PREOPERATE mode)
4452 OPERATE	(W-Device changed to the OPERATE mode)
4453	

9.3.3 SM W-Device protocol

9.3.3.1 Overview

The behavior of the W-Device is mainly driven by W-Master messages. Compared to IO-Link (cyclic Process Data exchange) the transmission of Process Data between a W-Master and a W-Device is only necessary if they change. Therefore, a W-Device can send Process Input Data without an explicit request of the W-Master. A W-Device can also send events without a W-Master request.

9.3.3.2 State machine of W-Device System Management

Figure 106 shows the state machine for W-Device System Management, it evaluates the different communication phases during startup and controls the communication status of the W-Device.




Figure 106 State machine for W-Device System Management

4468

Table 120 State transition tables of the W-Device System Management

STATE NAME	STATE DESCRIPTION
Idle_0	In SM_Idle the SM is waiting for configuration by the W-Device application. The state is left on receiving a SM_SetDeviceMode(ESTABCOM) request from the W-Device application. The following sequence of services shall be executed between W-Device application and SM: Invoke SM_SetDeviceCom(initial parameter list) Invoke SM_SetDeviceIdent(VID, initial DID, FID)
Com_Establish_1	In SM_ComEstablish the SM is waiting for the communication to be established. The state is left on a DL_Mode (ACTIVE) from DL-mode handler, if the W-Device is connected to W-Master. In case of no connection (the W-Device is out of range or not paired) this state is kept. In this state, it is possible to pair the W-Device only via UniqueID triggered by W-Master
IdentStartup_2	In this state the communication parameter (Direct Parameter page 1, addresses 0x02 to 0x06) are read by the W-Master SM via DL_Read requests. In SM_IdentStartup the identification data (VID, DID, FID) are read and verified by the W-Master. In case of incompatibilities the W-Master SM writes the supported Revision (RID) and configured DeviceID (DID) to the W-Device. The state is left upon reception of a DL_Mode(INACTIVE), a DL_Mode(PREOPERATE) indication (compatibility check passed), or a DL_Write(MCmd_DEVICEIDENT) request (new compatibility requested).
IdentCheck_3	In SM_IdentCheck the SM waits for new initialization of identification parameters by application. The state is left on receiving a DL_Mode(INACTIVE) indication or a DL_Read(Direct Parameter page 1, addresses 0x02 = "MinCycleTime") request. Within this state the W-Device application shall check the RID and DID parameters from the SM and set these data to the supported values. Therefore, the following sequence of services shall be executed between W-Device application and SM. Invoke SM_GetDeviceCom(configured RID, parameter list) Invoke SM_GetDeviceIdent(configured DID, parameter list) Invoke W-Device application checks and provides compatibility function and parameters Invoke SM_SetDeviceCom(new supported RID, new parameter list) Invoke SM_SetDeviceIdent(new supported DID, parameter list)
CompStartup_4	In SM_CompStartup the communication and identification data are reread and verified by the W-Master SM. The state is left on receiving a DL_Mode(INACTIVE) or a DL_Mode(PREOPERATE) indication.
Preoperate_5	During SM_Preoperate the SerialNumber can be read and verified by the W-Master SM, as well as Data Storage and W-Device parameterization may be executed. The state is left on receiving a DL_Mode(INACTIVE), a DL_Mode(STARTUP) or a DL_Mode(OPERATE) indication.
Operate_6	During SM_Operate the cyclic Process Data exchange and acyclic On-request Data transfer are active. The state is left on receiving a DL_Mode(INACTIVE) or a DL_Mode(STARTUP) indication.
ButtonPairing_7	In SM_ButtonPairing the SM is waiting for Pairing by Button.

4469

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	<i>The W-Device is switched to the communication mode by receiving the trigger SM_SetDeviceMode(ESTABCOM) by application.</i> Invoke SM_DeviceMode(ESTABCOM). Invoke DL_SetParam(initial parameter list) Invoke PL_SetMode(START).
T2	1	2	The W-Device application receives an indication that the communication has been established by receiving the trigger DL_Mode.ind(ACTIVE). Invoke SM_DeviceMode(IDENTSTARTUP)
T3	2	3	The W-Device identity check phase is entered by receiving the trigger DL_Write.ind(MCmd_DEVICEIDENT). Invoke SM_DeviceMode(IDENTCHANGE)
T4	3	4	The W-Device compatibility startup phase is entered by receiving the trigger DL_Read.ind(Direct Parameter page 1, address 0x02 = "MinCycleTime").
T5	4	5	The W-Device's preoperate phase is entered by receiving the trigger DL_Mode.ind(PREOPERATE). Invoke SM_DeviceMode(PREOPERATE)
T6	5	6	The W-Device's operate phase is entered by receiving the trigger DL_Mode.ind(OPERATE). Invoke SM_DeviceMode(OPERATE)
T7	1	7	The W-Device is switched to the pairing by button mode by receiving the trigger SM_SetDeviceMode(PAIRING_BUTTON) from W-Device application. Invoke PL_Pairing(PAIRING_BUTTON)
T8	2	5	The W-Device's preoperate phase is entered by receiving the trigger DL_Mode.ind(PREOPERATE). Invoke SM_DeviceMode(PREOPERATE)
T9	5	2	The W-Device's communication startup phase is entered by receiving the trigger DL_Mode.ind(STARTUP). Invoke SM_DeviceMode(STARTUP)
T10	6	2	The W-Device's communication startup phase is entered by receiving the trigger DL_Mode.ind(STARTUP). Invoke SM_DeviceMode(STARTUP)
T11	2, 3, 4, 5, 6	0	The W-Device is switched to SM_Idle mode by receiving the trigger DL_Mode.ind(INACTIVE) or SM_SetDeviceMode(IDLE). Invoke PL_SetMode(STOP) Invoke SM_DeviceMode(IDLE)
T12	7	1	The transition is triggered by PL_Pairing.ind(TIMEOUT) or PL_Pairing.ind(PERMANENT) Invoke SM_DeviceMode(ESTABCOM). Invoke SM_DeviceMode(TIMEOUT or PERMANENT).
T13	1	1	Invoke SM_DeviceMode.ind(PAIRED or UNPAIRED) to indicate PL-State after startup
T14	1	1	Invoke SM_DeviceMode.ind(PERMANENT or TEMPORARY) to indicate PL-State after pairing


4470

4471 **9.3.3.3 State Machine of W-Device AHT handler**

4472 Figure 107 shows the main state machine of the W-Device AHT-handler. The handler manages the adaptive
4473 hopping table mechanism, see clause 18.4.

4474

4475



4476

Figure 107 State Machine of the W-Device AHT-handler

4477

4478

Table 121 State transition table of the W-Device AHT-handler

STATE NAME	STATE DESCRIPTION
Idle_0	-
SetWakeUpTime_1	Set the WakeUpTime of low energy W-Device.

4479


TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke PL_SetHopTable(HopTable)
T2	1	2	Invoke PL_SetWakeUpTime(WakeUpTime)
T3	2	2	See T1

4480

4481
4482
4483
4484
4485

9.3.3.4 Start-up and Synchronization

Figure 108 shows a typical sequence chart for the SM communication startup of a W-Device matching the W-Parameter of the W-Master port (regular startup).




4486
4487
4488

Figure 108 Sequence chart of a regular W-Device startup

4489
4490
4491
4492
4493
4494

Figure 109 shows a typical sequence chart for the SM communication startup of a W-Device not matching the W-Parameter of the W-Master port (compatibility mode). In this mode, the W-Master tries to overwrite the W-Device's identification parameters to achieve a compatible and a workable mode. The sequence chart in Figure 109 shows only the actions until the PREOPERATE state. The remaining actions until the OPERATE state can be taken from Figure 106.



4495
4496

Figure 109 Sequence chart of a Device startup in compatibility mode

4497 Figure 110 shows a typical sequence chart for the SM communication startup of a W-Device not matching
 4498 the W-Master port. The system management of the W-Master tries to reconfigure the W-Device with
 4499 alternative W-Device identification parameters (compatibility mode). In this use case, the alternative
 4500 parameters are assumed to be incompatible.
 4501




Figure 110 Sequence chart of a Device startup when compatibility fails

4502
4503

10 W-Device

10.1 Overview

Figure 111 provides an overview of the complete structure and services of a W-Device.




Figure 111 Structure and services of a W-Device

The W-Device applications comprise first the technology specific application consisting of the radio physical and medium access layer (PL) with its technology parameters, its diagnosis information, and its Process Data. The common W-Device applications comprise:

- Parameter Manager (PM), dealing with compatibility and correctness checking of complete sets of technology (vendor) specific and common system parameters (see 10.3);
- Data Storage (DS) mechanism, which optionally uploads or downloads parameters to the W-Master (see 10.4);
- Event Dispatcher (ED), supervising states and conveying diagnosis information such as notifications, warnings, errors, and W-Device requests as peripheral initiatives (see 10.5);
- Process Data Exchange (PDE) unit, conditioning the data structures for transmission in case of a sensor or preparing the received data structures for signal generation. It also controls the operational states to ensure the validity of Process Data (see 10.2).

4524

4525 10.2 Process Data Exchange (PDE)

4526

4527 The Process Data Exchange unit transmits and receives Process Data without interference from the On-
4528 request Data (parameters, commands, and Events), given by the priority in the W-Master and W-Device
4529 Message handler (see 6.5.2 and 6.5.4)

4530 Due to the continuous transmission of DLinks (W-Device synchronization with or without data) and "I'm
4531 alive" ULinks (see 10.3) from W-Device to a W-Master, a transmission of Process Data is only necessary if
4532 they change.

4533

4534 An actuator (output Process Data) shall observe the transmission and enter a default appropriate state, for
4535 example keep last value, stop, or de-energize, whenever the data transmission is interrupted (COMLOST,
4536 see 7.2.3 and 10.7.3). The Process Data of an actuator automatically become valid, if the W-Master's sends
4537 Process Data (see 7.4.1) prior to regular operation after restart in case of an interruption.

4538

4539 NOTE: A transmission of output Process Data is only possible, if the W-Master's Process data handler is
4540 enabled via PDOOUT_VALID.

4541

4542 Within DLinks, an actuator (output Process Data) receives a W-Message "Process Data Out Invalid" (see
4543 12.3.1 DLink Control Octet), whenever the output Process Data are invalid and receives a W-Message with
4544 new Process Data, whenever they become valid again.

4545

4546 There is no need for a sensor W-Device (input Process Data) to monitor the data exchange. However, if
4547 the W-Device is not able to guarantee valid Process Data, the PD status "Process Data In invalid" shall be
4548 signaled to the W-Master application via the W-Message "Process Data In Invalid" (see 12.4.1 ULink Control
4549 Octet).

4550

4551 Each W-Cycle shall be used to transmit process data, while retransmits shall be used for acyclic On-request
4552 Data, if retry / retries for process data are not necessary. It is also possible to transmit On-request Data in
4553 a W-Cycle if no Process Data have to be sent.

4554

4555

4556 10.3 IMA handling

4557 If there are no W-Messages to transmit (e.g. no process data change for long time), the W-Device shall
4558 send an IMA message before the IMA time will be reached (see Figure 63). If IMA time is exceeded
4559 (monitored by the W-Master, see Figure 60), a communication error shall be reported via W-Master's system
4560 management. Also, the PL_State service reports a COMLOST for this W-Port to the W-Master's system
4561 management.

4562

4563 10.4 Parameter Manager (PM)**4564 10.4.1 General**

4565 A W-Device can be parameterized by using the Direct Parameters or the Index memory space. In IO-Link
4566 wireless both are accessible by the help of ISDUs (see Figure 11 and clause 14).

4567

4568 Mandatory for all W-Devices are the Direct Parameters in page 1. Page 1 contains common communication
4569 and identification parameters (see Table 164).

4570

4571 For IO-Link Wireless additional mandatory parameters have been defined, which are listed in Table 168
4572 (Index 0x5000 to 0x50FF). These parameters contains the necessary information for the wireless
4573 connection and represents an extension of the Parameter Page 1. Access to these parameters is performed
4574 via AL_Read and AL_Write.

4575

4576 Direct Parameter page 2 optionally offers space for a maximum of 16 octets of technology (vendor) specific
4577 parameters. Access to the Direct Parameter page 2 is performed via AL_Read and AL_Write.

4578

4579 The transmission of parameters to and from the spacious Index memory can be performed in two ways:
4580 single parameter by single parameter or as a block of parameters. Single parameter transmission as

4581 specified in 10.4.4 is secured via several checks and confirmation of the transmitted parameter. A negative
4582 acknowledgement contains an appropriate error description and the parameter is not activated. Block
4583 parameter transmission as specified in 10.4.5 defers parameter consistency checking and activation until
4584 after the complete transmission. The W-Device performs the checks upon reception of a special command
4585 and returns a confirmation or a negative acknowledgement with an appropriate error description. In this
4586 case the transmitted parameters shall be rejected and a roll back to the previous parameter set shall be
4587 performed to ensure proper functionality of the W-Device.
4588

4589 **10.4.2 Parameter manager state machine**

4590 See IO-Link specification 10.3.2 in REF 1.
4591

4592 **10.4.3 Dynamic parameter**

4593 See IO-Link specification 10.3.3 in REF 1.
4594

4595 **10.4.4 Single parameter**

4596 See IO-Link specification 10.3.4 in REF 1.
4597

4598 **10.4.5 Block parameter**

4599 See IO-Link specification 10.3.5 in REF 1.
4600

4601 **10.4.6 Concurrent parameterization access**

4602 See IO-Link specification 10.3.6 in REF 1.
4603

4604 **10.4.7 Command handling**

4605 See IO-Link specification 10.3.7 in REF 1.
4606

4607 **10.5 Data Storage (DS)**

4608 **10.5.1 General**

4609 See IO-Link specification 10.4.1 in REF 1.
4610

4611 **10.5.2 Data Storage state machine**

4612 See IO-Link specification 10.4.2 in REF 1.

4613 Use Table 181 for "DS_UPLOAD_REQ" Event instead Table D.2 from IO-Link.
4614

4615 **10.5.3 DS configuration**

4616 See IO-Link specification 10.4.3 in REF 1.
4617

4618 **10.5.4 DS memory space**

4619 See IO-Link specification 10.4.4 in REF 1.
4620

4621 **10.5.5 DS Index_List**

4622 See IO-Link specification 10.4.5 in REF 1.
4623

4624 **10.5.6 DS parameter availability**

4625 See IO-Link specification 10.4.6 in REF 1.
4626

4627

10.5.7 DS without ISDU

4628 The ISDU-Mechanism is mandatory for W-Device. To support IO-Link Devices without ISDU via a W-Bridge,
4629 see IO-Link specification 10.4.7 in REF 1 anyway.

4630

4631

10.5.8 DS parameter change indication

4632

See IO-Link specification 10.4.8 in REF 1.

4633

4634

10.6 Event Dispatcher (ED)

4635

Any of the W-Device applications can generate predefined system status information when SDCI operations
4636 fail or technology specific information (diagnosis) as a result from technology specific diagnostic methods
4637 occur. The Event Dispatcher turns this information into an Event according to the definitions in 12.11. The
4638 Event consists of an EventQualifier indicating the properties of an incident and an EventCode ID
4639 representing a description of this incident together with possible remedial measures. Table 180 comprises
4640 a list of predefined IDs and descriptions for application oriented incidents. Ranges of IDs are reserved for
4641 profile specific and vendor specific incidents. Table 181 comprises a list of predefined IDs for SDCI specific
4642 incidents.

4643

4644

Events are classified in "Errors", "Warnings", and "Notifications". See 10.2 for these classifications and see
4645 11.5 for how the W-Master is controlling and processing these Events.

4646

4647

The Event Dispatcher handles each Event one by one and each Event is acknowledged with a single
4648 command (DLink Control Octet, see 12.3.1) from W-Master to W-Device.

4649

4650

10.7 W-Device features

4651

10.7.1 General

4652

The following W-Device features are defined to a certain degree in order to achieve a common behavior.
4653 They are accessible via standardized or W-Device specific methods or parameters. The availability of these
4654 features is defined in the IODD of a W-Device, except Pairing by Button.

4655

10.7.2 Scan

4656

This feature enables the detection of unpaired W-Device's within a W-Master's proximity during
4657 commissioning or for Roaming, see 5.6.1.5.

4658

This mandatory functionality is supported by the PL of the W-Device (see 5.6).

4659

10.7.3 Pairing by UniqueID

4660

This feature enables the pairing of an unpaired W-Device to a W-Master Port by a pairing request via the
4661 W-Device's UniqueID (see 4.4.2.1 and 5.6.1.3).

4662

This mandatory functionality is supported by the PL of the W-Device (see 5.6).

4663

10.7.4 Pairing by Button / Re-Pairing

4664

This feature enables a W-Device to use the "pairing by Button" mechanism (see Figure 49). The mechanism
4665 is predominantly used to change a damaged W-Device without the need of a Port and Device Configuration
4666 Tool" (PDCT).

4667

It is also possible to pair a W-Device to an unused, preconfigured W-Port during commissioning phase.
4668 Therefore, a W-Port configuration is needed by the W-Master Application, see 9.2.2.7 SM_SetPortConfig.
4669 The "Pairing-Button" or a similar trigger is mandatory for a W-Device. An overview for pairing by Button or
4670 Re-pairing by Button is given in 4.4.2.2 and 4.4.2.3.

4671

Therefore, the PL of a W-Device shall store the ConnectionParameter (see Table 140) in non-volatile
4672 memory (e.g. flash memory).

4673

This mandatory functionality is supported by the PL of the W-Device (see 5.6).

4674

10.7.5 Roaming

4675

This feature is used to pair a W-Device temporary to a W-Master, to allow predefined W-Device mobility
4676 between multiple predefined W-Masters (see 4.4.4 and 5.6.1.5).

4677

Therefore, the PL of a W-Device shall store the ConnectionParameter (see Table 140) in volatile memory
4678 (e.g. RAM memory). In case of a terminated or lost connection, the W-Device is available for other W-
4679 Master's.

- 4680 This mandatory functionality is supported by the PL of the W-Device (see 5.6).
- 4681 **10.7.6 Unpairing**
- 4682 This feature removes a paired or connected roaming W-Device from a W-Master port. The PL of the W-
4683 Device shall clear its ConnectionParameter (see Table 140).
- 4684 This mandatory functionality is supported by the PL of the W-Device (see 5.6).
- 4685 **10.7.7 W-Device backward compatibility**
- 4686 This feature enables a W-Device to play the role of a previous W-Device revision. In the start-up phase the
4687 W-Master system management overwrites the W-Device's inherent DeviceID (DID) with the requested
4688 former DeviceID. The W-Device's technology application shall switch to the former functional sets or
4689 subsets assigned to this DeviceID. W-Device backward compatibility support is optional for a W-Device.
4690 As a W-Device can provide backward compatibility to previous DeviceIDs (DID), these compatible Devices
4691 shall support all parameters and communication capabilities of the previous W-Device ID. Thus, the W-
4692 Device is permitted to change any communication or identification parameter in this case.
4693 Since the UniqueID of a W-Device contains the DeviceID (see 0), an overwrite of the DeviceID shall NOT
4694 lead in an update of the UniqueID.
- 4695 **10.7.8 Protocol revision compatibility**
- 4696 This feature enables a W-Device to adjust its protocol layers to a previous IOLW protocol version. In the
4697 start-up phase the W-Master system management can overwrite the W-Device's inherent protocol
4698 RevisionID (RID) in case of discrepancy with the RevisionID supported by the W-Master. Revision
4699 compatibility support is optional for a W-Device.
- 4700 **10.7.9 Factory settings**
- 4701 This feature enables a W-Device to restore parameters to the original delivery status. The Data Storage
4702 flag and other dynamic parameters such as "Error Count" (see B.2.17 in REF 1), "Device Status" (see
4703 B.2.18 in REF 1), and "Detailed Device Status" (see B.2.19 in REF 1) shall be reset when this feature is
4704 applied. This does not include vendor specific parameters such as for example counters of operating hours.
4705 NOTE In this case an existing stored parameter set within the W-Master will be automatically downloaded into the W-Device after
4706 its start-up.
- 4707 It is the vendor's responsibility to guarantee the correct function under any circumstances. The reset is
4708 triggered by the reception of the SystemCommand "Restore factory settings" (see Table 166). Reset to
4709 factory settings is optional for a W-Device.
- 4710 **10.7.10 Application reset**
- 4711 This feature enables a W-Device to reset the technology specific application. It is especially useful
4712 whenever a technology specific application has to be set to a predefined operational state without
4713 communication interruption and a shut-down cycle. The reset is triggered by the reception of a
4714 SystemCommand "Application reset" (see Table 166). Reset of the technology specific application is
4715 optional for a W-Device.
- 4716 **10.7.11 W-Device reset**
- 4717 This feature enables a W-Device to perform a "warm start". It is especially useful whenever a W-Device
4718 has to be reset to an initial state such as power-on. In this case communication will be interrupted. The
4719 warm start is triggered by the reception of a SystemCommand "W-Device reset" (see Table 166). Warm
4720 start is optional for a W-Device.
- 4721 **10.7.12 Device human machine interface (HMI)**
- 4722 This feature indicates the operational state of the W-Device's communication interface or the W-Device
4723 state itself. The indication of the modes is specified in 10.10.3.1. The indication is optional but highly
4724 recommended for a W-Device.
4725 The mandatory "Pairing-Button" supports pairing, re-pairing and further optional functions, see 10.10.3.2.
- 4726 **10.7.13 Parameter access locking**
- 4727 This feature enables a W-Device to globally lock or unlock write access to all writeable W-Device
4728 parameters accessible via the wireless interface (see B.2.4 in REF 1). The locking is triggered by the
4729 reception of a system parameter "Device Access Locks" (see Table 168). The support for these functions
4730 is optional for a W-Device.

- 4731 **10.7.14 Data Storage locking**
- 4732 Setting this lock will cause the "State_Property" (Table B.10 in REF 1) to switch to "Data Storage locked"
- 4733 and the W-Device not to send a DS_UPLOAD_REQ Event. The support for this function is mandatory for a
- 4734 W-Device if the Data Storage mechanism is implemented.
- 4735 **10.7.15 W-Device parameter locking**
- 4736 Setting this lock will disable overwriting W-Device parameters via on-board control or adjustment elements
- 4737 such as teach-in buttons (see B.2.4 in REF 1). The support of this function is optional for a W-Device.
- 4738 **10.7.16 W-Device user interface locking**
- 4739 Setting this lock will disable the operation of on-board human machine interface displays and adjustment
- 4740 elements such as teach-in or pairing button(s) on a W-Device (see B.2.4 in REF 1). The support for this
- 4741 function is optional for a W-Device.
- 4742 **10.7.17 Data Storage concept**
- 4743 The Data Storage mechanism in a W-Device allows to automatically save parameters in the Data Storage
- 4744 server of the W-Master and to restore them upon Event notification. Data consistency is checked in either
- 4745 direction within the W-Master and W-Device. Data Storage mainly focuses on configuration parameters of
- 4746 a W-Device set up during commissioning (see 10.5 and 11.3). The support of this function is optional for a
- 4747 W-Device.
- 4748 **10.7.18 Block Parameter**
- 4749 The Block Parameter transmission feature in a W-Device allows transfer of parameter sets from a PLC
- 4750 program without checking the consistency single data object by single data object. The validity and
- 4751 consistency check is performed at the end of the Block Parameter transmission for the entire parameter
- 4752 set. This function mainly focuses on exchange of parameters of a W-Device to be set up at runtime (see
- 4753 10.4). The support of this function is optional for a W-Device.
- 4754
- 4755 **10.8 W-Device design rules and constraints**
- 4756 **10.8.1 General**
- 4757 In addition to the protocol definitions in form of state, sequence, activity, and timing diagrams some more
- 4758 rules and constraints are required to define the behavior of the Devices. An overview of the major protocol
- 4759 variables scattered all over the standard is concentrated in Table 122 with associated references.
- 4760 For additional design rules of low energy W-Devices see clause 17.
- 4761 **10.8.2 Process Data**
- 4762 The process communication channel transmits the Process Data without any interference of the On-request
- 4763 Data communication channels. Process Data exchange starts automatically whenever the W-Device is
- 4764 switched into the OPERATE state via message from the W-Master.
- 4765 The format of the transmitted data is W-Device specific and varies from no data octets up to 32 octets in
- 4766 each communication direction.
- 4767 Recommendations:
- 4768 • Data structures should be suitable for use by PLC applications.
- 4769 • It is highly recommended to comply with the rules in E.3.3 in REF 1 and in REF 3.
- 4770 See 10.2, 12.3.1 and 12.4.1 for details on the indication of valid or invalid Process Data via the transmission
- 4771 of Process Data (PDx_Valid) within the data exchange.
- 4772 **10.8.3 MaxRetry error detection**
- 4773 It is the responsibility of the W-Device designer to define the appropriate behavior of the W-Device in
- 4774 case communication with the W-Master exceeds the configured maximum Retries for a data transmission
- 4775 (transition T4 in Figure 56 handles detection of the MaxRetry error, reported via AL_Control (MaxRetry) to
- 4776 the W-Device Application). This Error indicates that the configured cycle time has not been kept, e.g. a
- 4777 W-Device is at the edge of the RF coverage area.
- 4778 If the AL_Control reports a MaxRetry error, the Device Application shall send the Event
- 4779 (IOLW_Retry_Error) via event channel to the W-Master.
- 4780 NOTE This is especially important for actuators such as valves or motor management.

4781 10.8.4 Communication loss

4782 It is the responsibility of the W-Device designer to define the appropriate behavior of the W-Device in case
4783 communication with the W-Master is lost (transition T10 in Figure 56 handles detection of the
4784 communication loss (reported via PL_State service), while 10.2 define resulting W-Device actions).

4785 NOTE This is especially important for actuators such as valves or motor management.

4786 10.8.5 Direct Parameter

4787 Compared to IO-Link (using the page communication channel) a Direct Parameter access for IO-Link
4788 wireless is redirected to the ISDU communication channel, except the MasterCommand (see 7.7.1 and
4789 7.7.2). The access to the Direct Parameter pages provides no handshake mechanism (similar to IO-Link),
4790 to ensure proper reception or validity of the transmitted parameters. The Direct Parameter page can only
4791 be accessed single octet by single octet (Subindex) or as a whole (16 octets). Therefore, the consistency
4792 of parameters larger than 1 octet cannot be guaranteed in case of single octet access.

4793 The parameters from the Direct Parameter page cannot be saved and restored via the Data Storage
4794 mechanism.

4795 10.8.6 ISDU communication channel

4796 The ISDU communication channel provides a powerful means for the transmission of parameters and
4797 commands (see 14.3).

4798 The following rules shall be considered when using this channel (see Figure 11).

- 4799 • Index 0 Subindex 1 (MasterCommand) is not accessible via the ISDU communication channel.
- 4800 • All other Subindices of Index 0 (Direct Parameter page 1) included Index 1 (Direct Parameter
4801 page 2) are redirected by the W-Master to the Direct Parameter page 1 / 2 using the ISDU
4802 communication channel.
- 4803 • Index 3 cannot be accessed by a PLC application program. The access is limited to the W-Master
4804 application only (Data Storage).
- 4805 • After reception of an ISDU request from the W-Master the W-Device shall respond within 5 000 ms
4806 (see Table 122). Any violation causes the W-Master to abandon the current task.

4807

4808 10.8.7 DeviceID rules related to W-Device variants

4809 Devices with a certain DeviceID and VendorID shall not deviate in communication and functional behavior.
4810 This applies for sensors and actuators. Those Devices may vary for example in

- 4811 • housing materials,
- 4812 • mounting mechanisms,
- 4813 • other features, and environmental conditions.

4814

4815 **10.8.8 Protocol constants**

4816 Table 122 gives an overview of the major protocol constants for Devices.

4817
4818

Table 122 Overview of the protocol constants for W-Device

System variable	References	Values	Definition
ISDU acknowledgement time, for example after a SystemCommand	14.1.9	5 000 ms	Time from reception of an ISDU for example SystemCommand and the beginning of the response message of the W-Device (see Figure 75)
Maximum number of entries in Index List	B.2.3, REF 1	70	Each entry comprises an Index and a Subindex. 70 entries result in a total of 210 octets.
Preset values for unused or reserved parameters, for example FunctionID	Annex C	0 (if numbers) 0x00 (if characters)	Engineering shall set all unused parameters to the preset values.
Detection for COMLOST	0	5 * MaxRetry	ComLost is reported via PL-service PL_State, see Figure 46, T10, T12
Detection for "wireless connection synchronized"	0	3 W-Sub-cycles	SYNCED is reported via service PL_State, see Figure 46, T9 (3 subsequent DLinks received by W-Device)
MinCycleTime	14.1.2	N * 5 ms	W-Device or W-Bridge defines its minimum cycle time to acquire input or process output data.
Usable Index range	14.3	See Table 168	This version of the standard reserves some areas within the total range of 65535 Indices.
Errors and warnings	13.8	50 ms	An Event with MODE "Event appears" shall stay at least for the duration of this time.
EventCount	6.3.6	1	Constraint for AL_Event.req.

4819
4820

4821 **10.9 I/O W-Device description (W-IODD)**

4822 An IODD (I/O Device Description) is a file that formally describes an IO-Link Device. It provides all the
4823 necessary properties to establish communication and describes the Device parameters and their
4824 boundaries to establish the desired function of a sensor or actuator.

4825

4826 An IODD file shall be provided for each W-Device, and shall include all information necessary to support
4827 this standard.


4828

4829 The IODD can be used by engineering tools for PLCs and/or W-Masters for the purpose of identification,
4830 configuration, definition of data structures for Process Data exchange, parameterization, and diagnosis
4831 decoding of a particular Device. Additionally, IODDs are also used for automatic IO-Link Wireless
4832 conformance testing.

4833

4834 NOTE Details of the IODD language to describe a Device can be found in REF 3 and clause 21.

4835



4836

Figure 112 Schematic representation of the use of (a) a W-Device and (b) a W-Bridge to connect a wired IO-link Device.

4837

4838

4839

4840

10.9.1 CommNetwork Profile Instance for the IODD file for IO-Link wireless

4841

This section gives an example for the content of the IODD file using “IOLinkWirelessCommNetworkProfileT”. The wired connection part is optional and should be used to describe a W-Device equipped with wired power connection.

4842

4843

4844

In the case of a W-Bridge configuration, the IODD of the wired IO-Link Device and the required extension for wireless can be merged together to constitute the W-IODD of the novel entity formed by the W-Bridge and the wired IO-Link Device. For more details see clause 21.

4845

4846

4847

4848

The wireless specific parameters which shall be used as an extension to the Direct Parameter page 1 are located from 0x5000 to 0x50FF.

4849

4850

4851

In most cases the “CommNetworkProfile” of the wired IODD must be replaced by the “IOLinkWirelessCommNetworkProfileT” of the wireless IODD. The IODD description from index 0x5000 to 0x50FF must be added to the wired IODD. to get a IODD for a W-Device

4852

4853

4854

4855

In the case where the device has a wired and a wireless interface, 2 IODD files, one for the wired and another one for the wireless connection, must be used to describe it.

4856

4857

4858

4859

10.9.1.1 Example of a wireless extension:

4860

```
<CommNetworkProfile xsi:type="IOLinkWirelessCommNetworkProfileT" iolinkRevision="V1.1">
```

4861

```
<TransportLayer>
```

4862

```
<PhysicalLayer minCycleTime="50" doubleSlot="yes" isABridge="yes">
```

4863

```
<Connection xsi:type="M5ConnectionT">
```

4864

```
<Wire1/>
```

4865

```
<Wire2 function="NC"/>
```

4866

```
<Wire3/>
```

4867

```
<Wire4/>
```

4868

```

4869     </Connection>
4870
4871 </PhysicalLayer>
4872 </TransportLayer>
4873 </CommNetworkProfile>
4874
4875 PhysicalLayer(mandatory)
4876 •   minCycleTime   (required)   value is expressed in micro-second
4877 •   doubleSlot     (required)   value = ["yes" | "no"]
4878 •   isABridge      (required)   value = ["yes" | "no"]
4879

```

Connection (line powered, optional)

This parameter describes the sensor's wiring. In case of a W-Device which gets its energy line powered, it describes the type of connector and the feature of each pin.

10.10 W-Device diagnosis

10.10.1 Concepts

This standard provides only most common EventCodes in 15.1. It is the purpose of these common diagnosis information to enable an operator or maintenance person to take fast remedial measures without deep knowledge of the W-Device's technology. Thus, the text associated with a particular EventCode shall always contain a corrective instruction together with the diagnosis information.

Fieldbus-W-Master-Gateways tend to only map few EventCodes to the upper system level. Usually, vendor specific EventCodes defined via the IODD can only be decoded into readable instructions via a Port and W-Device Configuration Tool (PDCT) or specific vendor tool using the IODD.

Condensed information of the W-Device's "state of health" can be retrieved from the parameter "Device Status" (see B.2.18 in REF 1). Table 136 provides an overview of the various possibilities for Devices and shows examples of consumers for this information.

If implemented, it is also possible to read the number of faults since power-on or reset via the parameter "Error Count" (see B.2.17 in REF 1) and more information in case of profile Devices via the parameter "Detailed Device Status" (see B.2.19 in REF 1).

NOTE Profile specific values for the "Detailed Device Status" are given in REF 4.

If required, it is highly recommended to provide additional "deep" technology specific diagnosis information in the form of W-Device specific parameters (see Table 168) that can be retrieved via port and W-Device configuration tools for Masters or via vendor specific tools. Usually, only experts or service personnel of the vendor are able to draw conclusions from this information.

4906

Table 123 Classification of W-Device diagnosis incidents

Diagnosis incident	Appear/disappear	Single shot	Parameter	Destination	Consumer
Error (fast remedy; standard EventCodes)	yes	-	-	PLC or HMI (fieldbus mapping)	Maintenance and repair personnel
Error (IODD: vendor specific EventCodes; see Table D.1)	yes	-	-	PDCT or vendor tool	Vendor service personnel
Error (via W-Device specific parameters)	-	-	See Table B.8 REF 1	PDCT or vendor tool	Vendor service personnel
Warning (fast remedy; standard EventCodes)	yes	-	-	PLC or HMI	Maintenance and repair personnel
Warning (IODD: vendor specific EventCodes; see Table D.1)	yes	-	-	PDCT or vendor tool	Vendor service personnel
Warning (via W-Device specific parameters)	-	-	See Table B.8 REF 1	PDCT or vendor tool	Vendor service personnel
Notification (Standard EventCodes)	-	yes	-	PDCT	Commissioning personnel
Detailed W-Device status	-	-	-	PDCT or vendor tool	Commissioning personnel and vendor service personnel
Number of faults via parameter "Error Count"	-	-	See B.2.1 REF 1	PDCT or vendor tool	Commissioning personnel and vendor service personnel
W-Device "health" via parameter "W-Device Status"	-	-	See B.2.18, Table B.13 REF 1	HMI, Tools such as "Asset Management"	Operator

4907

10.10.2 Events

MODE values shall be assigned as follows (see 12.11.1):

- Events of TYPE "Error" shall use the MODEs "Event appears / disappears"
- Events of TYPE "Warning" shall use the MODEs "Event appears / disappears"
- Events of TYPE "Notification" shall use the MODE "Event single shot"

The following requirements apply:

- The Event which is already placed in the Event queue are discarded by the Event Dispatcher when communication is interrupted or cancelled.

NOTE After communication resumes, the technology specific application is responsible for proper reporting of the current Event causes.

- It is the responsibility of the Event Dispatcher to control the "Event appears" and "Event disappears" flow. Once the Event Dispatcher has sent an Event with MODE "Event appears" for a given EventCode, it shall not send it again for the same EventCode before it has sent an Event with MODE "Event disappears" for this same EventCode.
- Each Event shall use static mode, type, and instance attributes.
- Each vendor specific EventCode shall be uniquely assigned to one of the TYPEs (Error, Warning, or Notification).

4927

In order to prevent the diagnosis communication channel (see Figure 11) from being flooded, the following requirements apply:

- The same diagnosis information shall not be reported at less than 60 s intervals, that is the Event Dispatcher shall not invoke the AL_Event service with the same EventCode more often than 60 s.
- The Event Dispatcher shall not issue an "Event disappears" less than 50 ms after the corresponding "Event appears".
- Subsequent incidents of errors or warnings with the same root cause shall be disregarded, that means one root cause shall lead to a single error or warning.
- The Event Dispatcher shall not invoke the AL_Event service with an EventCount greater than one.
- Errors are prioritized over Warnings.

10.10.3 W-Device HMI

10.10.3.1 Visual indicators

The indication of IO-Link Wireless communication on the W-Device is optional (but highly recommended). The different states shall then be implemented, see Table 124. The IO-Link Wireless indication shall use a green indicator.

Table 124 Visual states of W-Device

W-Device state	LED indication	LED-Timing (see NOTE 1)	Initiator for Application
Unpaired	permanent on	LED on	SM_DeviceMode.ind(UNPAIRED)
Paired	blink	Trep=700 ms; Toff=350 ms	SM_DeviceMode.ind(PAIRED)
Connected	inverted flash	Trep=1000 ms; Toff=100 ms	SM_DeviceMode.ind(PREOPERATE) SM_DeviceMode.ind(OPERATE)
Wink	double flash	Trep=1000 ms; Ton=100 ms; Toff=100 ms	See Table 166, Reserved for profiles.

NOTE 1: The LED timings are typical values. A tolerance of 10% shall not be exceeded.

The indication of the blinking LED follows the timing shown in Figure 113.





Figure 113 Device LED blink timing

4954 The indication of the double flashing LED follows the timing shown in Figure 114.
 4955



4956 **Figure 114 Device LED double flash timing.**

4957
 4958 The additional function of visual indicators for low energy W-Devices are defined in 17.1.8.
 4959

4960 **10.10.3.2 Pairing Button**

4961 The “Pairing-Button” or a similar trigger is mandatory for a W-Device. An overview for pairing by Button or
 4962 Re-pairing by Button is given in 4.4.2.2 and 4.4.2.3. Further, each button press shall trigger a “HMI button
 4963 pressed” Event, see Table 180 EventCodes.
 4964 The Pairing-Button supports further functions, depending on the duration of the button pressed, see Table
 4965 125.
 4966
 4967

Table 125 Pairing Button functions

Button timing	press	Button press function	Remarks
[0.1...1] s		Wake up a sleeping W-Device and / or activation of the visual indicators	Highly recommended for low energy W-Devices with an internal power source.
[>1...3] s		No action	
[>3...10] s		Pairing by Button / Re-pairing by Button	mandatory for all W-Devices
[>10...30] s		No action	
>30s		Device Reset (see 10.7.11)	Highly recommended for low energy W-Devices with an internal power source.

4968
 4969 NOTE: The button press timings are typical values. A tolerance of 10% shall not be exceeded.
 4970

4971 **10.11 W-Device connectivity**

4972 See 4.4.2 (Pairing), 4.4.3 (Unpairing) and 4.4.4 (Roaming) for the different possibilities of pairing W-Devices
 4973 to W-Master ports and the corresponding mechanisms.
 4974

4975 NOTE For compatibility reasons, this standard does not prevent W-Devices from providing additional functions.
 4976
 4977

11 W-Master

11.1 Overview

The W-Master handles the communication between the application and its associated W-Devices. The recommended relationship between the IO-Link wireless technology and a fieldbus technology was already presented in clause 4.2. Even though this may be the major use case in practice, it does not automatically imply that the IO-Link wireless technology depends on the integration into fieldbus systems. It can also be directly integrated into PLC systems, industrial PC, or other control systems without fieldbus communication in between.

Figure 115 provides an overview of the complete structure and services of a W-Master. The purpose of the different layers and their service interfaces are described in the previous clauses.




Figure 115 Structure and services of a W-Master

The W-Master applications comprise first a fieldbus specific gateway or direct connection to a PLC (host) for the purpose of start-up configuration and parameterization as well as Process Data exchange, user-program-controlled parameter change at runtime, and diagnosis propagation. For the purpose of configuration, parameterization, and diagnosis during commissioning a so-called "Port and Device Configuration Tool" (PDCT) is connected either directly to the W-Master or via fieldbus communication. These instruments are using the following common W-Master applications.

- **W-Master-, Track- and W-Port-Configuration Manager (CM)**, transforms the user configuration assignments into W-Port and track set-ups (see 11.2 in REF 1);
- **Data Storage (DS)** mechanism, which can be used to save and restore the W-Device parameters (see 11.3 in REF 1);


5001
5002
5003
5004
5005
5006
5007
5008
5009
5010
5011
5012
5013
5014
5015
5016

- **Diagnosis Unit (DU)**, which routes Events from the AL to the Data Storage unit or the gateway application (see 11.4 in REF 1);
- **On-request Data Exchange (ODE)**, which provides for example acyclic parameter access (see 11.5 in REF 1);
- **Process Data Exchange (PDE)** builds the bridge to upper level automation instruments. It also controls the operational states to ensure the validity of Process Data (see 11.6 in REF 1).

These W-Master applications provide standard methods/functions to the available Services, specified in the following subclauses.

The Configuration Manager (CM) and the Data Storage mechanism (DS) need special coordination in respect to On-request Data, see Figure 116 and **Fehler! Verweisquelle konnte nicht gefunden werden..**

The gateway application maps these functions into the features of a particular fieldbus/PLC or directly into a host system. It is not within the scope of this standard to define any of these gateway applications.



5017
5018
5019
5020

Figure 116 Relationship of the common W-Master applications

The internal variables between the common W-Master applications are specified in Table 126.. The main responsibility is assigned to the Configuration Manager (CM) as shown in Figure 116 and explained in 11.2

5021

Table 126 Internal variables and Events to control the common W-Master applications

Internal Variable	Definition
OperatingMode	This variable activates the W-Port and provides the configuration parameters.
ReadyToOperate	This variable indicates correct configuration of the W-Port.
StartOperate	This variable allows for explicit change of all ports to the OPERATE mode.
Operating	This variable indicates all ports are in cyclic Process Data exchange mode
Fault	This variable indicates abandoned communication at any W-Port (see Figure 85 and Table 127 State transition tables of the Track Configuration Manager).
DS_Startup	This variable triggers the Data Storage (DS) state machine causing an Upload or Download of W-Device parameters if required (see 11.3).
DS_Ready	This variable indicates the Data Storage has been accomplished successfully; operating mode is CYCLIC or ROAMING (see 9.2.2.2)
DS_Fault	This variable indicates the Data Storage has been aborted due to a fault.
DS_Delete	Any verified change of W-Device configuration leads to a deletion of the stored data set in the Data Storage.
DS_Upload	This variable triggers the Data Storage state machine in the W-Master due to the special Event "DS_UPLOAD_REQ" from the W-Device.
OD_Start	This variable enables On-request Data access via AL_Read and AL_Write.
OD_Stop	This variable indicates that On-request Data access via AL_Read and AL_Write is acknowledged with a negative response to the gateway application.
OD_Block	Data Storage upload and download actions disable the On-request Data access through AL_Read or AL_Write. Access by the gateway application is denied.
OD_Unblock	This variable enables On-request Data access via AL_Read or AL_Write.
DU_Start	This variable enables the Diagnosis Unit to propagate remote (W-Device) or local (W-Master) Events to the gateway application.
DU_Stop	This variable indicates that the W-Device Events are not propagated to the gateway application and not acknowledged. Available Events are blocked until the DU is enabled again.
PD_Start	This variable enables the Process Data exchange with the gateway application.
PD_Stop	This variable disables the Process Data exchange with the gateway application.

5022

5023

5024

11.2 Configuration Manager (CM)

5025

5026

11.2.1 General

5027

The coordinating role of the configuration manager amongst all the common W-Master applications is described in the IO-link spec, clause 11.2.1 in REF 1. After setting up a W-Port to the assigned modes (see 11.2.2.1 through 11.2.2.3 in REF 1) CM starts the Data Storage mechanism (DS) and returns the variable "Operating" or "Fault" to the gateway application.

5028

5029

5030

5031

5032

In case of the variable "Operating" of a particular W-Port, the gateway application activates the state machines of the associated Diagnosis Unit (DU), the On-request Data Exchange (ODE), and the Process Data Exchange (PDE).

5033

5034

5035




Figure 117 Sequence diagram of configuration manager actions

5036
5037

5038 **11.2.2 Configuration parameter**

5039
5040 **11.2.2.1 Track OperatingMode**

5041 One of the following operating modes can be selected. All modes are mandatory. The OperatingMode is
5042 significant to all W-Ports of a track see SM_SetPortConfig and SM_GetPortConfig.

5043 **Inactive**

5044 All W-Ports of the selected track are deactivated. The corresponding Process Data for input and output is
5045 zero.

5046 **CyclicMode**

5047 The track is configured for continuous cyclic communication. Process and On-request Data will be
5048 transmitted. The connection and the W-Device specific cycle time will be monitored. It is not possible to
5049 scan for unpaired W-Devices or pair W-Devices. Roaming is not supported in this mode.

5050 **ServiceMode**

5051 In addition to the cyclic communication, the configuration channels are activated on this track to support
5052 scan, pairing and roaming activities. To avoid collisions on the configuration channels, only one track of a
5053 multi-track W-Master shall be operated in the ServiceMode at the same time.

5054 **11.2.2.2 PortOperatingMode**

5055 **PortInactive**

5056 The W-Master port is deactivated. The corresponding Process Data for input and output is zero.

5057 **PortCyclicMode**

5058 For operate a port in Cyclic Mode it is necessary to configure the corresponding Track in Mode or
5059 ServiceMode.

5060 **PortRoamingMode**

5061 For operate a port in PortRoamingMode it is necessary to configure one track permanently in ServiceMode

5062

5063 **11.2.2.3 PortCycle**

5064 The process data update is performed in a cyclic manner and is determined by the W-Port related cycle
5065 time, within which the process data of the W-Device are read or written.

5066 It is highly recommended to perform the process data update right after the read of the input data
5067 (AL_GetInput) within the same port cycle.

5068 It is also highly recommended to write the process output data to the W-Devices within one port cycle
5069 (AL_SetOutput).

5070 One of the following W-Port cycle modes can be selected. None of the modes is mandatory but it is highly
5071 recommended to support all modes.

5072

5073 **FreeRunning**

5074 The W-Port cycle timing is not restricted.

5075

5076 **FixedValue**

5077 The port cycle timing is fixed to a specific value which shall be set via service SM_SetPortConfig for all
5078 ports. If the Device is not able to achieve this timing, for example if the timing is lower than the
5079 MinCycleTime of the Device, an error shall be generated. The fixed value can be written in the
5080 ConfiguredCycleTime parameter as specified in 11.2.2.4.

5081

5082 **11.2.2.4 Configured/Real CycleTime**

5083 This parameter contains the requested ConfiguredCycleTime or actual RealCycleTime for the specific ports.
5084 It shall be passed as a value via SM_SetPortConfig and SM_GetPortConfig. The RealCycleTime must
5085 always be equal or greater than the MinCycleTime.

5086

5087 **11.2.2.5 PDConfig**

5088 This set of parameters contains the rules for the Process Data mapping between the W-Device Process
5089 Data stream and the gateway Process Data stream (see example in Figure 127 for the definitions).

5090

5091	This parameter contains the requested length of the W-Device input ProcessDataIn Bits
5092	PosIn
5093	This parameter contains the offset within the gateway input Process Data stream in Bit.
5094	SrcOffsetIn
5095	This parameter contains the offset within the W-Device Input Process Data stream in Bit.
5096	LenOut
5097	This parameter contains the requested length of the W-Device output ProcessDataOut Bits.
5098	PosOut
5099	This parameter contains the offset within the gateway output Process Data stream in Bit.
5100	SrcOffsetOut
5101	This parameter contains the offset within the W-Device Output Process Data stream in Bit.
5102	
5103	11.2.2.6 DeviceIdentification
5104	This set of parameters contains the actual configured W-Device identification.
5105	VendorID
5106	This parameter contains the requested or read vendor specific ID as specified in B.1.8. in REF 1
5107	DeviceID
5108	This parameter contains the requested or read W-Device specific ID as specified in B.1.9. in REF 1
5109	SerialNumber
5110	This parameter contains the requested or read SerialNumber as specified in B.2.13. in REF 1
5111	InspectionLevel
5112	This parameter contains the requested InspectionLevel as specified in Table 78. in REF 1
5113	
5114	11.2.2.7 DataStorageConfig
5115	This set of parameter items contains the settings of the Data Storage (DS) mechanism.
5116	ActivationState
5117	This parameter contains the requested state of the DS mechanism for this W-Port. The following modes are supported:
5118	
5119	DS_Enabled
5120	The DS mechanism is active and provides the full functionality as specified in clause 11.3.2
5121	DS_Disabled
5122	The DS mechanism is inactive, and the complete parameter set of this W-Port remains stored.
5123	DS_Cleared
5124	The DS mechanism is disabled, and the stored parameter set of this W-Port is cleared.
5125	DownloadEnable
5126	The DS mechanism is permitted to write data to the connected W-Device.
5127	UploadEnable
5128	The DS mechanism is permitted to read data from the connected W-Device.
5129	

11.2.3 State machine of the Track Configuration Manager

Figure 118 shows the state machine of the Track configuration manager.




Figure 118 State machine of the Track Configuration Manager

Table 127 State transition tables of the Track Configuration Manager

STATE NAME	STATE DESCRIPTION
INACTIVE_0	Waiting for activation by W-Master application. W-Master configuration is not set.
TrackINACTIVE_1	W-Master configuration loaded. Waiting for activation of track in operating mode (CYCLIC or ROAMING).
TrackACTIVE_2	Track is active (CYCLIC, SCAN, PAIRING or ROAMING mode). Depending on the W-Port configurations the gateway application is exchanging Process Data and ready to send or receive On-request Data. For SCAN, PAIRING or ROAMING mode additionally the configuration channels are active.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke SM_SetMasterConfig to configure each track, dependent on the HW-Tracks on a W-Master (track number 0 up to 4). Each Track shall use the same MasterID and Blacklist.
T2	1	2	Invoke SM_SetTrackMode(CYCLIC or ROAMING) depending on track configuration.
T3	1	2	Invoke SM_SetTrackMode(STOP).
T4	2	0	Invoke SM_SetTrackMode(STOP) for all tracks.
T5	1	0	See T4.

11.2.4 State machine of the W-Port Configuration Manager

Figure 119 shows the state machine of the W-Port configuration manager.




Figure 119 State machine of the W-Port Configuration Manager

Key:
 xFAULT: REV_FAULT or COMP_FAULT or SERNUM_FAULT
 yMODE: INACTIVE or COMLOST

5149
5150

Table 128 State transition tables of the W-Port Configuration Manager

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for any of the OperatingMode variables from the gateway application: CYCLIC, ROAMING.
SM_Startup_1	Waiting for an established communication or loss of communication or any of the faults REVISION_FAULT, COMP_FAULT, or SERNUM_FAULT (see Table 109).
DS_ParamManager_2	Waiting for accomplished Data Storage startup. Parameter are downloaded into the W-Device or uploaded from the W-Device.
PortFault_3	W-Device in state PREOPERATE (communicating). However, one of the three faults REVISION_FAULT, COMP_FAULT, SERNUM_FAULT, or DS_Fault occurred.
CM_ReadytoOperate_4	W-Port is waiting until the gateway application indicates "StartOperate".
WaitingOnOperate_5	Waiting for SM to switch to OPERATE.
PortActive_6	W-Port is in OPERATE mode. The gateway application is exchanging Process Data and ready to send or receive On-request Data.

5151

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	Invoke SM_SetPortConfig(CYCLIC) or SM_SetPortConfig(ROAMING)
T2	1	2	DS_Startup: The DS state machine is triggered.
T3	1	3	"Fault" indication to gateway application (REVISION_FAULT, COMP_FAULT, or SERNUM_FAULT), see Figure 116.
T4	2	4	Indication to gateway application: ReadyToOperate
T5	2	3	Data Storage failed. Rollback to previous parameter set.
T6	4	5	SM_Operate.
T7	5	6	Indication to gateway application: "Operating" (see Figure 117).
T8	1,2,3,4,5,6	0	SM_SetPortConfig_INACTIVE. "Fault" indication to gateway application: COMLOST or INACTIVE

5152

INTERNAL ITEMS	TYPE	DEFINITION
DS_Ready	Bool	Data Storage sequence (upload, download) accomplished. W-Port operating mode is CYCLIC or ROAMING.
DS_Fault	Bool	See Table 126
StartOperate	Bool	Gateway application causes the W-Port to switch to OPERATE.
CYCLIC	Bool	One of the Operating Modes (see 11.2.2.1)
ROAMING	Bool	One of the Operating Modes (see 11.2.2.1)

5153

11.3 Data Storage (DS)

5154

5155

11.3.1 Overview

5156

5157

5158

5159

5160

Data Storage between W-Master and W-Device is specified within this standard, whereas the adjacent upper Data Storage mechanisms depend on the individual fieldbus or application system. The W-Device holds a standardized set of objects providing parameters for Data Storage, memory size requirements, control and state information of the Data Storage mechanism. Changes of Data Storage parameter sets are detectable via the "Parameter Checksum" (see 10.4.8 in REF 1).

11.3.2 DS data object

The structure of a Data Storage data object is specified see Table F.1 in REF 1.

The W-Master shall always hold the header information (Parameter Checksum, VendorID, and DeviceID) for the purpose of checking and control. The object information (objects 1...n) will be stored within the non-volatile memory part of the W-Master (see Annex F in REF 1.). Prior to a download of the Data Storage data object (parameter block), the W-Master will check the consistency of the header information with the particular W-Device.

The maximum permitted size of the Data Storage data object is 2 x 2^10 octets. It is mandatory for W-Masters to provide at least this memory space per W-Port if the Data Storage mechanism is implemented.

11.3.3 DS state machine

The Data Storage mechanism is called right after establishing the communication, before entering the OPERATE mode. During this time, any other communication with the W-Device shall be rejected by the gateway.

Figure 120 shows the state machine of the Data Storage mechanism.





Figure 120 Main state machine of the Data Storage mechanism

5180
5181
5182

Figure 121 shows the submachine of the state "UpDownload_2". This submachine can be invoked by the Data Storage mechanism or during runtime triggered by a "DS_UPLOAD_REQ" Event.



5183
5184

Figure 121 Submachine "UpDownload_2" of the Data Storage mechanism

5185 Figure 122 shows the submachine of the state "Upload_7".
5186 This state machine can be invoked by the Data Storage mechanism or during runtime triggered by a
5187 DS_UPLOAD_REQ Event.
5188





Figure 122 Data Storage submachine "Upload_7"


5189
5190

5191 Figure 123 demonstrates the Data Storage upload sequence using the Data Storage Index (DSI) specified in B.2.3 and Table B.10 in REF 1. The structure of Index_List is specified in Table B.11 in REF 1. The DS_UPLOAD_FLAG shall be reset at the end of each sequence (see Table B.10 in REF 1).
 5192
 5193
 5194



5195 **Figure 123 Data Storage upload sequence diagram**

5196 Figure 124 shows the submachine of the state "Download_10". This state machine can be invoked by the
 5197 Data Storage mechanism.
 5198
 5199



5200 **Figure 124 Data Storage submachine "Download_10"**

5201
5202
5203
5204
5205
5206
5207
5208
5209
5210
5211
5212
5213
5214
5215
5216
5217
5218
5219
5220
5221
5222
5223
5224
5225
5226
5227
5228
5229
5230
5231
5232
5233
5234
5235

Figure 125 demonstrates the Data Storage download sequence using the Data Storage Index (DSI) specified in B.2.3 and Table B.10 in REF 1. The structure of Index_List is specified in Table B.11 in REF 1. The DS_UPLOAD_FLAG shall be reset at the end of each sequence (see Table B.10 in REF 1).




Figure 125 Data Storage download sequence diagram

5236
5237
5238

Table 129 shows the states and transitions of the Data Storage state machines.

Table 129 States and transitions of the Data Storage state machines

STATE NAME	STATE DESCRIPTION
CheckActivationState_0	Check current state of the DS configuration: Independently from communication status, DS_Startup from configuration management or an Event DS_UPLOAD_REQ is expected.
WaitingOnDSActivity_1	Waiting for upload request, W-Device startup, all changes of activation state independent of the W-Device communication state.
UpDownload_2	Submachine for up/download actions and checks
Off_3	Data Storage handling switched off or deactivated
SM: CheckIdentity_4	Check W-Device identification (DeviceID, VendorID) against parameter set within the Data Storage (see Table F.2 in REF 1). Empty content does not lead to a fault.
SM: CheckMemSize_5	Check data set size (Index 3, Subindex 3) against available W-Master storage size.
SM: CheckUpload_6	Check for DS_UPLOAD_FLAG within the Data Storage Index (see Table B.10 in REF 1).
SM: Upload_7	Submachine for the upload actions
SM: CheckDSValidity_8	Check whether stored data within the W-Master is valid or invalid. A W-Master could be replaced between upload and download activities. It is the responsibility of a W-Master designer to implement a validity mechanism according to the chosen use cases.
SM: CheckChecksum_9	Check for differences between the data set content and the W-Device parameter via the "Parameter Checksum" within the Data Storage Index (see Table B.10 in REF 1).
SM: Download_10	Submachine for the download actions
SM: DS_Ready_11	Prepare DS_Ready indication to the Configuration Management (CM)
SM: DS_Fault_12	Prepare DS_Fault indication from "Identification_Fault", "SizeCheck_Fault", "Upload_Fault", and "Download_Fault" to the Configuration Management (CM)
SM: Decompose_IL_13	Read Index List within the Data Storage Index (see Table B.10 in REF 1). Read content entry by entry of the Index List from the W-Device (see Table B.11 in REF 1).
SM: ReadParameter_14	Wait until read content of one entry of the Index List from the W-Device is accomplished.
SM: StoreDataSet_15	Task of the gateway application: store entire data set according to Table F.1 and Table F. in REF 1)
SM: Upload_Fault_16	Prepare Upload_Fault indication from "W-Device_Error" and "COM_ERROR" as input for the higher level indication DS_Fault.
SM: Decompose_Set_17	Write parameter by parameter of the data set into the W-Device according to Table F.1 in REF 1
SM: Write_Parameter_18	Wait until write of one parameter of the data set into the W-Device is accomplished.
SM: Download_Done_19	Download completed. Read back "Parameter Checksum" from the Data Storage Index according to Table B.10 in REF 1. Save this value in the stored data set according to Table F.2 in REF 1.
SM: Download_Fault_20	Prepare Download_Fault indication from "W-Device_Error" and "COM_ERROR" as input for the higher level indication DS_Fault.

5239

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	1	-
T2	1	2	-
T3	2	1	OD_Unblock; Indicate DS_Ready to CM
T4	1	2	Confirm Event "DS_UPLOAD_REQ"
T5	2	1	DS_Break (AL_Write, Index 3, Subindex 1); clear intermediate data (garbage collection); rollback to previous parameter state; DS_Fault (see Figure 116 OD_Unblock.

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T6	3	2	-
T7	0	3	-
T8	3	1	-
T9	1	1	Clear saved parameter set (see Table F.1 and Table F.2 in REF 1)
T10	3	3	Clear saved parameter set (see Table F.1 and Table F.2 in REF 1)
T11	1	3	Clear saved parameter set (see Table F.1 and Table F.2 in REF 1)
T12	1	3	-
T13	3	3	Confirm Event "DS_UPLOAD_REQ"; no further action
T14	3	3	DS_Ready to CM
T15	4	12	Indicate DS_Fault(Identification_Fault) to the gateway application
T16	4	5	Read "Data Storage Size" according to Table B.10 in REF 1, OD_Block
T17	5	12	Indicate DS_Fault(SizeCheck_Fault) to the gateway application
T18	5	6	Read "DS_UPLOAD_FLAG" according to Table B.10 in REF 1.
T19	6	7	Data Storage Index 3, Subindex 1: "DS_UploadStart" (see Table B.10 in REF 1)
T20	6	8	-
T21	8	7	Data Storage Index 3, Subindex 1: "DS_UploadStart" (see Table B.10 in REF 1)
T22	8	9	-
T23	7	12	Data Storage Index 3, Subindex 1: "DS_Break" (see Table B.10 in REF 1). Indicate "DS_Fault(Upload)" to the gateway application
T24	9	10	Data Storage Index 3, Subindex 1: "DS_DownloadStart" (see Table B.10 in REF 1)
T25	9	11	-
T26	7	11	Data Storage Index 3, Subindex 1: "DS_UploadEnd"; read Parameter Checksum (see Table B.10 in REF 1)
T27	10	11	-
T28	10	12	Data Storage Index 3, Subindex 1: "DS_Break" (see Table B.10 in REF 1) Indicate "DS_Fault(Download)" to the gateway application.
T29	6	12	Indicate DS_Fault(Data Storage locked) to the gateway application
T30	13	14	AL_Read (Index List)
T31	14	13	-
T32	14	16	-
T33	14	16	-
T34	13	16	-
T35	13	15	Read "Parameter Checksum" (see Table B.10 in REF 1)
T36	15	16	-
T37	17	18	Write parameter via AL_Write
T38	18	17	-
T39	18	20	-
T40	18	20	-
T41	17	19	Data Storage Index 3, Subindex 1: "DS_DownloadEnd" (see Table B.10 in REF 1) Read "Parameter Checksum" (see Table B.10 in REF 1).
T42	19	20	-

INTERNAL ITEMS	TYPE	DEFINITION
DS_Cleared	Bool	Data Storage handling switched off, see 11.2.2.6 in REF 1.
DS_Disabled	Bool	Data Storage handling deactivated, see 11.2.2.6 in REF 1.
DS_Enabled	Bool	Data Storage handling activated, see 11.2.2.6 in REF 1.
COMLOST	Bool	Error in communication detected
W-Device_Error	Bool	Access to Index denied, AL_Read or AL_Write.cnf(-) with ErrorCode 0x80
DS_Startup	Variable	Trigger from CM state machine, see Figure 116
COMLOST	Bool	No communication
ACTIVE	Bool	communication working properly
DS_UPLOAD_REQ	Event	See Table D.2
UploadEnable	Bool	Data Storage handling configuration, see 11.2.2.6 in REF 1.
DownloadEnable	Bool	Data Storage handling configuration, see 11.2.2.6 in REF 1.
DS_Valid	Bool	Valid parameter set available within the W-Master. See state description "SM: CheckDSValidity_8"
DS_Invalid	Bool	No valid parameter set available within the W-Master. See state description "SM: CheckDSValidity_8"
Checksum_Mismatch	Bool	Acquired "Parameter Checksum" from W-Device does not match the checksum within Data Storage (binary comparison)
Checksum_Match	Bool	Acquired "Parameter Checksum" from Device matches the checksum within Data Storage (binary comparison)

5241 **11.3.4 Parameter selection for Data Storage**

5242 The W-Device designer defines the parameters that are part of the Data Storage mechanism.


5243 The IODD marks all parameters not included in Data Storage with the attribute "excludedFromDataStorage".
 5244 However, the Data Storage mechanism shall not consider the information from the IODD but rather the
 5245 Parameter List read out from the W-Device.

5246

5247 **11.4 On-request Data Exchange (ODE)**

5248 **Fehler! Verweisquelle konnte nicht gefunden werden.** shows the state machine of the W-Master's On-r
 5249 equest Data Exchange. This behavior is mandatory for a W-Master.

5250 During an active data transmission of the Data Storage mechanism, all On-request Data requests are
 5251 blocked.
 5252



On-request Data Exchange

5253 Table 130 shows the state transition table of the On-request Data Exchange state machine.
 5254

Table 130 State transition table of the ODE state machine

STATE NAME	STATE DESCRIPTION
Inactive_0	Waiting for activation
ODactive_1	On-request Data communication active using AL_Read or AL_Write
ODblocked_2	On-request Data communication blocked

TRANSITION	SOURCE STATE	TARGET STATE	ACTION /Remarks
T1	0	0	Access blocked (inactive): indicates "Service not available" to the gateway application
T2	0	1	-
T3	1	0	-
T4	1	1	AL_Read or AL_Write
T5	1	2	-
T6	2	2	Access blocked temporarily: indicates "Service not available" to the gateway application
T7	2	1	-

INTERNAL ITEMS	TYPE	DEFINITION
ODrequest	Variable	On-request Data read or write requested via AL_Read or AL_Write

5260

5261 **11.5 Diagnosis Unit (DU)**

5262 The Diagnosis Unit (DU) routes Events from the AL to the Data Storage unit or the gateway application.
5263 These Events primarily contain diagnosis information.

5264

5265 Main goal for diagnosis information is to alert an operator in an efficient manner. That means:

5266

- 5267 • no diagnosis information flooding
- 5268 • report of the root cause of an incident within a W-Device or within the W-Master and no subsequent
5269 correlated faults
- 5270 • diagnosis information shall provide information on how to maintain or repair the affected component
5271 for fast recovery of the automation system.

5272

5273 Within IO-Link Wireless, diagnosis information of Devices is conveyed to the W-Master via Events
5274 consisting of EventQualifiers and EventCodes (see clause 15. The associated human readable text is
5275 available for standardized EventCodes within this standard (see Table 180) and for vendor specific
5276 EventCodes within the associated IODD file of a W-Device. The standardized EventCodes can be mapped
5277 to semantically identical or closest fieldbus channel diagnosis definitions within the gateway application.
5278 Vendor specific IODD coding can be mapped to specific channel diagnosis definitions (individual code and
5279 associated human readable information) within the fieldbus device description file.

5280

5281 Fieldbus engineering tools and process monitoring systems (human machine interfaces) can use the
5282 fieldbus device description to decode the received fieldbus diagnosis code into human readable diagnosis
5283 text.

5284

5285 Diagnosis information flooding is avoided by flow control, which allows for only one Event per W-Device to
5286 be propagated to the W-Master/gateway application at a time.

5287

5288 The gateway application is able to start or stop the Diagnosis Unit (see Figure 116). When stopped, the DU
5289 is deferring any received AL_Event.ind call until the DU is started again.

5290

5291 The special DS_UPLOAD_REQ Event (see clause 15. and Table 181) of a W-Device shall be redirected to
5292 the common W-Master application Data Storage. Those Events are acknowledged by the DU itself and not
5293 propagated to the gateway.

5294

Figure 126 shows an example of the diagnosis information flow through a complete SDCI/fieldbus system.

NOTE The flow can end at the W-Master/PDCT or be more integrated depending on the fieldbus capabilities.




Figure 126 System overview of IO-Link diagnosis information propagation via Events

11.6 Process Data Exchange (PDE)

11.6.1 General

The Process Data Exchange provides the transmission of Process Data between the gateway application and the connected W-Device.

After an established communication and Data Storage, the W-Port is ready for any On-request Data (OD) transfers. The Process Data communication is enabled whenever the specific W-Port or all ports are switched to the OPERATE mode.

11.6.2 Process Data mapping

According to 11.2.2.5 the input and output Process Data are mapped to a specific part of the gateway Process Data stream.

5313
5314
5315

Figure 127 shows a sample mapping of the Process Data from 3 W-Master ports to the Gateway Process Data stream.




Figure 127 Process Data mapping from ports to the gateway data stream

5316
5317

11.6.3 Process Data invalid/valid qualifier status

5318
5319
5320
5321
5322

A sample transmission of an output PD qualifier status "invalid" from W-Master AL to W-Device AL is shown in the upper section of Figure 128




Figure 128 Propagation of PD qualifier status between W-Master and W-Device

5323
5324

5325

The Master informs the Device about the output Process Data qualifier status dependent on the PDOOut state.

5327

5328

PDOOUT_VALID:

5329

The Device PDOOut-handler generates the PDOOUT_VALID automatically by receiving PDOOut Process data.

5331

PDOOUT_INVALID:

5332

The Master PDOOut-handler sends the PDOOUT_INVALID via the DLink Control Octet.

5333

For input Process Data, the W-Device sends its Process Data qualifier status for PDIN_VALID / PDIN_INVALID in the same manner as the PDOOut state from W-Master.

5336

For detailed information see 12.9 and sequence chart Figure 128.

5337

11.7 Port and Device configuration tool (PDCT)

5339

11.7.1 General

5340

Figure 93 in REF 1 and Figure 106 in REF 1 demonstrate the necessity of a tool to configure ports, parameterize the W-Device, display diagnosis information, and provide identification and maintenance information. Depending on the degree of integration into a fieldbus system, the PDCT functions can be reduced, for example if the W-Port configuration can be achieved via the field device description file of the particular fieldbus.

5344

The PDCT functionality can be integrated partially (navigation, parameter transfer, etc.) or completely into the engineering tool of the particular fieldbus.

5347

5348

5349

11.7.2 Basic layout examples

5350

Figure 129 shows one example of a PDCT display layout.

5351

5352




Figure 129 Example 1 of a PDCT display layout

5353

The PDCT display should always provide a navigation window for a project or a network topology, a window for the particular view on a chosen W-Device that is defined by its IODD, and a window for the available Devices based on the installed IODD files.

5354


5355

5356

5357

5358

5359 Figure 130 shows another example of a PDCT display layout.
 5360



5361 **Figure 130 Example 2 of a PDCT display layout**

5362 NOTE Further information can be retrieved from IEC/TR 62453-61.
 5363

5364 **11.8 Gateway application**

5365 **11.8.1 General**

5366 The Gateway application depends on the individual host system (fieldbus, PLC, etc.) the W-Master
 5367 applications are embedded in. It is the responsibility of the individual system to specify the mapping of the
 5368 W-Master services and variables.

5369
5370
5371
5372
5373

However, the designers of IO-Link didn't have a chance to specify a detailed Master interface into existing fieldbuses. Therefore, the IO-Link community decided to define a Standardized Master Interface (SMI) which should be followed within the IO-Link wireless - System Extension. For detailed definition of the Standardized Master Interface see REF 12 IO-Link Community, Addendum 2017, V2.0, December 2017, Order No. 10.152




Figure 131 Generic relationship of W-Master and automation technology

5374
5375
5376

11.8.2 Changing W-Device configuration including Data Storage

5378
5379
5380
5381

After each change of W-Device configuration/parameterization (CVID and/or CDID, see 9.2.2.2 REF 1), the associated previously stored data set within the W-Master shall be cleared or marked invalid via the variable DS_Delete.

11.8.3 Parameter server and recipe control

5383
5384
5385
5386
5387
5388
5389
5390

The W-Master may combine the entire parameter sets of the connected Devices together with all other relevant data for its own operation, and make this data available for higher level applications. For example, this data may be saved within a parameter server which may be accessed by a PLC program to change recipe parameters, thus supporting flexible manufacturing. NOTE The structure of the data exchanged between the W-Master and the parameter server is outside the scope of this standard.

11.8.4 Interoperability to 5G Systems

5392
5393
5394
5395

In the requirements for 5G systems, the EAP framework for subscriber network access authentication according to RFC 5247 is proposed as primary authentication mechanism. When a vendor intends to implement a W-Master with interoperability to 5G management frameworks, it is therefore recommended by this standard to implement EAP in the IOLW-Master gateway application layer.

5396
5397
5398
5399
5400
5401
5402
5403
5404
5405
5406
5407
5408
5409

11.9 Human machine Interface (HMI)
11.9.1 Faulty device replacement

It is possible to replace a faulty W-Device without using a configuration tool (PDCT). Therefore, a minimum HMI functionality is mandatory. The W-Master displays the W-Port of a faulty W-Device. By pressing a button or a similar interface of the W-Master the pairing by button process will be started and the W-Master is waiting for a W-Device, which activates the pairing by button mode (see 4.4.2.2). Depending on the inspection level check the W-Device will be paired. After a successful pairing, the W-Master will change back in cyclic or roaming mode. In case of multiple faulty W-Devices, the replacement will be done one by one or by using an optional extended menu. The pairing button process has to be locked in case of non-device fault.




Figure 132 Faulty device replacement

5410
5411

Annex A
(normative)

12 W-Messages Codings

12.1 Overview

The Master indicates the manner the user data (see 12.8) shall be transmitted within a W-Frame.

12.2 Definition of a W-Message

Within the payload of a W-Frame, W-Messages are transmitted in DLink and ULinks (see Figure 133). W-Messages are used to serve the IO-Link Wireless mechanisms such as Process data, MasterCommand and EVENT- or ISDU-data.

A W-Message in a DLink or an ULink consists of Control Octets (CO), followed by data, or without data (e.g. MasterCommand).

See Figure 134 for definition of DLink Control Octet and Figure 136. for definition of ULink Control Octet.

For the generation of the Control Octets, see 6.5.3 Compilation of DLink W-Message and 6.5.5 Compilation of ULink W-Message.

For examples of the transmission of W-Messages see 12.6 Example for downlink data transmission and 12.7 Examples for uplink data transmissions.




Figure 133 W-Message and Control Octets

12.3 Downlink W-Messages: Control Octets

12.3.1 DLink Control Octet

The DLink Control Octet is used to send a W-Message to a dedicated W-Device within a DLink. Figure 134 shows the definition of the Control Octet (2 octet) for a DLink-W-Message




Figure 134 Definition of DLink Control Octet

12.3.1.1 Bit 0 to 4: DataLength (DLen)

These bits contain a 5 bit value from 0 to 31 to transmit the data length of the data which are following after the W-Message. If the W-Message contains no data (see Table 42), the DataLength shall be ignored. DLen is coded in the following way:

5449
5450

Table 131 Definition of DataLength (DLen)

DataLength (DLen)	
DLen	Data length in octet followed by the Control Octet
0	1
1	2
...	...
31	32

5451

5452

12.3.1.2 Bit 5 to 9: FlowControl (FC)

5453
5454
5455
5456
5457

The FlowControl is controlling the segmented data flow for Process data, Event- or ISDU data. The defined values for the FlowControl are listed in Table 75 Flow Control for segmented data. Examples for the usage of FlowControl see 12.6 Example for DLink data transmission and 12.7. Examples for ULink data transmission.

5458

12.3.1.3 ChannelCode (ChC)

5459
5460
5461
5462

These bits indicate the communication channel code for the access to the user data. The defined values for the communication channel parameter are listed in Table 132.

Table 132 Definition of ChannelCode (ChC) for DLink

ChannelCode (ChC)		
Value	Definition	Remarks
0	INVALID	W-Message is invalid and shall be ignored by W-Device
1	Process data	W-Master sends Process data out to W-Device
2	Process data INVALID	W-Master sends PDOOUT_INVALID to W-Device
3	ISDU	W-Master sends ISDU data
4	EVENT	W-Master sends event acknowledge to W-Device
5	MasterCommand	W-Master sends a MasterCommand to W-Device, see Table 165.
6	Reserved	Reserved for future
7	Reserved	Reserved for future

5463

5464

12.3.1.4 Bit 13 to 15: Slotnumber (SN)

5465
5466


These bits contain the "address" (Slotnumber 0 to 7) to which W-Device the W-Message shall be sent.

5467

12.3.2 DLink Control Octets contains MasterCommand

5468
5469

Figure 135 shows the DLink-W-Message to transmit a MasterCommand to a W-Device:



5470

5471

5472

5473

Figure 135 DLink Control Octets contains MasterCommand

If the ChC = 5, the 2nd octet (octet 1) shall be used as MasterCommand. For definition of the MasterCommand see Table 165

5474
5475
5476
5477
5478
5479
5480
5481
5482
5483
5484

5485
5486
5487
5488
5489
5490
5491
5492
5493
5494
5495
5496
5497

5498
5499
5500
5501
5502
5503
5504
5505
5506

12.3.2.1 Bit 8: Broadcast (BC)

Bit 8 marks a Broadcast message. If this bit is equal to 1 then MCcmd is for all W-Devices on Track. Broadcast supports only limited MasterCommands, see Table 165.

12.3.2.2 Bit 9: Reserved

Reserved for future use.

12.4 Uplink W-Messages

12.4.1 ULink Control Octet

The ULink Control Octet is used to send a W-Message from the W-Device to the W-Master within an ULink. Figure 136 shows the definition of the ULink Control Octet (1 octet):




Figure 136 Definition of ULink Control Octet

12.4.1.1 Bit 0 to 4: FlowControl (FC)

The FlowControl is controlling the segmented data flow for Process data, Event- or ISDU data. The defined values for the FlowControl are listed in Table 75. Flow Control definition for segmented data. Examples for the usage of FlowControl see 12.6 Example for DLink data transmission and 12.7 Examples for ULink data transmission.

12.4.1.2 ChannelCode (ChC)

These bits indicate the communication channel code for the access to the user data. The defined values for the communication channel parameter are listed in Table 133.

Table 133 Definition of ChannelCode (ChC) for ULink

ChannelCode (ChC)		
Value	Definition	Remarks
0	INVALID	W-Message is invalid and shall be ignored by W-Master
1	Process data	W-Device sends Process data in to W-Master
2	Process data INVALID	W-Device sends PDIN_INVALID to W-Master
3	ISDU	W-Device sends ISDU data to W-Master
4	EVENT	W-Device sends EVENT data to W-Master
5	Reserved	Reserved for future
6	Reserved	Reserved for future
7	Reserved	Reserved for future


12.5 Example for combination of several W-Messages within a DLink / PreDLink

The W-Master Message handler collects all data delivered via all DL-B handler for each W-Device and compiles the Control Octet for all W-Messages subsequently. Further in the Message handler place the compiled Control Octet with the delivered handler-data to the payload of a downlink in a predefined order, see Figure 60. For definition of the Control Octet see Figure 134.

The following example shows the placement of different W-Messages in a downlink:

5507 Slotnumber 3 (Device Address = 3):
 5508 8 Octet process data Out
 5509 10 Octet acyclic ISDU-write
 5510
 5511 Slotnumber 5 (Device Address = 5):
 5512 1 Octet MasterCommand in PreDownLink
 5513
 5514 Slotnumber 1 (Device Address = 1):
 5515 6 Octet process data Out
 5516 Event acknowledge

5517 The W-Master Message handler places the W-Messages in the following way into DLink payload, see Figure
 5518 137.
 5519



5522 **Figure 137 Placement of different W-Messages in a downlink**
 5523

5524 **12.6 Example for DLink data transmission within cyclic process data and segmentation**

5525 Note:

5526 Maximum downlink payload (37 octet) see Figure 35
 5527 For the definition of DLink Control Octet (2 octet) see Figure 134
 5528

5529 This example demonstrates how the W-Master sends:

- 5530 • 16 octets Process Data Out to the W-Device at Slot 2 (W-Cycle = 5 ms)
- 5531 • 8 octets Process Data Out to the W-Device at Slot 3 (W-Cycle = 10 ms)
- 5532 • 50 octets acyclic ISDU Data to the W-Device at Slot 5 (acyclic)
- 5533 • Acyclic Event acknowledge to the W-Device at Slot 3 (acyclic, see W-Sub-cycle x+8)
- 5534 • PDOUT_INVALID to the W-Device at Slot 2 (acyclic, see W-Cycle x+12)

5535
 5536 DLink for W-Cycle x:

5537 2 Octet Control Octet: SN = 2; ChC = 1; FC = EOS; DLen = 15
 5538 16 Octet Data: 16 octets Process Out data following the Control Octet
 5539 2 Octet Control Octet: SN = 3; ChC = 1; FC = EOS; DLen = 7
 5540 8 Octet Data: 8 octets Process Out data following the Control Octet
 5541 2 Octet Control Octet: SN = 5; ChC = 3; FC = START; DLen = 6
 5542 7 Octet Data: 7 octet ISDU data following the Control Octet
 5543

5544 DLink for W-Sub-cycle x+1:

5545 2 Octet Control Octet: SN = 5; ChC = 3; FC = 1; DLen = 31
 5546 32 Octet Data: 32 octet ISDU data following the Control Octet
 5547

5548 DLink for W-Sub-cycle x+2:

5549 2 Octet Control Octet: SN = 5; ChC = 3; FC = 2; DLen = 10
 5550 11 Octet Data: 11 octet ISDU data following the Control Octet

5551
5552 DLink for W-Cycle x+3:
5553 2 Octet Control Octet: SN = 2; ChC = 1; FC = EOS; DLen = 15
5554 16 Octet Data: 16 octets Process Out data following the Control Octet
5555 Control Octet: SN = 5; ChC = 3; FC = EOS; DLen = x
5556 Data: No data to transmit. Only Control Octet is transmitted to send EOS.
5557
5558 DLink for W-Sub-cycle x+4: nothing to transmit
5559
5560 DLink for W-Sub-cycle x+5: nothing to transmit
5561
5562 DLink for W-Cycle x+6:
5563 2 Octet Control Octet: SN = 2; ChC = 1; FC = EOS; DLen = 15
5564 16 Octet Data: 16 octets Process Out data following the Control Octet
5565 2 Octet Control Octet: SN = 3; ChC = 1; FC = EOS; DLen = 7
5566 8 Octet Data: 8 octets Process Out data following the Control Octet
5567
5568 DLink for W-Sub-cycle x+7: nothing to transmit
5569
5570 DLink for W-Sub-cycle x+8:
5571 Control Octet: SN = 3; ChC = 4; FC = x; DLen = x
5572 Data: No data to transmit. Only Control Octet is transmitted to Event-Ack.
5573
5574 DLink for W-Cycle x+9:
5575 2 Octet Control Octet: SN = 2; ChC = 1; FC = EOS; DLen = 15
5576 16 Octet Data: 16 octets Process Out data following the Control Octet
5577
5578 DLink for W-Sub-cycle x+10: nothing to transmit
5579
5580 DLink for W-Sub-cycle x+11: nothing to transmit
5581
5582 DLink for W-Cycle x+12:
5583 2 Octet Control Octet: SN = 2; ChC = 2; FC = x; DLen = x
5584 Data: No data to transmit. Only Control Octet is transmitted for PDOOUT_INVALID.
5585
5586 DLink for W-Sub-cycle x+...: nothing to transmit
5587

5588 12.7 Examples for uplink data transmissions

5589 Note:

5590 Maximum uplink payload of SSlot (2 octet) see Figure 37.
5591 Maximum uplink payload of DSlot (15 octet) see Figure 38.
5592 Size of ULink Control Octet (1 octet) see Figure 136.

5594 12.7.1 DSlot W-Device sends 8 octets not segmented Process Data In to W-Master

5595 W-Cycle x:

5596 Control Octet: ChC = 1; FC = 18 (data length = 8)
5597 Data: 8 octets Process In data following the Control Octet
5598

5599 12.7.2 DSlot W-Device sends 32 octets segmented Process Data In to W-Master

5600 W-Cycle x:

5601 Control Octet: ChC = 1; FC = 8 (Segment Start)
5602 Data: 14 octets Process In data (ULink payload filled completely with Control Octet and
5603 data)

5604 W-Cycle x+1:

5605 Control Octet: ChC = 1; FC = 1 (Segment Counter)
5606 Data: 14 octets Process In data (ULink payload filled completely with Control Octet and
5607 data)

5608 W-Cycle x+2:

5609 Control Octet: ChC = 1; FC = 14 (data length = 4)
 5610 Data = 4 octet Process In data. Segmented data transmission is complete.

5611 12.7.3 SSlot W-Device responds with 3 octets segmented ISDU Data to W-Master

5612 W-Cycle/ W-Sub-cycle x*:
 5613 Control Octet: ChC = 3; FC = 8 (Segment Start)
 5614 Data: 1 octet ISDU data following the Control Octet
 5615 W-Sub-cycle x+1:
 5616 Control Octet: ChC = 3; FC = 1 (Segment Counter)
 5617 Data: 1 octet ISDU data following the Control Octet
 5618 W-Sub-cycle x+2:
 5619 Control Octet: ChC = 3; FC = 2 (Segment Counter)
 5620 Data: 1 octet ISDU data following the Control Octet
 5621 W-Sub-cycle x+3:
 5622 Control Octet: ChC = 3; FC = 9 (EOS)
 5623 Data: No data to transmit, W-Message contains the separate EOS for ISDU.
 5624

5625 * W-Cycle/ W-Sub-cycle x*: A W-Device can send ISDU-data also in a W-Cycle, if no process data are
 5626 available to send.
 5627

5628 12.7.4 DSlot W-Device sends 4 octets Process Data In every 5 ms and responds with 25 octets 5629 segmented ISDU Data to W-Master

5630 W-Cycle x:
 5631 Control Octet: ChC = 1; FC = 14 (data length=4)
 5632 Data: 4 octets Process In data following the Control Octet
 5633 Control Octet: ChC = 3; FC = 8 (Segment Start)
 5634 Data: 9 (15-6) octet ISDU-data (ULink payload filled up with ISDU-data)
 5635 W-Sub-cycle x+1:
 5636 Control Octet: ChC = 3; FC = 1 (Segment Counter)
 5637 Data: 14 octet ISDU data (ULink payload filled completely with Control Octet and ISDU-
 5638 data)
 5639 W-Sub-cycle x+2:
 5640 Control Octet: ChC = 3; FC = 12 (data length = 2)
 5641 Data: 2 octet ISDU data
 5642 W-Cycle x+3:
 5643 Control Octet: ChC = 1; FC = 14 (data length=4)
 5644 Data: 4 octets Process In data following the Control Octet
 5645 Control Octet: ChC = 3; FC = 9 (EOS)
 5646 Data: No data to transmit, W-Message contains the separate EOS for ISDU.
 5647 W-Sub-cycle x+4: unused – no ULink to send
 5648 W-Sub-cycle x+5: unused – no ULink to send
 5649 W-Cycle x+6:
 5650 Control Octet: ChC = 1; FC = 14 (data length = 4)
 5651 Data: 4 octet process data following the Control Octet
 5652

5653 *If the W-Device send process data, the W-Cycle is used to transmit them. Additionally, acyclic ISDU- or
 5654 Event- data can be added to fill up the ULink payload. Further, ISDU- or Event- data are transmitted in the
 5655 following W-Sub-cycles, if they are not needed to retransmit process data.
 5656

5657 12.8 User data (PD or OD)

5658 User data is a general term for both, Process Data and On-request Data. The length of user data can vary
 5659 from 0 to 35 octets depending on the transmission direction (downlink or uplink) and the W-Device's
 5660 SlotType (DSlot or SSlot). An overview of the available data types is shown in Table 134. These data types
 5661 can be arranged as records (different types) or arrays (same types).
 5662

5663

Table 134 Data types for user data

Data type	Reference
BooleanT	See E.2 in REF 1
UIntegerT	See E.2.3 in REF 1
IntegerT	See E.2.4 in REF 1
StringT	See E.2.6 in REF 1
OctetStringT	See E.2.7 in REF 1
Float32T	See E.2.5 in REF 1
TimeT	See E.2.8 in REF 1
TimeSpanT	See E.2.9 in REF 1

5664

5665 12.9 PDVALID PDINVALID

5666

5667

5668

5669

5670

5671

5672

5673

To support low energy W-Devices the minimization of data transmission is necessary. Due to this it is possible to exchange process data only on a change of them. If process data becomes invalid it shall not be send any more. PDx_INVALID is transmitted via AL_Control / DL_Control and the ULink control octets instead.

The generation of PDVALID or PDINVALID is specified in the following way:

Table 135 PDVALID PDINVALID

PDIN_VALID:	With each reception of process input data from a W-Device, the W-Masters PDIN data handler generates PDIN_VALID automatically (see Table 65 MASTER-PDIn handler, T5).
PDIN_INVALID:	W-Device application sends PDIN_INVALID via AL/DL_Control and the ULink control octet to the W-Master.
PDOUT_VALID:	With each reception of process output data from W-Master, the devices PDIN data handler generates PDOUT_VALID automatically (see Table 66. DEVICE-PDOut handler, T5)
PDOUT_INVALID:	W-Master application sends PDOUT_INVALID via AL/DL_Control and the DLink control octet to the W-Device.

5674

5675

5676 12.10 General structure and encoding of ISDUs


5677 The encoding of ISDU data delivered by the ISDU handler shall be implemented equal to IO-Link, see 7.4.3.

5678 12.11 General structure and encoding of Events

5679 12.11.1 EventQualifier

5680 The structure of the EventQualifier is shown in Figure 138

5681



5682

Figure 138 Structure of the EventQualifier

5683 12.11.1.1 Bits 0 to 2: INSTANCE

5684 These bits indicate the particular source (instance) of an Event thus refining its evaluation on the receiver side. Permissible values for INSTANCE are listed in Table 136

5685

5686

5687

Table 136 Values of INSTANCE

Value	Definition
0	Unknown
1 to 3	Reserved
4	Application
5 to 7	Reserved

5688 **12.11.1.2 Bit 3: SOURCE**

5689 This bit indicates the source of the Event. Permissible values for SOURCE are listed in Table 137

5690
5691**Table 137 Values of SOURCE**

Value	Definition
0	W-Device (remote)
1	W-Master (local)

5692 **12.11.1.3 Bits 4 to 5: TYPE**

5693 These bits indicate the Event category. Permissible values for TYPE are listed in Table 138.

5694
5695**Table 138 Values of TYPE**

Value	Definition
0	Reserved
1	Notification
2	Warning
3	Error

5696 **12.11.1.4 Bits 6 to 7: MODE**

5697 These bits indicate the Event mode. Permissible values for MODE are listed in Table 139.

5698
5699**Table 139 Values of MODE**

Value	Definition
0	reserved
1	Event single shot
2	Event disappears
3	Event appears

5700 **12.11.2 EventCode**5701 The EventCode entry contains the identifier of an actual Event. Permissible values for EventCode are listed
5702 in clause 155703
5704

5705
5706
5707
5708
5709
5710
5711
5712
5713
5714
5715
5716
5717

Annex B
(normative)

13 W-Frame Codings, CRC calculation and errors

13.1 Description of ConnectionParameter

The ConnectionParameter in Table 140 describe a subset of parameters which are necessary for a communication in Cyclic Mode. These parameters are transmitted to the W-Device during pairing and are managed by Medium Access Layer (MAC Layer). These parameters are not accessible by application. These parameters shall be stored in non-volatile memory if the W-Device is used as Normal-Device. These parameters shall be stored in volatile memory only if the W-Device is used as Roaming-Device

The parameters are listed in Table 140.

Table 140 Description of ConnectionParameter

ConnectionParameter	TYPE
MasterID	5 Bit (1-29)
Slot_N	3 Bit (0-7)
Track_N	3 Bit (0-4)
HoppingTable	Octet String
DataSyncword	3 Octet (see Figure 31)

5718
5719
5720
5721
5722
5723
5724

13.2 W-Frame Downlink encodings for Normal Operation

The Figure 139 shows the general structure of the Downlink part of the W-Frame within a W-Sub-cycle from W-Master to W-Device. The Downlink includes the Pre-Downlink part ending with the CRC16. The remaining octets to the CRC32 reflects the payload space, which carry cyclic and acyclic data in Cyclic Mode. Unused fields must be filled with zeros.




Figure 139 W-Frame encodings

5725
5726
5727
5728

Table 141 MasterID

Value	Meaning
0	invalid
1..29	Valid MasterID

5729

Table 142 Track_N

Value	Meaning
0..4	Valid Track_N

5730
5731

Table 143 Normal Downlink ACK

Value	Meaning
0..7	Valid ACK for devices 0...7 as bit-fields

5732

5733

13.3 W-Frame Downlink encodings for Configuration Operation

5734
5735
5736
5737
5738

In ServiceMode, the configuration channels are utilized to transmit configuration requests in downlink direction towards the W-Device. The ServiceMode covers Scan, Pairing and Negotiation procedures. The downlink message types listed in Table 144 shall be implemented and used during configuration.

Table 144 Downlink-MSG-Type content (Config Mode only)

Value	Meaning	Payload Content
0x80	MSG_DLink_Pair_Button	MasterID + ULink type + ACK + Device_N + IMATime + Retry Count
0x90	MSG_DLink_Pair_Unique	MasterID + ULink type + ACK + Device_N + IMATime + Retry Count+ UniqueID
0x40	MSG_DLink_Scan_Req	MasterID + ACK + RequestN
0xA0	MSG_DLink_Pair Neg 1	MasterID + ACK + Device_N + Hopping Table (Part 1)
0xB0	MSG_DLink_Pair Neg 2	MasterID + ACK + Device_N + Hopping Table (Part 2) + Col-N

5739
5740

Table 145 Uplink Type

Value	Meaning
00	Single Slot Uplink
01	Double Slot Uplink

5741
5742

Table 146 Config Downlink ACK

Value	Meaning
0	no packet received
1	last packet received

5743
5744

Table 147 Downlink-MSG-Type coding

Types	Hex Code	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
MSG_DLink_Pair_Button	0x80	1	0	0	0	X	X	X	X
MSG_DLink_Pair_Unique	0x90	1	0	0	1	X	X	X	X
MSG_DLink_Scan_Req	0x40	0	1	0	0	X	X	X	X
MSG_DLink_Pair Neg 1	0xA0	1	0	1	0	X	X	X	X
MSG_DLink_Pair Neg 2	0xB0	1	0	1	1	X	X	X	X

5745
5746

Table 148 Device_N

Bit	5	4	3	2	1	0
Meaning	Track_N (2)	Track_N (1)	Track_N (0)	Slot_N (2)	Slot_N (1)	Slot_N (0)

5747
5748
5749
5750
5751
5752

Table 149 Roaming Flag

Value	Meaning
00	Roaming not requested
01	Roaming requested

5753

5754

Table 150 Track_N

Value	Meaning
0-4	Valid
5-7	Invalid

5755
5756

Table 151 Slot_N

Value	Meaning
0-7	Valid


5757

5758 13.3.1 Scan Request Downlink

5759 In Scan Mode and Roaming Mode, the W-Master is able to discover unpaired W-Devices. This is achieved
5760 by transmitting Scan Request messages shown in Figure 140 in configuration downlinks.

5761
5762 After receiving a Scan Request, W-Devices shall respond with the Scan Response Uplink after a random
5763 number of W-Sub-cycles, as described in clause 12.6.1.

5764
5765 The W-Master should transmit its MasterID, an Acknowledge for last received Uplinks, the Scan Request
5766 identifier and the consecutive number of Scan Request as Request_N in each configuration Downlink during
5767 ServiceMode.
5768



5769

Figure 140 Scan Request

5770

5771 13.3.2 Pairing Request Downlink

5772

5773 In ServiceMode (Pairing State), the W-Master has to address a specific unpaired W-Device. Therefore, the
5774 W-Master starts the configuration process with sending Pairing Requests shown in Figure 141 in
5775 configuration Downlinks. The addressed W-Device shall answer with a Pairing Response Uplink within the
5776 same W-Sub-cycle.
5777

5778 Each Pairing Request shall contain the ID of the W-Master, requested Uplink type (SSlot Uplink or DSlot
5779 Uplink), the Acknowledge for the last received Uplink, the Pairing Request command, the roaming flag, the
5780 W-Device number, UniqueID, and DataSyncword.

5781
5782 If a W-Device receives an active Roaming Flag in a Pairing Request, it changes its mode to Roaming mode.
5783 In this mode, the Pairing by Button and Re-pairing features are deactivated on the W-Device
5784


5785 ServiceMode supports two pairing mechanisms:

- 5786 • Pairing Request by Button.
- 5787 • Pairing Request by UniqueID

5788

5789 During Paring Request by Button, the UniqueID shall be set to zero. In this case, the W-Master does not
5790 address the W-Device. Only the W-Device which was already set into the Pairing by Button mode shall
5791 respond on the W-Master request.
5792

5793 Pairing Request by UniqueID transfers the UniqueID of the W-Device the W-Master tries to pair. Pairing by
 5794 UniqueID is used for two cases: pairing of the W-Device during system configuration or temporarily pairing
 5795 of W-Device in Roaming mode.
 5796



5797 **Figure 141 Pairing Request**

5798 **Table 152 Pairing Request: Unique ID**

Value	UniqueID
0x0000000000000000	Pair by Button
0x0000000000000001- 0xFFFFFFFFFFFF	Pair by Unique ID

5800

13.3.3 Pairing Negotiation Downlink

In ServiceMode within the Paring Procedure, the Negotiation Downlinks are used by W-Master for configuration of the W-Device. There are two mandatory consecutive Negotiation Downlinks necessary to be able to transmit frequency tables. The unused fields at the end are filled with zero. The hopping sequence itself is encoded in the given sequence of the channels, each octet reflecting a 1 MHz channel in the 2.4 GHz-ISM-Band.

Negotiation Downlinks are containing the MasterID, Uplink Slot Type of the W-Device being configured, the Acknowledge of the last received Uplink, Downlink-MSG-type (MSG_DLink_Pair Neg 1 or MSG_DLink_Pair Neg 2), the Device_N (combination of Slot_N, Track_N), the actual frequency hopping table length, current Col_N of Cyclic Mode and the frequency hopping table of Cyclic Mode.

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														ConfigSyncword																	
4	ConfigSyncword							MasterID			UL type	ACK		MSG_DLink_type							Reserved		Device_N									
8	Table length							HOP-1							HOP-2							HOP-3										
12	HOP-4							HOP-5							HOP-6							HOP-7										
16	HOP-8							HOP-9							HOP-10							HOP-11										
20	HOP-12							HOP-13							HOP-14							HOP-15										
24	HOP-16							HOP-17							HOP-18							HOP-19										
28	HOP-20							HOP-21							HOP-22							HOP-23										
32	HOP-24							HOP-25							HOP-26							HOP-27										
36	HOP-28							HOP-29							HOP-30							HOP-31										
40	HOP-32							HOP-33							HOP-34							HOP-35										
44	HOP-36							HOP-37							HOP-38							HOP-39										
48	CRC 32																															

Figure 142 Pairing Negotiation type 1 => DLink-Message-Type = MSG_DLink_Pair_Neg_1

Table 153 Values for Frequency Table length

Value	Meaning
0-14, 79-255	invalid
15-78	Valid table length

Table 154 Permitted Values for HOP_N

Value	Meaning
0,2,3-79,81-83	Valid frequency for cyclic data channel
0	End of Frequency Table Delimiter

Table 155 HOP_N Bit coding

Bit	7	6	5	4	3	2	1	0
Meaning	0	HOP_N (6)	HOP_N (5)	HOP_N (4)	HOP_N (3)	HOP_N (2)	HOP_N (1)	HOP_N (0)

5820

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														ConfigSyncword																	
4	ConfigSyncword							MasterID			UL type	ACK	MSG_DLink_type							Reserved			Device_N									
8	Col_N							HOP-40							HOP-41							HOP-42										
12	HOP-43							HOP-44							HOP-45							HOP-46										
16	HOP-47							HOP-48							HOP-49							HOP-50										
20	HOP-51							HOP-52							HOP-53							HOP-54										
24	HOP-55							HOP-56							HOP-57							HOP-58										
28	HOP-59							HOP-60							HOP-61							HOP-62										
32	HOP-63							HOP-64							HOP-65							HOP-66										
36	HOP-67							HOP-68							HOP-69							HOP-70										
40	HOP-71							HOP-72							HOP-73							HOP-74										
44	HOP-75							HOP-76							HOP-77							HOP-78										
48	CRC 32																															

Figure 143 Pairing Negotiation type 2 => DLink-Message-Type = MSG_DLink_Pair_Neg_2

5821

5822

5823

13.4 Uplink encodings for Normal Operations

5824

5825

13.4.1 Regular Single Slot Uplink (SSlot)

5826

In Cyclic Mode, the Regular Uplink packet shown in Figure 144 is used to transmit process and event data from W-Device to the W-Master. A message in SSlot Uplink telegram can handle 16 bit data payload, which can contain cyclic process data, diagnosis data or event notifications.

5827

5828

5829

5830

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														DataSyncword																	
4	DataSyncword							MasterID			IMA=0				ACK	Payload																
8	CRC 32																															


Figure 144 Regular SSlot Uplink Packet

5831

5832

5833 **13.4.2 Regular Double Slot Uplink (DSlot)**

5834 In Cyclic Mode, the Regular DSlot Uplink packet is used to transmit process and event data from W-Device
 5835 to W-Master.
 5836



5837 **Figure 145 Regular DSlot Uplink Packet**

5838 **Table 156 Uplink IMA**

Value	Meaning
0	Normal Uplink
1	IMA Uplink


5842 **Table 157 Uplink ACK**

Value	Meaning
0	no packet received
1	last packet received

5846 **13.4.3 IMA Uplink**

5847 W-Master as well as W-Device controls the time between two successive Uplink packets. If this time in W-
 5848 Master is greater than the defined IMA time, an Event should be initiated by the W-Master application. If
 5849 this time in W-Device is greater than defined IMA time the W-Device Message handler causes an IMA
 5850 packet with diagnosis data to avoid an IMA alert at the W-Master.

5851 Depending on Uplink Type, the W-Device uses an IMA D-Slot Uplink see Figure 146 or an IMA Slot Uplink
 5852 see Figure 147. IMA Uplinks should send an IMA=1 Flag, the Acknowledge for Previously received packet
 5853 and diagnosis data.
 5854



5855 **Figure 146 DSlot IMA-Uplink Packet**

5856

5857




Figure 147 SSlot IMA-Uplink-Packet

5858
5859
5860
5861

Table 158 Diagnosis encoding octet 3 (RSSI)

Bit	7	6	5	4	3	2	1	0
Meaning	RSSI No 7	RSSI No 6	RSSI No 5	RSSI No 4	RSSI No 3	RSSI No 2	RSSI No 1	RSSI No 0

5862
5863
5864
5865
5866
5867
5868
5869

Table 159 Diagnosis encoding octet 4 (Link Quality)

Bit	7	6	5	4	3	2	1	0
Meaning	Link Quality No 7	Link Quality No 6	Link Quality No 5	Link Quality No 4	Link Quality No 3	Link Quality No 2	Link Quality No 1	Link Quality No 0

5870

13.5 Uplink encodings for Configuration Operations

5871
5872
5873

In the ServiceMode the System Management, DL-A/B Message handlers are not involved in the Uplink assembly, therefore the data flow control shall be implemented in the MAC layers of the IO-Link wireless stack.

5874
5875

The ServiceMode itself covers Scan, Pairing and Negotiation procedures. Therefore, five message types, presented in the Uplink-MSG-Type tables, shall be implemented und used during configuration.

5876

13.5.1 Definition of Uplink encodings

5877
5878

Table 160 Uplink-MSG-Type (Config Mode only)

Value	Meaning	Payload Content
0x40	MSG_UPLINK_Scan_Resp	RevisionID + IMATime + UniqueID
0x80/0x90	MSG_UPLINK_Pair_Resp	RevisionID + IMATime + UniqueID
0xA0	MSG_UPLINK_Pair_Neg_1_Resp	Response Only, (no data transfer)
0xB0	MSG_UPLINK_Pair_Neg_2_Resp	Response Only, (no data transfer)
0xF0	MSG_UPLINK_Pair_Failed	Response Only, (no data transfer)

5879
5880

Table 161 Slot-Type in config Uplink

Value	SlotType
00	Single Slot
01	Double Slot

5881
5882

Table 162 Uplink-MSG-Type Coding

Header Type	Hex Code	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
MSG_UPLINK_Scan_Resp	0x40	0	1	0	0	X	X	X	X
MSG_UPLINK_Pair_Button_Resp	0x80	1	0	0	0	X	X	X	X
MSG_UPLINK_Pair_Unique_Resp	0x90	1	0	0	1	X	X	X	X
MSG_UPLINK_Pair_Neg_1_Resp	0xA0	1	0	1	0	X	X	X	X
MSG_UPLINK_Pair_Neg_2_Resp	0xB0	1	0	1	1	X	X	X	X
MSG_UPLINK_Pair_Failed	0xF0	1	1	1	1	X	X	X	X

5883
5884
5885

Table 163 RevisionID

Bits	Value	Meaning
0 to 3	0x0...0xF	MinorRev part of the protocol revision (see page 217 in REF 1)
4 to 7	0x0...0xF	MajorRev part of the protocol revision (see page 217 in REF 1)

5886

13.5.2 Scan Response Uplink

5888 In ServiceMode the W-Device answers to a received Scan Request with a Scan Response. A Scan
5889 Response shown in Figure 148 must contain the MasterID received in the Scan Request, the Uplink type,
5890 an Uplink Message type, the RevisionID, and its UniqueID.
5891

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														ConfigSyncword																	
4	ConfigSyncword							MasterID							UL type	ACK	MSG_UPLINK_type							RevisionID								
8	UniqueID																															
12	UniqueID																															
16	UniqueID							unused																								
20	unused							CRC 32																								
24	CRC 32																															

5892

Figure 148 Scan Response Packet

5893

13.5.3 Pairing Response Uplink

5895 In ServiceMode, the W-Device shall answer to a Pairing Request Downlink with a Pairing Response
5896 Uplink within the same W-Sub-cycle. The W-Device shall submit the received MasterID, the Uplink Type
5897 of the W-Device, the acknowledge for the last received Downlink, the RevisionID and the UniqueID of the
5898 W-Device as shown in Figure 149.
5899

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														ConfigSyncword																	
4	ConfigSyncword							MasterID							UL type	ACK	MSG_UPLINK_type							RevisionID								
8	UniqueID																															
12	UniqueID																															
16	UniqueID							unused																								
20	unused							CRC 32																								
24	CRC 32																															

5900

Figure 149 Pairing Response Packet

5901

13.5.4 Negotiation Response Uplink

In ServiceMode, the W-Device shall respond on each Negotiation Downlink it receives. W-Device shall submit the Uplink Type of the W-Device, the acknowledge for the last received Downlink, MSG_UPLINK and the W-Device RevisionID as shown in Figure 150.

Octet	1							2							3							4										
Bit	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
0	Preamble														ConfigSyncword																	
4	ConfigSyncword							MasterID							UL type	ACK	MSG_UPLINK_type							RevisionID								
8	UniqueID																															
12	UniqueID																															
16	UniqueID							unused																								
20	unused							CRC 32																								
24	CRC 32																															

Figure 150 Pairing Negotiation Uplink Packet

13.6 Acknowledge Generation

The PL in W-Master shall generate an ACK-Bit (see Figure 139) for each W-Device, if the W-Master received a valid Uplink.

The PL in W-Device shall generate an ACK-Bit (see Figure 144 and Figure 145) if the W-Device received a valid Downlink with data for this specific W-Device from W-Master.

In both cases: If no acknowledge within an Uplink is received or the Uplink is lost or invalid (e.g. wrong CRC) a NACK (ACK-Bit = 0) is generated.

13.7 CRC16 and CRC32 calculation

The integrity of Uplink and Downlink transmissions is protected through 32 bit CRC defined in IEEE 802.3 (CRC32).

The integrity of Pre-Downlink shall be protected through CRC16-CCITT (CRC16).

The CRC algorithms are defined as follows:

The CRC32 Generator polynomial is $x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$

Initial Value (Pre-set) 0xFFFFFFFF.

The final xor (residue) during transmission: 0xFFFFFFFF

The final xor (residue) during reception: 0xC704DD7B

Note: In Cyclic Mode, the final XOR value shall be updated during the Uplink exchange by W-Master and W-Device with the "W-Device distinguishing identifier" as following:

The final xor during reception shall be set to [0xC704DD7B xor W-Device distinguish identifier]

CRC16:

generator polynomial is $x^{16} + x^{12} + x^5 + 1$

Initial Value (Pre-set) 0xFFFF.

The final xor during transmission and reception 0x0000

The CRC16 calculated over Pre-Downlink only and placed at its end.

13.8 Errors

The Acknowledgement bit/bits and the checksum are two independent mechanisms to secure the data transfer.

Remedy: The W-Master or W-Device can repeat the packet for maximum 2 times (see clause 4). DL-A/DL-B handler in W-Master or W-Devices assumes content of the payload within the next W-Sub-cycle.

5946

13.8.1 Checksum errors

5947

Any checksum error in a receiver suppress it's acknowledge to the transmitter.

5948

5949

13.8.2 Latency errors

5950

The latency error occurs if an expected cyclic message is not received within the W-Cycle.

5951

5952

13.8.3 IMA Timeout errors

5953

IMA Timeout errors occurs if the configured IMA time at the W-Master is exceeds.

5954

13.8.4 False positive Error

5955

False Positive errors occurs when interference falsifies a transmitted packet in a way the CRC and other integrity checks at the receiver cannot detect.

5956

5957

5958
5959
5960


Annex C
(normative)

5961 **14 W-Device Parameter and commands**

5962 This section describes and defines the parameters and commands within a W-Device. Compared to the IO-
5963 Link Interface and System Specification, the page communication channel is not implemented in wireless
5964 IO-Link. Thus index 0 and 1 remain solely accessible using the ISDU channel. For compatibility reasons
5965 towards IO-Link Interface and System Specification, the memory structure of page 1 and 2 is kept. A
5966 detailed memory mapping for W-Devices can be found in Figure 151 and for W-Bridges in Figure 152.

5967
5968 The wireless parameters are addressed via index 0x5000 to 0x50FF.


5969
5970 All other mechanisms described in the IO-Link Interface and System Specification are fully supported, for
5971 a more complete description please refer to the IO-Link Interface and System Specification REF 1. For W-
5972 Devices, the use of profile(s) is recommended e.g. smart sensor profile and common profile, see REF 4.
5973



5974
5975

Figure 151 Memory mapping of the direct parameter page 1 of a W-Master with a W-Device.

5976



5977
5978
5979

Figure 152 Memory mapping of the direct parameter page 1 of a W-Master with a W-Bridge connected to an IO-Link device.

5980

14.1 Direct Parameter Page 1

5981

For compatibility reasons towards IO-Link Interface and System Specification, the direct parameter page 1 is kept identical in its structure. This allows in the case of a W-Bridge application with a wired IO-Link Device in most cases a straight forward mapping of the parameters, see Figure 152.

5982

Despite having the same direct parameter structure, wired and wireless devices differ in the following way:

5983

- A read request on idx 0 sub-idx 0 returns the whole page 1
- A read request on idx 0 sub-idx 4 (i.e. M-SequenceCapability) returns 0xFF.
- A write request on idx 0 sub-idx 0 is ignored by the subindices which are “read-only”
- A write request on idx 0 sub-idx 10 is redirected within the device towards idx 2.

5984

5985

5986

5987

5988

5989

5990

5991

5992

5993

Table 164 Direct Parameter Page 1

Index	Subindex	Access	Parameter name	Description	Implementation / reference
	0x00		To read the whole Direct Parameter Page 1 in one go		
0x0000	0x01	W	MasterCommand	Master command to switch to operating states (see Note 2)	Mandatory/ see 14.1.1
	0x02	R/W	MasterCycleTime	Identical to IO-Link Interface and System Specification	Mandatory/ see 14.1.2
	0x03	R	MinCycleTime	Identical to IO-Link Interface and System Specification	Mandatory/ see 14.1.2
	0x04	R	M-Sequence Capability	Not used: the byte is set to 0xFF	-
	0x05	R/W	Revision ID	ID of the used RevisionID for implementation (shall be set to 0x11)	Mandatory/ see 14.1.3
	0x06	R	ProcessDataIn	Number and structure of input data (Process Data from Device to W-Master)	Mandatory/ see 14.1.4
	0x07	R	ProcessDataOut	Number and structure of output data (Process Data from W-Master to W-Device)	Mandatory/ see 14.1.5
	0x08	R	VendorID (MSB)	Unique vendor identification	Mandatory/ see 14.1.6
	0x09	R	VendorID (LSB)		
	0x0A	R/W	DeviceID 1 (Octet 2, MSB)	Unique Device identification allocated by a vendor	Mandatory/ see 14.1.7
	0x0B	R/W	DeviceID 2 (Octet 1)		
	0x0C	R/W	DeviceID 3 (Octet 0, LSB)		
	0x0D	R	FunctionID 1 (MSB)	Reserved (Engineering shall set both octets to "0x00")	see 14.1.8
	0x0E	R	FunctionID 2 (LSB)		
0x0F	-	-	-	-	
0x10	-	-	System-Command	Not used (see Note 1)	-
NOTE 1 For all IO-link wireless device SystemCommand on page 1 shall not be used, but index 2 instead.					
NOTE 2 A Read operation returns unspecified values					

5994

5995

14.1.1 MasterCommand

5996

The W-Master application is able to check the status of a W-Device or to control its behavior with the help of MasterCommands. The permissible value definitions for these parameters are specified in Table 165.

5997

5998

5999

Table 165 Types of MasterCommands.

MasterCommand		
Value	MasterCommand	Description
0x00 to 0x5B	Reserved	
0x5C	Inactive	Switches the W-Device state machines to inactive
0x5D	PreDLink	Switches the W-Device radio to receive Pre-Downlink W-frames
0x5E	FullDLink	Switches the W-Device radio to receive full Downlink W-frames
0x5F	UnPairing	Unpairs the W-Device. The W-Device deletes all its wireless communication parameters. Invoke PL_Pairing(UNPAIRING) on W-Device
0x60 to 0x95	Reserved	
0x96	DevicelIdent	Start check of Direct Parameter page for changed entries
0x97	DeviceStartup	Switches the Device from OPERATE or PREOPERATE to STARTUP
0x98	Reserved	
0x99	DeviceOperate	Process output data invalid or not available. Switches the Device from STARTUP or PREOPERATE to OPERATE
0x9A	DevicePreoperate	Switches the Device from STARTUP to state PREOPERATE
0x9B to 0xEF	Reserved	
0xF0 to 0xFE	Jump (Broadcast)	Triggers a countdown starting with the value of last 4 bits (14 to 0) for updating the hopping table to new values. MCmd is sent (decrease 1 each sub cycle) until all W-Devices have acknowledged. When counter reaches 0 then W-Master and W-Device shall use the new hopping table immediately, starting with the first frequency (HOP-1, see Figure 142)
0xFF	WakeUp	Set low energy W-Device WakeUpTimer to 0 which increases every sub cycle. W-Device wakes up when WakeUpTimer reaches WakeUpTime
<p>NOTE For low energy W-Devices, the Pre-Downlink is used to minimize the radio-on time to save power. A switch to full Downlink may be necessary on low energy W-Device s for a higher amount of data e.g. a parameter write.</p>		

6000

14.1.2 MasterCycleTime and MinCycleTime

6001

The MasterCycleTime is a Master parameter and sets up the actual cycle time of a particular W -Port.

6002

6003

The MinCycleTime is a W-Device parameter to inform the W-Master about the shortest cycle time supported by this W-Device.

6004

6005

6006

The structure of these two parameters is shown in Figure 153.

6007

6008




Figure 153 MasterCycleTime and MinCycleTime

6009

6010

6011 **Bits 0 to 5: Multiplier**
 6012 These bits contain a 6-bit multiplier for the calculation of MasterCycleTime or MinCycleTime. Permissible
 6013 values for the multiplier are 0 to 63.
 6014

6015 **Bits 6 to 7: Time Base**
 6016 These bits specify the time base for the calculation of MasterCycleTime or MinCycleTime.
 6017 The permissible combinations for time base and multiplier are listed in Figure 154 along with the resulting
 6018 values for MasterCycleTime or MinCycleTime.
 6019

Time base encoding	Time Base value	Calculation	Cycle Time	6020
00	-	-	FreeRunning	
01	5 ms	Multiplier × Time Base	5 ms to 315 ms	
10 to 11	Reserved	Reserved	Reserved	
NOTE For W-Devices and W-Bridges the minimum possible transmission time is 5 ms.				

6021 **Figure 154 Possible values of MasterCycleTime and MinCycleTime**

6022 14.1.3 Revision ID

6023 Identical to IO-Link Interface and System Specification: Section B.1.5 in REF 1
 6024

6025 The RevisionID numbers of the wired and wireless are independent. This revision of the standard specifies
 6026 RevisionID 1.1 (i.e. RevisionID=0x11).

6027 14.1.4 ProcessDataIn

6028 Identical to IO-Link Interface and System Specification: Section B.1.6 in REF 1
 6029

6030 The exact size and content of the PD is described by the profile, e.g. smart profile for sensors. Due to the
 6031 nature of the wireless protocol the slot sizes stay unchanged in any case.
 6032

6033 14.1.5 ProcessDataOut

6034 Identical to IO-Link Interface and System Specification: Section B.1.7 in REF 1
 6035

6036 The exact size and content of the PD is described by the profile, e.g. smart profile for sensors. Due to the
 6037 nature of the wireless protocol the slot sizes stay unchanged in any case
 6038

6039 14.1.6 VendorID

6040 Identical to IO-Link Interface and System Specification: Section B.1.8 in REF 1
 6041

6042 14.1.7 DeviceID

6043 Identical to IO-Link Interface and System Specification : Section B.1.9 in REF 1
 6044

6045 14.1.8 FunctionID

6046 Identical to IO-Link Interface and System Specification: Section B.1.10 in REF 1
 6047

6048 14.1.9 SystemCommand

6049 Devices with ISDU support shall use the ISDU Index 0x0002 to receive the SystemCommand. The
 6050 commands shall be acknowledged. A positive acknowledge indicates the complete and correct finalization
 6051 of the requested command. A negative acknowledge indicates the command cannot be realized or ended
 6052 up with an error. A SystemCommand shall be executed within less than 5 s to fulfill the ISDU timing
 6053 requirements (see Table 97 in REF 1). Implementation of the SystemCommand feature is mandatory for W-
 6054 Masters and optional for Devices. The coding of SystemCommand is specified in Table 166. For wireless
 6055 specific commands, the system command's range from 0x30 to 0x3F is reserved and used.

6056
6057

Table 166 Coding of SystemCommand (ISDU)

Command (hex)	Command (dec)	Command name	M/O	Definition
0x00	0	Reserved	-	-
0x01	1	ParamUploadStart	O	Start parameter upload
0x02	2	ParamUploadEnd	O	Stop parameter upload
0x03	3	ParamDownloadStart	O	Start parameter download
0x04	4	ParamDownloadEnd	O	Stop parameter download
0x05	5	ParamDownloadStore	O	Finalize parameterization and start Data Storage
0x06	6	ParamBreak	O	Cancel all Param commands
0x07 to 0x3F	7 to 63	Reserved	-	-
0x40 to 0x7F	64 to 127	Reserved for profiles	-	-
0x80	128	Device reset	O	-
0x81	129	Application reset	O	-
0x82	130	Restore factory settings	O	-
0x83 to 0x9F	131 to 159	Reserved	-	-
0xA0 to 0xFF	160 to 255	Vendor specific	-	-
NOTE See 10.3				
Key M = mandatory; O = optional				

6058
6059

14.2 Direct Parameter Page 2

The direct parameter page 2 shall not be used by W-Devices. Nevertheless, page 2 is kept to ensure backward compatibility in the case of a W-Bridge usage with IO-Link device, which are not ISDU compatible. For a pure W-Device a reading attempt on index 1 shall return a "Index not available" error message (error code: 0x80, Additional code: 0x11).

6063
6064
6065
6066
6067

Table 167 Direct parameter Page 2

Index	Subindex	Access	Parameter name	Coding / description	Data type
0x0001	0x01... 0x10	Optional	Vendor Specific	Device Specific Parameters	-

6068

14.3 Wireless Parameter (W-Parameter)

14.3.1 Overview

IO-Link wireless makes use of the same predefined device parameter as standard IO-Link devices. Nevertheless, in order to store the wireless specific parameters new indices have been predefined.

6071
6072

6073




Figure 155 Index space for ISDU data objects

6074
6075

6076

Table 168 Index assignment of data objects (W-Device parameter)

Index (dec)	Object name	Access	Length	Data type	M/O/C	Remark
0x0000 (0)	Page 1	R/W		RecordT	M	See Table 164
0x0001 (1)	Page 2	R/W		RecordT	O	Pure IO-Link wireless device shall not use this index. In the case of a W-Bridge it shall be implemented to ensure backward compatibility with IO-Link device.
0x0002 (2)	SystemCommand	W	1 octet	UIntegerT	M	See REF 1
0x0003... 0x0014 (3 to 20)	Similar to IOL.	-	-	-	-	See REF 1
0x0015 (21)	SerialNumber	R	Max. 16 octets	StringT	M	Vendor specific serial number (similar to IOL)
0x0016... 0x4FFF (22 to 20479)	Similar to IOL					See REF 1
0x5000 (20480)	Reserved	-	-	-	-	-
0x5001 (20481)	WirelessSystemMgmt	R	9 octets	RecordT	M	See Section: 14.3.3
0x5002 (20482)	WirelessSystemCfg	R/W	4 octets	RecordT	M	See Section: 14.3.3
0x5003 (20483)	LinkQuality	R	1 octet	UIntegerT	M	See Section: 14.3.10
0x5004 (20484)	WBridgelInfo	R	12 octets	RecordT	O	See Section: 14.3.11
0x5005 (20485)	WRadioInfo	R	12 octets	RecordT	M	See Section: 14.3.11
0x5006 (20486)	AdaptiveHopTable	W	82 octets	RecordT	M	See Section: 14.3.12
0x5007- 0x50FF (20487 to 20735)	Reserved					
0x5100... 0xFFFF (20736 to 65535)	Similar to IO-Link Interface and System Specification	-	-	-	-	See REF 1

Key M=Mandatory; O=optional; C=conditional

6077

6078

14.3.2 SystemCommand

6079
6080
6081
6082
6083
6084
6085

The ISDU Index 0x0002 shall be used to receive SystemCommands. Any received commands shall be acknowledged. A positive acknowledge indicates the complete and correct finalization of the requested command. A negative acknowledge indicates the command cannot be executed or terminated with an error. Any SystemCommand shall be executed within less than 5 s to fulfill the ISDU timing requirements. The W-Master may act as a proxy for a temporarily unreachable W-Device. Implementation of the SystemCommand feature is mandatory for W-Masters and optional for Devices. The coding of SystemCommand is specified in Table 166.

6086

6087 **14.3.3 Wireless System**

6088 This index range stores all the WirelessSystemMgmt and WirelessSystemCfg parameters of a W-Device.

6089

6090

Table 169 Wireless system index assignments

Index	Subindex	Access	Parameter name	Coding	Data type
0x5001	0x00	Gives access to the whole index			
	0x01	R	UniqueID	See Section: 14.3.9	OctetStringT9
0x5002	0x00	Gives access to the whole index			
	0x01	R/W	IMATime	See Section: 14.3.5	OctetStringT2
	0x02	R/W	MaxRetry	See Section: 14.3.6	UIntegerT8
	0x03	R/W	TxPower	See Section: 14.3.7	UIntegerT8

6091

6092 **14.3.3.1 WRadioInfo**

6093 This index range stores all the information related to the radio hardware and software installed on the device.

6094

6095

6096

Table 170 Radio manufacturer identification information

Index	Subindex	Access	Parameter name	Coding	Data type
0x5005	0x00	Gives access to the whole index			
	0x01	R	RadioVendorID	similar to VendorID	OctetStringT2
	0x02	R	RadioModuleID	vendor specific similar to DeviceID	OctetStringT2
	0x03	R	RadioHWRevision	vendor specific	OctetStringT4
	0x04	R	RadioSWRevision	vendor specific	OctetStringT4

6097

6098 NOTE RadioVendorIDs are assigned by IO-Link community.

6099

6100 **14.3.4 ISDU Mapping for system management**

6101 The Table 171 shows which ISDU indexes shall be forwarded to the system management.

6102

6103

Table 171 ISDU indexes for system management

Index	Object name
0x0000	Page 1
0x5001	WirelessSystemMgmt
0x5002	WirelessSystemCfg
0x5006	AdaptiveHopTable

6104

6105 **14.3.5 IMATime**

6106 The IMA ("I am alive") time is a mandatory W-Parameter. IMATime is system and W-Device specific. Device manufacturer shall submit the maximal and minimal IMA times for each W-Device. (i.e. as mapped parameter in the W-Device itself). This information can be used by W-Master during configuring of the W-Device for performance optimization.

6107 In Normal mode, W-Master and W-Device control the time between two successive uplink messages of each W-Device. If there are no other messages to transmit, the W-Device shall send an IMA message before IMA time will be reached. If IMA time is exceeded on W-Master, a communication error must be reported via system management and a failsafe may be performed by the application.

6111

6112

6113

6114

6115 The minimum IMA time is dependent of the number of MaxRetry. Therefore the minimum IMA time shall be
6116 calculated shown in Table 172:

6117
6118

Table 172 Minimum and maximum IMA time

Minimum IMA time	W-Sub-cycle duration [ms] * (MaxRetry + 1)
Maximum IMA time	Limited to 10 minutes

6119
6120
6121
6122

The IMA time encoding is shown in Table 173:

Table 173 IMA time encoding

Octet 0	Octet 1
Time Base encoding see Table 174	Multiplier Permitted values: 1 to 255

6123
6124
6125
6126
6127

A value of 0x01 means that the device stays always on.

Table 174 Time value encoding table for the IMATime

Time base encoding	Time Base Value	Conversion to W-Sub-cycles	Remark
0x00	-	-	Reserved
0x01	1.664 ms	1	Limits see Table 172
0x02	5 ms	3	
0x03	1 s	600	
0x04	1 minute	36,000	
0x05 ...0xFF	-	-	Reserved

6128
6129
6130

The IMATime value is calculated by multiplying the “time base” with the “multiplier”.

6131

14.3.6 MaxRetry

6132 This index stores the maximal number of retries. The minimum and default value is 0x02, thus one primary
6133 transmission and 2 retries.

6134
6135

Table 175 Value for the maximal number of retries

Value	Remark
0x00, 0x01	Reserved
0x02	2 retry
0x03	3 retry
0x04	4 retry
...	...
0x1F	31 retry
0x20 ...0xFF	Reserved

6136
6137

14.3.7 TxPower

6138 This parameter stores the currently used transmission power. The transmission power is encoded in
6139 predefined power levels which values shall be defined in the vendor’s documentation. If those values are
6140 not otherwise specified the values in Table 12 are valid. If the requested power value is not support by the
6141 radio, the later shall round the Tx Power value to the closest matching one and correct the stored value
6142 accordingly. The corrected value replaces then the original value.

6143
6144

Table 176 TxPower parameter

TxPower	Predefined Level	Power	Values [dBm]
0x00	-		Reserved
0x01	Level 1		-20
0x02	Level 2		-19
...
0x14	Level 20		0
...
0x0F	Level 30		9
0x1F	Level 31		10
0x20 – 0xFF	-		Reserved

6145

6146 **14.3.8 SerialNumber**

6147 This mandatory parameter shall contain a unique vendor specific code for each individual W-Device. It is a
6148 read-only object of data type StringT with a maximum fixedLength of 16. This real SerialNumber (RSN) can
6149 be used by the Application for compatibility checks against a configured SerialNumber (CSN) provided by
6150 the application, depending on the InspectionLevel (IL).

6151
6152 NOTE: In case the vendor does not maintain a separate number space for the SerialNumber, the UniqueID shall be converted to
6153 StringT representation and used as SerialNumber.
6154

6155 **14.3.9 UniqueID**

6156 This mandatory parameter consists of the 2 octet manufacturer distinguishing VendorID (MSO) followed by
6157 the 3 octet W-DeviceID and a 4 octet device distinguishing identifier (LSO). The Device Distinguishing ID
6158 must be a unique value for every sample of all devices produced by that vendor. It is in the responsibility
6159 of the vendor to maintain that number space or its computation algorithm.
6160



6161

Figure 156 UniqueID octet mapping

6162

6163 The UniqueID is either stored in non-volatile memory of the W-Device during production of the device
6164 sample or generated in the W-Device during startup.
6165

6166
6167 NOTE: The vendor should keep a clear relationship between the SerialNumber and the UniqueID of a W-Device. It is highly
6168 recommended that the Device Distinguishing ID is derived from the SerialNumber or vice versa.
6169

6170 **14.3.10 Link Quality**

6171 This index stores statistical data about the reliability of the radio transmission for this W-Device. The method
6172 used for the calculation of the LinkQuality is described in clause 5.4.6).
6173

6174

Table 177 LinkQuality parameter

LinkQuality	Values
0x00	0 %
0x01	1 %
0x02	2 %
...	...
0x64	100 %
0x65 – 0xFF	Reserved

6175

6176
6177
6178
6179
6180
6181**14.3.11 W-Bridge Information**

This index range WBridgeInfo stores the parameters used in a W-Bridge configuration. BDeviceID, BVendorID and BFunctionID are similar to DeviceID, VendorID and FunctionID and refer to the W-Bridge, not the connected IO-Link device.

Table 178 W-Bridge information index assignments

Index	Subindex	Access	Parameter name	Coding	Data type
0x5004	0x00	Gives access to the whole index			
	0x01	R	BDeviceID	Octet 1: DeviceID 1 (MSB) Octet 2: DeviceID 2 Octet 3: DeviceID 3(LSB)	OctetStringT3
	0x02	R	BVendorID	Octet 1: VendorID 1 (MSB) Octet 2: VendorID 2(LSB)	OctetStringT2
	0x03	R	BFunctionID	Octet 1: FunctionID 1 (MSB) Octet 2: FunctionID 2(LSB)	OctetStringT2
	0x04	R	BDevice DistinguishingID	Octet 1: DeviceD_ID1 (MSB) Octet 2: DeviceD_ID 2 Octet 3: DeviceD_ID 3 Octet 4: DeviceD_ID4(LSB)	OctetStringT4
	0x05	R	ConnectionStatus	0x00: No device connected 0x10: Device connected 0x11: Device connected but not communication could be established	UIntegerT8

6182
6183
6184
6185
6186**14.3.12 AdaptiveHopTable**

This index range AdaptiveHopTable stores the values for the updated hopping sequence, see clause 18.4.

Table 179 update hopping table index assignments

Index	Subindex	Access	Parameter name	Data type
0x5006	0x01	W	WakeUpTime	3 Octet
	0x02	W	UpdateType	Octet
	0x03	W	Index	Octets
	0x04	W	Frequency value	OctetString

6187
6188

Annex D

(normative)

15 EventCodes

IO-Link Interface and System Specification defines the concept of Events in clause 7.3.8.1, general structure and encoding of Events in Clause A.6 and Table D.1 lists the specified EventCode identifiers and their definitions.

An EventCode identifies an actual incident. The EventCodes are created by the technology specific Device application (instance = APP).

The Event Codes for IO-Link wireless are placed in the range 0xFFB0 to 0xFFBF as indicated in Table C1.

15.1 EventCodes for Devices

Table 180 lists the specified EventCode identifiers and their definitions. The EventCodes are created by the technology specific Device application (instance = APP).

Table 180 EventCodes

EventCodes	Definition and recommended maintenance action	Device Status Value (NOTE 1)	TYPE
0x0000	No malfunction	0	Notification
0x1000	General malfunction – unknown error	4	Error
0x1001 to 0x17FF	Reserved		
0x1800 to 0x18FF	Vendor specific		
0x1900 to 0x3FFF	Reserved		
0x4000	Temperature fault – Overload	4	Error
0x4001 to 0x420F	Reserved		
0x4210	Device temperature over-run – Clear source of heat	2	Warning
0x4211 to 0x421F	Reserved		
0x4220	Device temperature under-run – Insulate Device	2	Warning
0x4221 to 0x4FFF	Reserved		
0x5000	Device hardware fault – Device exchange	4	Error
0x5001 to 0x500F	Reserved		
0x5010	Component malfunction – Repair or exchange	4	Error
0x5011	Nonvolatile memory loss – Check batteries	4	Error
0x5012	Batteries low – Exchange batteries	2	Warning
0x5013	HMI button pressed	0	Notification
0x5014 to 0x50FF	Reserved		
0x5100	General power supply fault – Check availability	4	Error
0x5101	Fuse blown/open – Exchange fuse	4	Error
0x5102 to 0x510F	Reserved		
0x5110	Primary supply voltage over-run – Check tolerance	2	Warning
0x5111	Primary supply voltage under-run – Check tolerance	2	Warning
0x5112	Secondary supply voltage fault (W-Port Class B) – Check tolerance	2	Warning
0x5113 to 0x5FFF	Reserved		
0x6000	Device software fault – Check firmware revision	4	Error

EventCodes	Definition and recommended maintenance action	Device Status Value (NOTE 1)	TYPE
0x6001 to 0x631F	Reserved		
0x6320	Parameter error – Check data sheet and values	4	Error
0x6321	Parameter missing – Check data sheet	4	Error
0x6322 to 0x634F	Reserved		
0x6350	Parameter changed – Check configuration	4	Error
0x6351 to 0x76FF	Reserved		
0x7700	Wire break of a subordinate device – Check installation	4	Error
0x7701 to 0x770F	Wire break of subordinate device 1 ...device 15 – Check installation	4	Error
0x7710	Short circuit – Check installation	4	Error
0x7711	Ground fault – Check installation	4	Error
0x7712 to 0x8BFF	Reserved		
0x8C00	Technology specific application fault – Reset Device	4	Error
0x8C01	Simulation active – Check operational mode	3	Warning
0x8C02 to 0x8C0F	Reserved		
0x8C10	Process variable range over-run – Process Data uncertain	2	Warning
0x8C11 to 0x8C1F	Reserved		
0x8C20	Measurement range over-run – Check application	4	Error
0x8C21 to 0x8C2F	Reserved		
0x8C30	Process variable range under-run – Process Data uncertain	2	Warning
0x8C31 to 0x8C3F	Reserved		
0x8C40	Maintenance required – Cleaning	1	Notification
0x8C41	Maintenance required – Refill	1	Notification
0x8C42	Maintenance required – Exchange wear and tear parts	1	Notification
0x8C43 to 0x8C9F	Reserved		
0x8CA0 to 0x8DFF	Vendor specific		
0x8E00 to 0xAFFF	Reserved		
0xB000 to 0xBFFF	Reserved for profiles		
0xC000 to 0xFEFF	Reserved		
0xFF00 to 0xFFAF	SDCI specific EventCodes (see Table D.2 in REF 1)		
0xFFB0 to 0xFFBF	IOLW specific EventCodes (see Table 94)		
NOTE 1 See B.2.18 in REF 1			

6207
6208
6209
6210
6211
6212
6213

These W-Port-related events in Table 126 are processed via AL_Event. Table 180 lists basic IOLW Events related to system management, W-Device or W-Master application, and specifies how they are encoded. Other types of Events may be reported but are not specified in this standard. Processing of these Events by the W-Master is vendor specific.

6214

Table 181 EventCodes used for IOLW

Incident ^a	Origin	Instance	Name	EventCode	Action	Remark
System management						
W-Device communication lost	LOCAL	APP	DEV_COM_LOST	0xFF22	PD stop	See Clause 11
Data Storage identification mismatch	LOCAL	APP	DS_IDENT_MISMATCH	0xFF23	-	See Clause 11
Data Storage buffer overflow	LOCAL	APP	DS_BUFFER_OVERFLOW	0xFF24	-	See Clause 11
Data Storage parameter access denied	LOCAL	APP	DS_ACCESS_DENIED	0xFF25	-	See Clause 11
IOLW_Retry_Error	LOCAL	APP	IOLW_RETRY_ERROR	0xFFB1	-	See Clause 11
IOLW_IMATimeout	LOCAL	APP	IOLW_IMATIMEOUT	0xFFB2	-	See Clause 11
Unspecified						
Incorrect Event signaling	LOCAL	DL	EVENT	0xFF31	Event.ind	See Clause 11
Device specific application						
IOLW_Retry_Error	REMOTE	APP	IOLW_RETRY_ERROR	0xFFB9	-	See Clause 11
Data Storage upload request	REMOTE	APP	DS_UPLOAD_REQ	0xFF91	Event.ind	
Reserved	REMOTE	APP		0xFF98	Event.ind	Shall not be used
^a All Events are of StatusCode type 2 (with details), EventQualifier type "Notification", EventQualifierMode "Single-shot"						

6215

6216

Annex E

6217

(normative)

6218

6219

16 Data Types

6220

This annex refers to IO-Link Interface and System Specification REF 1, Annex E, which specifies basic and composite data types. Examples demonstrate the structures and the transmission aspects of data types for singular use or in a packed manner.

6221

6222

6223

6224

6225

Annex F

6226

(normative)

6227

6228

17 Device design rules for low Energy W-Devices

6229

17.1 Low Energy W-Devices

6230

For the design of Low-energy W-Devices, the following support is given by this specification to minimize power consumption:

6231

6232

17.1.1 Low voltage design

6233

To minimize dissipation loss within the W-Device circuitry, the power supply voltage should be chosen as low as possible.

6234

6235

17.1.2 Event triggered activation

6236

To minimize transmitter activity, an uplink is only transmitted when the W-Device has new data to report or the IMA-timer has expired.

6237

6238

17.1.3 Long IMATime

6239

To minimize both receiver and transmitter activity, the maximum configurable IMATime should be chosen as long as possible.

6240

6241

17.1.4 Pre-downlink

6242

To minimize receiver activity for synchronization, a W-Device should receive only the pre-downlink, provided that no new data is received to the W-Device.

6243

6244

17.1.5 W-Master not reachable

6245

A W-Device that has lost connectivity to its W-Master and could not resynchronize should stop listening by issuing SM_SetDeviceMode(IDLE) until e.g. the next IMA time cycle has expired or when an event at the W-Device occurs, e.g. the button on the W-Device has been pressed by the operator.

6246

6247

6248

17.1.6 Quick Synchronization

6249

To minimize receiver activity for synchronization after a longer IMA sleep period, a W-Device listens on its assigned frequency according to the hopping sequence within an uncertainty window. To minimize the worst-case resynchronization time, the usage rate of a certain frequency within the hopping table could be increased. This frequency channel shall then be used by the W-Device for the resynchronization procedure. The W-Device shall analyze its hopping table and use the most used frequency channel for resynchronization purposes.

6250

6251

6252

6253

6254

6255

6256

17.1.7 Establish communication

6257

After waking up a sleeping low energy W-Device (see 10.10.3.2) a paired W-Device starts to synchronize to the W-Master, respectively an unpaired W-Device is waiting for a Master Request, see 5.6.1

6258

6259

To minimize the power consumption the W-Device should go back to sleep after the recommended power on time, see Table 182. Therefore the application has to start or stop the radio via SM_SetDeviceMode.

6260

6261

6261

6262

Table 182 Recommended power on time

	On time	
Synchronization	270 ms	2*80 W-Sub-cycle
Scan	300 ms	50 ms + 30 x 5 W-Sub-cycle
Pairing by Button Pairing by UniqueID	200 ms	See Table 186

6263

6264

17.1.8 HMI sleep

6265

A low energy Device should deactivate the visual indication after a W-Device specific timeout (e.g. 5 min) for power saving reasons.

6266

6267

By pressing the pairing button or by receiving a “WinkOn” SystemCommand, the visual indication shall be activated until the W-Device specific timeout exceeds. After receiving the “WinkOff” SystemCommand the visual indication shall signal the W-Device state defined in Table 124 Visual states of W-Device for the remaining W-Device specific timeout.

6268

6269

6270

6271

6272

17.2 Battery lifetime calculation

6273

The following formula provides support for a rough estimation of battery lifetime for a W-Device.

6274

6275

6276

$$T_{batt} = \frac{Q_{batt} \cdot \frac{1}{24h} \cdot \frac{1}{365d}}{(12.5\text{ ms} + 0.416\text{ ms}) \cdot I_{receive} + (0.2\text{ ms}) \cdot I_{transmit} + (T_{sleep} + 0.208\text{ ms} + 0.632\text{ ms}) \cdot I_{sleep}}$$

$$12.5\text{ ms} + 0.416\text{ ms} + 0.2\text{ ms} + 0.208\text{ ms} + 0.632\text{ ms} + T_{sleep}$$

6277

 = 12.5 ms Synchronization phase and 0.416ms reception phase

6278

 = 0.2 ms Transmitting phase

6279

 = 0.208 ms Tx to Rx change phase, 0.632ms inactive phase and application specific sleeping phase

6280

6281

Thus:

6282

6283

$$T_{batt} = \frac{Q_{batt} \cdot \frac{1}{24h} \cdot \frac{1}{365d}}{12.9\text{ ms} \cdot I_{receive} + 0.2\text{ ms} \cdot I_{transmit} + (T_{sleep} + 0.84\text{ ms}) \cdot I_{sleep}}$$

$$14.0\text{ ms} + T_{sleep}$$

6284

6285

Factor	Unit	Description	Typical value
T _{batt}	[years]	Calculated battery lifetime in years	8 years
Q _{batt}	[Ah]	Capacity of the battery	1.2 Ah
T _{sleep}	[seconds]	Average sleeping time between two active phases	10 s
I _{sleep}	[µA]	Current drain when transceiver is inactive	2 µA
I _{transmit}	[mA]	Avg. current drain when transceiver is in transmitting mode	9 mA
I _{receive}	[mA]	Avg. current drain when transceiver is in receiving mode	6 mA

6286

The above formula is based on the assumptions:

6287

6288

The W-Device is only active, while sending or receiving data. This just includes the yellow and green areas in the figure below. While a physical transceiver chip isn't able to turn on and off immediately before/after its real active time, a tolerance of about 3...5% should be considered regarding the battery lifetime for this point.

6289

6290

6291

6292

6293

An amount of 46 channels is used for the hopping table.

6294

6295

No retries have been used during the data transfer. In an ambient with no excessive RF-disturbances, this should be near to the real-world scenario.

6296

6297

6298

6299 The synchronization process will take an average of 12.5 ms, before the W-Device is able to communicate
6300 with the W-Master again after a long (e.g. some minutes) sleep phase. This estimation is based on an
6301 average of 7.5 Sub-Cycles required for the synchronization.

6302
6303 The formula further is based on the IOLW-specs regarding timing values. To clarify the used times please
6304 check the following extract of the IOLW-timing diagram below.
6305

Annex G

(normative)

18 Frequency Hopping Calculation

18.1 Blacklisting

Blacklisting is a mechanism to avoid on air collision with other wireless systems, such as WLAN. Conventional Bluetooth cannot be blacklisted, because it is an uncoordinated frequency hopper. The blacklist itself uses eighty 1 MHz wide frequency channels.

The blacklisting examples described here are focused on WLAN according to IEEE 802.11 for the 2,4GHz ISM band, which supports 13 different, overlapping 22 MHz frequency blocks. Each blacklisted WLAN channel shall be mapped to the blacklist format described in 5.4.5. The frequency blocks used by IO-Link-Wireless for blacklisting are shown in Table 183. The configuration channels 2401 MHz and 2480 MHz cannot be blacklisted.

Table 183 Frequency table for WLAN channels

WLAN Channels	Centre Frequency (MHz)	Occupied frequencies (MHz)
1	2412	2401-2423
2	2417	2406-2428
3	2422	2411-2433
4	2427	2416-2438
5	2432	2421-2443
6	2437	2426-2448
7	2442	2431-2453
8	2447	2436-2458
9	2452	2441-2463
10	2457	2446-2468
11	2462	2451-2473
12	2467	2456-2478
13	2472	2461-2483

18.2 Creation of frequency hopping table HT01 with blacklisting

The creation of the frequency hopping table HT01 is divided into seven steps:

- (i) Create an array with the all available frequency channels within the 2.4 GHz ISM frequency Band.
- (ii) Find all blacklisted channels according to the provided blacklist and remove them from the frequency array.
- (iii) Perform a circular shift of the array depending on MasterID in order to randomize the starting frequency. *CircularShift(array, MasterID);*
- (iv) Discover the permutation index **P**. The permutation index is a greatest prime number that is smaller or equal to the length of an array created in the previous step:

```

for (index = 0: length(primes_array))
  if (prime_array(index) <= length(array)) then
    P = prime_array(index);
  end if;
end for;

```

- (v) Calculate a Sequence number **N** in according to the MasterID

```

if ((MasterID % 2 )== 0) then
  N = int16((P-1)/2) + (MasterID/2);
else
  N = int16((P-1)/2) - ((MasterID - 1)/2);

```

```

6346     end if;
6347
6348
6349 (vi) Create a Matrix with the possible frequencies, the frequency spacing should be taken in to account.
6350
6351     Possible_Freq_Matrix = zeros(5,length(array));
6352     for (index = 0:length(array))
6353         Possible_Freq_Matrix (0,index) = array(index);
6354         for (index_track = 1 : Track_N)
6355             Possible_Freq_Matrix (index_track,index) = array(((index +
6356                 (Spacing*index_track)) % length(array)));
6357         end for;
6358     end for;
6359
6360 (vii) Generate frequency hopping table from frequency matrix. Selecting of the appropriate frequency is
6361 perform using of Sequence number N and Prime index P as following:
6362 For (index = 0:P)
6363     Sequence_index = (N * index)% P;
6364     for (index_track = 0 : Track_N)
6365         Frequency_Table(index_track, index) =
6366             Possible_Freq_Matrix(index_track, Sequence_index)
6367     end for;
6368 end for;
6369


```

6370 18.2.1 Example with 2 WLAN Channels

```

6371 MasterID = 10;
6372 Track number = 5;
6373 Spacing = 3;
6374 Primes = [2, 3, 5, 7, 11, 13, 17, 19, 23, 29, 31, 37, 41, 43, 47, 53, 59, 61, 67, 71, 73, 79]
6375 BlackList = [0x0000 00000 FFFF F3EF FFF7] (See Table 184, Figure 157)
6376
6377
6378

```



6379 **Figure 157 Blacklisting of 2 WLAN channels in 2.4GHz ISM Band**

```

6380
6381 The influence of the given blacklist on the whole 2.4 GHz ISM Spectrum is demonstrated in Figure 157. If
6382 the blacklist is used the occupied frequencies given in are not used.
6383

```

6384

Table 184 WLAN Channels 1 and 6 Blacklisting example

Blacklisted WLAN Channels	Center (MHz)	Frequency	Occupied frequencies (MHz)
1	2412		2402-2423
6	2437		2427-2448

6385

Calculating a frequency Table using a given data:

6386

6387

6388

Steps (i) and (ii): Find all not blacklisted channels, create an array:

6389

array = {

6390

2424 2425 2426 2427 2428 2429 2430 2454 2455 2456 2457 2458 2459 2460 2461 2462 2463 2464 2465

6391

2466 2467 2468 2469 2470 2471 2472 2473 2474 2475 2476 2477 2478}

6392

6393

Step (iii): Circular Shift; shift length = 10:

6394

array = {

6395

2469 2470 2471 2472 2473 2474 2475 2476 2477 2478 2424 2425 2426 2427 2428 2429 2430 2454 2455

6396

2456 2457 2458 2459 2460 2461 2462 2463 2464 2465 2466 2467 2468}

6397

6398

Step (iv): Find Permutation index **P**:

6399

Length(array) = 32

6400

$P = \max(\text{Primes} < 32) = 31.$

6401

6402

6403

Step (v): Calculate a Sequence number **N** in consideration of the MasterID

6404

6405

$\text{mod}((\text{MasterID}), 2) = \text{mod}(10, 2) = 0 \Rightarrow$

6406

$N = ((P-1) / 2) + (\text{MasterID} / 2) = (31-1 / 2) + (10/2) = 20$

6407

6408

Step (vi): Create a Matrix with the possible frequencies respecting the frequency spacing:

6409

	Frequency																																		
Track 1	2469	2470	2471	2472	2473	2474	2475	2476	2477	2478	2424	2425	2426	2427	2428	2429	2430	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468			
Track 2	2473	2474	2475	2476	2477	2478	2424	2425	2426	2427	2428	2429	2430	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468	2469	2470	2471	2472	2473	2474	2475
Track 3	2476	2477	2478	2424	2425	2426	2427	2428	2429	2430	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468	2469	2470	2471	2472	2473	2474	2475			
Track 4	2424	2425	2426	2427	2428	2429	2430	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468	2469	2470	2471	2472	2473	2474	2475	2476	2477	2478			
Track 5	2427	2428	2429	2430	2454	2455	2456	2457	2458	2459	2460	2461	2462	2463	2464	2465	2466	2467	2468	2469	2470	2471	2472	2473	2474	2475	2476	2477	2478	2424	2425	2426			

6410

Figure 158 Possible Frequencies for 5 Tracks.

6411

6412

Step (vii): Generate the Frequency table using Frequency matrix, the Permutation Index and a Sequence number.

6413

6414

	Frequency																															
Track 1	2457	2478	2466	2455	2476	2464	2430	2474	2462	2428	2472	2460	2426	2470	2458	2424	2467	2456	2477	2465	2454	2475	2463	2429	2473	2461	2427	2471	2459	2425	2469	
Track 2	2461	2427	2470	2459	2425	2468	2457	2478	2466	2455	2476	2464	2430	2474	2462	2428	2471	2460	2426	2469	2458	2424	2467	2456	2477	2465	2454	2475	2463	2429	2473	
Track 3	2464	2430	2473	2462	2428	2471	2460	2426	2469	2458	2424	2467	2456	2477	2465	2454	2474	2463	2429	2472	2461	2427	2470	2459	2425	2468	2457	2478	2466	2455	2476	
Track 4	2467	2456	2476	2465	2454	2474	2463	2429	2472	2461	2427	2470	2459	2425	2468	2457	2477	2466	2455	2475	2464	2430	2473	2462	2428	2471	2460	2426	2469	2458	2424	
Track 5	2470	2459	2424	2468	2457	2477	2466	2455	2475	2464	2430	2473	2462	2428	2471	2460	2425	2469	2458	2478	2467	2456	2476	2465	2454	2474	2463	2429	2472	2461	2427	

6415

Figure 159 Frequency Table for 5 Tracks

6416

6417

18.2.2 Example with one WLAN channel

6418

MasterID = 9;

6419

Track number = 1;

6420

Spacing = 3;

6421

Primes = [2, 3, 5, 7, 11, 13, 17, 19, 23, 29, 31, 37, 41, 43, 47, 53, 59, 61, 67, 71, 73, 79]

6422

BlackList = [0x0000 0000 FFFF F300 0000] (See table 2, Figure 1)

6458 Step (vii): Generate the Frequency array using Frequency matrix, the Permutation Index and a Sequence
 6459 number
 6460

		Frequency																																	
Track 1		2414	2456	2405	2424	2471	2415	2457	2406	2425	2472	2416	2458	2407	2426	2473	2417	2459	2408	2427	2474	2418	2460	2409	2428	2475	2419	2461	2410	2429	2476	2420	2462		
Track 1		2411	2430	2477	2421	2463	2412	2454	2478	2422	2464	2413	2455	2404	2423	2470																			

Figure 162 Frequency Table for 1 Track

18.3 Modified Sequence for ServiceMode

As stated in 5.4.4 "Configuration Channel", the ServiceMode must also utilize the configuration frequencies during the IO-Link Wireless installation phase, for W-Device exchange in exceptionally cases or permanently for roaming. The ServiceMode is called in case of an adding of the W-Device (PL_Pairing.req) or invoking a scanning on the W-Devices in neighborhood (PL_Scan.req).

In W-Master and W-Device the ServiceMode frequency hopping table is implemented by the temporal exchange of a frequency in the normal frequency hopping table every 5th W-Sub-cycle with a configuration frequency. Therefore, one of the configuration frequencies 1 (2401) and 80 (2480) shall be used every 5th W-Sub-cycle in an alternating manner on the W-Master side. In order to ensure the reception of the configuration telegrams, the configuration frequencies shall switch every 10th W-Sub-cycle on the W-Device side. This frequency alternation is implemented using a so called column counter (Col_N) of the hopping frequencies in the frequency hopping table, which will switch to one of the alternating configuration frequencies (see Figure 163).




Figure 163 Usage of the configuration frequencies

Figure 163 shows an example of Track_0 in ServiceMode. In this track, every 5th W-Sub-cycles is substituted by a configuration W-Sub-cycle, the four others remain as regular cyclic data W-Sub-cycles. Besides the content, the carrier frequency in every 5th column in the frequency hopping table is alternately substituted with one of the configuration frequencies.

Configuration W-Sub-cycles are replacing time slots of the regular W-Sub-cycles, thus consuming transmission capacity on the expense of randomly selected slots, which might statistically reduce the guaranteed communication availability of these affected slots.

The modification of the frequency hopping table has only a temporary effect for Scan Mode and Pairing Mode. The maximum activation time of the ServiceMode on the W-Master side is given by the timeouts configured for Scan and Pairing procedures. For scan and pairing procedure on the W-Device, the default

activation time is given by the values in Table 186. The W-Device shall leave the ServiceMode directly after the exchange of the ConnectionParameter.

Table 186 Timeouts for ServiceMode

Timeouts:	W-Master	W-Device
SCAN_TIMEOUT	5 s	-
PAIRING_UNIQUE_TIMEOUT	min. 5 s	200 ms
PAIRING_BUTTON_TIMEOUT	min. 5 s	200 ms

18.4 Adaptive Hopping Table (AHT)

Adaptive hopping table enables to update the hopping table per track in a W-Master and its corresponding W-Devices. The frequency channels are monitored in the W-Master SM AHT handler and if an update is decided then the update data is sent to W-Devices via ISDU. For a track with low energy W-Devices the AHT will invoke a wake up sequence to synchronize a deterministic time when all W-Devices are listening, see Figure 164. W-Master can then trigger a countdown via MasterCommand to all updated W-Devices to synchronize a switch to the new hopping table values, see Figure 165. The support of this function is mandatory for a W-Device and optional for a W-Master.

This includes:

- PL_SetHopTable
- PL_GetHopTable
- PL_SetWakeUpTime
- PL_WakeUpTime
- PL_AHTStatus
- PL_CmdTrig
- DL Cmd handler - states 3 to 7 and all their related transitions
- SM AHT Handler - all states and transitions

Table 187 shows the update types, index and data types used by PL_SetHopTable service. The Data values contain the new frequencies of the hopping table which are restricted according to the Blacklist.

Table 187 AHT UpdateType

UpdateType	Description	Index	DataType
FULL_TABLE	Replace all frequencies of the hopping table, see Figure 162 Frequency Table for 1 Track	0	OctetString
DELETE_CELL	Deletes a frequency from the hopping table according to index. Index x deletes HOP-x.	1-78	-
ADD_CELL	Adds a frequency to the hopping table. Index x adds HOP-x and increments all the indexes larger than x by 1.	1-78	1 Octet
REPLACE_CELL	Replace a frequency in the hopping table, index x replaces HOP-x frequency	1-78	1 Octet

6519
6520
6521
6522
6523

Figure 164 shows an example for using Mcmd(WakeUp) in combination with Mcmd(Jump) to set a new hopping table HT02. This figure describes the timeline view for WakeUp of several W-Devices and synchronizing the switch of the hopping table to all W-Devices in the track.




Figure 164 Changing Hopping Table synchronization timeline

6524
6525

6526 Figure 165 shows the sequence of WakeUp of low energy W-Device
 6527




Figure 165 AHT WakeUp sequence

6528
 6529

6530
6531

Figure 166 shows the Jump sequences




Figure 166 AHT Jump sequence

6532
6533

6534

Annex H

6535 (normative)

6536 **19 How to get a certified product**

6537 In order to get a certified IO-Link wireless product, different testing and certification aspects must be
6538 considered:

6539 **19.1 Radio Certification**

6540 To satisfy the legal jurisdiction under which the wireless equipment shall be used, the locally valid regulatory
6541 compliance rules for wireless equipment must be fulfilled. Currently relevant regulations are outlined in
6542 more detail in Annex I "Regulatory Compliance".

6543 **19.2 IO-Link Certification**

6544 Compliance to the IO-Link wireless protocol defined in this standard must be documented with a
6545 manufacturer self-declaration and associated test reports for the specific product, containing the aspects
6546 of both protocol conformity and performance conformity.

6547 The required testing procedures and recommended test lab services towards the testing references will
6548 also be described in the separate IO-Link wireless test specification see REF 11

Annex I

(normative)

20 Regulatory Compliance

20.1 General

This Annex I provides requirements for compliance of IO-Link wireless devices operating in the 2.4 GHz ISM band with several regulatory standards. For operation in the United States, FCC 15.247 must be met (see clause 20.2). Additional requirements apply in Europe, which can be met by complying with FCC 15.247 in combination with harmonized standards EN 300 328 (see clause 20.3) and EN 300 440 (see clause 20.4).

It is generally recommended to handle the regulatory standards in a similar approach as the Bluetooth low Power Special Interest Group has outlined in (REF 5: "Bluetooth Low Energy Regulatory Aspects")

Additionally, ETSI Guide EG 203 367 (V1.1.0) contains guidance information in assessing conformity against the essential requirements of the Radio Equipment Directive 2014/53/EU (RED) for the combination of radio and non-radio products as well as the integration of several radios into a single equipment.

NOTE: In this Annex I, the terms "devices" and "equipment" are used synonymously and refer to electronics with radios operating according to the appropriate standard.

20.2 Compliance with FCC 15.247

To comply with FCC 15.247, the manufacturer should declare IO-Link wireless equipment according to FCC §15.247-a2 as "**systems using digital modulation**", where "**the minimum 6 dB bandwidth shall be at least 500 kHz**". This requires static testing at the relevant frequency channels (typically band edges and center channel) while frequency hopping algorithms are not subject of compliance testing procedures, see REF 7.

20.3 Compliance with ETSI EN 300 328 V2.1.1 (2016-11)

EN 300 328 is listed as a harmonized standard under the Radio Equipment Directive 2014/53/EU.

To comply with EN 300 328, the manufacturer should declare its IO-link wireless equipment as utilizing "**other types of Wide Band modulation**" with "**RF Output power is less than 10 dBm e.i.r.p.**" and being a "**non-adaptive equipment**".

The limit of 10 dBm shall apply for any combination of power level and intended antenna assembly. If more than one track (antenna) is used in a device, all tracks are sharing the 10 dBm. For example, 3 dBm per track are permitted in case of five tracks.

The required test suites must be carried out and compliance declared for the relevant technical requirements see REF 8.

20.4 Compliance with ETSI EN 300 440 V.2.1.1 (2017-03)

EN 300 440 is listed as harmonized standard under the Radio Equipment Directive 2014/53/EU.

To comply with EN 300 440, the manufacturer should declare its IO-link wireless equipment as "**Non-specific short-range device**" restricted to a "**Maximum radiated peak power (e.i.r.p.)**" of "**10 mW e.i.r.p.**" The e.i.r.p. is defined as the "**maximum radiated power of the transmitter and its antenna**", thus antenna gains better than 0 dBi require an adequate power adjustment.

The required test suites must be carried out and compliance declared for the relevant technical requirements see REF 9 and REF 10.

Annex J

21 Wireless IODD File handling

21.1 File naming convention

Wireless IODD files must follow the naming convention described below:

- IO-Link Device: <VendorName>-<DeviceName>-YYYYMMDD-IODD1.1.xml
- IO-Link W-Device: <VendorName>-<DeviceName>-**WD**-YYYYMMDD-IODD1.1.xml
- IO-Link W-Bridge: <VendorName>-<DeviceName>-**WB**-YYYYMMDD-IODD1.1.xml
- IO-Link W-Bridge with Device: <VendorName>-<DeviceName>-**WBD**-YYYYMMDD-IODD1.1.xml

21.2 Rules merging IODD and W-IODD file for W-Bridges

This section describes how the W-IODD of a W-Bridge and the IODD of wired IO-link Device shall be merged.




Figure 167 Merging IODD and W-IODD file for W-Bridges

The IODD of the wired IO-Link Device is taken as the basis document and is modified to correspond to the description of a W-Device. The information about the W-Device is being copied from the W-IODD of the bridge.

Step 1) The <CommNetworkProfile ... > </CommNetworkProfile>, see clause 10.9.1.1, tag and its content of the wired device IODD shall be replaced by its counterpart of the bridge-IODD.

Step 2) The <StdVariableRef id="V_SystemCommand"> must be completed with the wireless system command value 64 and 65, see Table 166.

```

<VariableCollection>
  <StdVariableRef id="V_DirectParameters_1" />
  <StdVariableRef id="V_DirectParameters_2" />
  <StdVariableRef id="V_SystemCommand">
...
    <StdSingleValueRef value="64" />
  <StdSingleValueRef value="65" />
...
  </StdVariableRef>
...
</VariableCollection>

```

Step 3) All <Variable ... index="i" ...> tags with index between 0x5000 and 0x50FF must be copied from the W-IODD of the bridge.

Step 4) The text from the W-IODD stored within <ExternalTextCollection>...</ExternalTextCollection> must also be transferred corresponding to the changes described at steps 1 to 4. Merging conflicts, for example due to identical variable name, shall be prompted within the engineering tool for correction by the user.

Step 5) The IODD checker must be executed in order to update the <Stamp crc="xxxxxxx"> tag and validate the newly created IODD file.

Step 6) For traceability, the merging process and tool are documented in the subelement <BridgeLayer> of CommNetworkProfile:

```
6645 <CommNetworkProfile xsi:type="IOLinkWirelessCommNetworkProfileT" iolinkRevision="V1.1">
6646 <TransportLayer>
6647   <PhysicalLayer minCycleTime="..." doubleSlot="..." isABridge="yes">
6648     ...
6649   </PhysicalLayer>
6650   <BridgeLayer>
6651     <DeviceIODD fileName="<VendorName>-<DeviceName>YYYYMMDD-IODD1.1.xml" />
6652     <BridgeIODD fileName="<VendorName>-<DeviceName>-WB-YYYYMMDD-IODD1.1.xml" />
6653     <MergerTool vendorName="..." name="..." version="nn.nn.nn" />
6654   </BridgeLayer>
6655 </TransportLayers>
6656 ...
6657 </CommNetworkProfile>
```

6660 Step 7) The newly created W-IODD file for the IO-Link W-Bridge with Device must be saved following the
6661 naming convention stated under clause 21.1

6662

22 Bibliography

6663

REF 1 IO-Link Community, IO-Link Interface and System Specification, V1.1.2, July 2013, Order No. 10.002

6664

6665

REF 2[IEC 61131-9, Programmable controllers – Part 9: Single-drop digital communication interface for small sensors and actuators (SDCI)

6666

6667

6668

REF 3 IO-Link Community, IO Device Description (IODD), V1.1, Order No. 10.012 (available at <http://www.io-link.com>)

6669

6670

6671

REF 4 IO-Link Community, IO-Link Smart Sensor Profile 2nd edition, V1.0, Order No. 10.042 (available at <http://www.io-link.com>)

6672

6673

6674

REF 5 Bluetooth SIG - Regulatory Committee, "Bluetooth Low Energy Regulatory Aspects", V10r00, 26 April 2011

6675

6676

6677

REF 6 IO-Link Community, IO-Link Common Profile, V0.9.9, Order No. 10.072 (available at <http://www.io-link.com>)

6678

6679

6680

REF 7 FCC §15.247 "Radio frequency devices; Operation within the bands 902-928 MHz, 2400-2483.5 MHz, and 5725-5850 MHz"

6681

6682

FCC §15.247 "Radio frequency devices; Operation within the bands 902-928 MHz, 2400-2483.5 MHz, and 5725-5850 MHz"

6683

6684

6685

REF 8 ETSI EN 300 328 V2.1.1 "Wideband transmission systems

6686

ETSI EN 300 328 V2.1.1 "Wideband transmission systems; Data transmission equipment operating in the 2.4 GHz ISM band and using wide band modulation techniques; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU"

6687

6688

6689

6690

REF 9 ETSI EN 300 440 V2.1.1 "Short Range Devices (SRD)

6691

ETSI EN 300 440 V2.1.1 "Short Range Devices (SRD); Radio equipment to be used in the 1 GHz to 40 GHz frequency range; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU"

6692

6693

6694

6695

REF 10 ETSI EN 300 440 V2.1.1 "Short Range Devices (SRD)

6696

ETSI EG 203 367 V.1.1.1 "Guide to the application of harmonized standards covering articles 3.1b and 3.2 of the Directive 2014/53/EU (RED) to multi-radio and combined radio and non-radio equipment"

6697

6698

6699

REF 11 IO-Link wireless test specification

6700

6701

6702

REF 12 IO-Link Community, Addendum 2017, V2.0, December 2017, Order No. 10.152

© Copyright by:

IO-Link Community
Haid-und-Neu-Str. 7
76131 Karlsruhe
Germany

Phone: +49 (0) 721 / 96 58 590

Fax: +49 (0) 721 / 96 58 589

e-mail: info@io-link.com

<http://www.io-link.com/>

